

GENUINE

228pgs

RT180 (A-G)



LIT-11616-07-30

**RT180 (A-B)
SERVICE MANUAL**

**© 1990 by Yamaha Motor Corporation, U.S.A.
1st Edition, January 1990**

**All rights reserved. Any reprinting or
unauthorized use without the written
permission of Yamaha Motor Corporation,
U.S.A. is expressly prohibited.**

Printed in U.S.A.

P/N: LIT-11616-07-30

NOTICE

This manual was written by Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to put an entire mechanic's education into one manual, so it is assumed that people using this book to perform maintenance and repairs on Yamaha motorcycles have a basic understanding of the mechanical concepts and procedures inherent in motorcycle repair technology. Without such knowledge, attempted repairs or service to this model render it unfit to use and/or unsafe.

Yamaha Motor Company, Ltd. is continually striving to improve all models manufactured by Yamaha. Modifications and significant changes in specifications or procedures will be forwarded to all Authorized Yamaha dealers and will, where applicable, appear in future editions of this manual.

SERVICE DIVISION
YAMAHA MOTOR DA AMAZÔNIA., LTDA.

HOW TO USE THIS MANUAL

PARTICULARLY IMPORTANT INFORMATION

This material is distinguished by the following notation:



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

WARNING

Failure to follow WARNING instructions could result in severe injury or death to the motorcycle operator, a bystander, or a person inspecting or repairing the machine.

CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the machine.

NOTE:

A NOTE provides key information to make procedures easier or clearer.

MANUAL FORMAT






















All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, hand reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspection operations.

In this format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g.,

- Bearings
Pitting/Damage → Replace.

EXPLODED DIAGRAM

Each chapter provides exploded diagrams before each disassembly section for ease in identifying correct disassembly and assembly procedures.

① GEN INFO 	② SPEC 
③ INSP ADJ 	④ ENG 
⑤ CARB 	⑥ CHAS 
⑦ ELEC 	⑧ TRBL SHTG ?
⑨ 	⑩ 
⑪ 	⑫ 
⑬ 	⑭ 
⑮ 	
⑯ 	⑰  ⑱ 
⑲  ⑳  ㉑ 	
㉒ 	

ILLUSTRATED SYMBOLS (Refer to the illustration)

Illustrated symbols ① to ⑧ are designed as thumb tabs to indicate the chapter's number and content.

- ① General information
- ② Specifications
- ③ Periodic inspection and adjustment
- ④ Engine
- ⑤ Carburetion
- ⑥ Chassis
- ⑦ Electrical
- ⑧ Troubleshooting








Illustrated symbols ⑨ to ⑮ are used to identify the specifications appearing in the text.

- ⑨ Filling fluid
- ⑩ Lubricant
- ⑪ Special tool
- ⑫ Tightening
- ⑬ Wear limit, clearance
- ⑭ Engine speed
- ⑮ Ω, V, A

Illustrated symbols ⑯ to ㉒ in the exploded diagram indicate grade of lubricant and location of lubrication point.

- ⑯ Apply engine oil
- ⑰ Apply gear oil
- ⑱ Apply molybdenum disulfide oil
- ⑲ Apply wheel bearing grease
- ⑳ Apply lightweight lithium-soap base grease
- ㉑ Apply molybdenum disulfide grease
- ㉒ Apply locking agent (LOCTITE®)

INDEX

GENERAL INFORMATION	
	GEN INFO 1
SPECIFICATIONS	
	SPEC 2
PERIODIC INSPECTION AND ADJUSTMENT	
	INSP ADJ 3
ENGINE OVERHAUL	
	ENG 4
CARBURETION	
	CARB 5
CHASSIS	
	CHAS 6
ELECTRICAL	
	ELEC 7
TROUBLESHOOTING	?
	TRBL SHTG 8




CONTENTS

CHAPTER 1. GENERAL INFORMATION

MACHINE IDENTIFICATION	1-1
VEHICLE IDENTIFICATION NUMBER	1-1
ENGINE SERIAL NUMBER	1-1
 IMPORTANT INFORMATION	1-2
PREPARATION FOR REMOVAL	1-2
ALL REPLACEMENT PARTS	1-3
GASKETS, OIL SEALS, AND O-RINGS	1-3
LOCK WASHERS/PLATES AND COTTER PINS	1-3
BEARINGS AND OIL SEALS	1-3
CIRCLIPS	1-4
 SPECIAL TOOLS	1-4
FOR TUNE UP	1-4
FOR ENGINE SERVICE	1-5
FOR CHASSIS SERVICE	1-6
FOR ELECTRICAL COMPONENTS	1-7

CHAPTER 2. SPECIFICATIONS

GENERAL SPECIFICATIONS	2-1
 MAINTENANCE SPECIFICATIONS	2-4
ENGINE	2-4
CHASSIS	2-8
ELECTRICAL	2-11
 GENERAL TORQUE SPECIFICATIONS	2-13
 DEFINITION OF UNIT	2-13
 LUBRICATION POINTS AND LUBRICANT TYPE	2-14
ENGINE	2-14
CHASSIS	2-15
 CABLE ROUTING	2-16




CHAPTER 3. PERIODIC INSPECTION AND ADJUSTMENT

INTRODUCTION	3-1
PERIODIC MAINTENANCE/LUBRICATION	3-1
ENGINE	3-2
IDLE SPEED ADJUSTMENT	3-2
THROTTLE CABLE FREE PLAY ADJUSTMENT	3-3
CARBURETOR CABLE FREE PLAY ADJUSTMENT	3-3
AUTOLUBE PUMP STROKE ADJUSTMENT	3-4
AUTOLUBE PUMP AIR BLEEDING	3-5
SPARK PLUG INSPECTION	3-7
IGNITION TIMING CHECK	3-8
ENGINE OIL LEVEL INSPECTION	3-8
OIL WARNING LIGHT CHECKING METHOD	3-8
TRANSMISSION OIL LEVEL INSPECTION	3-9
TRANSMISSION OIL REPLACEMENT	3-10
CLUTCH ADJUSTMENT	3-11
AIR FILTER CLEANING	3-14
CARBURETOR JOINT INSPECTION	3-17
FUEL LINE INSPECTION	3-17
CRANKCASE VENTILATION HOSE INSPECTION	3-17
EXHAUST SYSTEM INSPECTION	3-11
ENGINE OIL LINE INSPECTION	3-18
YEIS HOSE INSPECTION	3-18
CHASSIS	3-19
FRONT BRAKE ADJUSTMENT	3-19
REAR BRAKE ADJUSTMENT	3-19
BRAKE FLUID INSPECTION	3-20
FRONT BRAKE PAD INSPECTION	3-21
REAR BRAKE SHOE INSPECTION	3-22
BRAKE HOSE INSPECTION	3-22
DRIVE CHAIN SLACK ADJUSTMENT	3-22
DRIVE CHAIN LUBRICATION	3-24
STEERING HEAD ADJUSTMENT	3-24
FRONT FORK INSPECTION	3-26
REAR SHOCK ABSORBER ADJUSTMENT	3-26
TIRE INSPECTION	3-27
WHEEL INSPECTION	3-28
SPOKE INSPECTION AND TIGHTENING	3-28
CABLE INSPECTION AND LUBRICATION	3-29

CHAPTER 4. ENGINE OVERHAUL

ENGINE REMOVAL	4-1
SIDE COVERS	4-1
FUEL TANK	4-1
TRANSMISSION OIL	4-2
EXHAUST PIPE	4-2
CARBURETOR.....	4-2
AUTOLUBE PUMP CABLE AND HOSE	4-2
CLUTCH CABLE	4-3
LEADS AND HOSE	4-3
DRIVE CHAIN	4-4
ENGINE REMOVAL	4-4
ENGINE DISASSEMBLY	4-5
CYLINDER HEAD, CYLINDER AND PISTON.....	4-5
CLUTCH, PRIMARY DRIVE GEAR	4-6
CLUTCH PUSH LEVER.....	4-8
KICK AXLE AND KICK IDLE GEAR	4-9
SHIFT SHAFT AND STOPPER LEVER	4-9
MAGNETO ROTOR	4-10
CRANKCASE (LEFT).....	4-11
SHIFTER AND TRANSMISSION	4-13
CRANKSHAFT	4-13
AUTOLUBE PUMP ASSEMBLY	4-13
INSPECTION AND REPAIR	4-14
CYLINDER HEAD	4-14
CYLINDER AND PISTON	4-15
PISTON RINGS	4-18
PISTON PIN AND BEARING	4-18
CLUTCH	4-19
PRIMARY DRIVE	4-21
TRANSMISSION AND SHIFTER	4-21
KICK STARTER	4-23
SHIFT SHAFT AND STOPPER LEVER	4-24
CRANKSHAFT	4-24
AUTOLUBE PUMP.....	4-25
CRANKCASE	4-26
BEARINGS AND OIL SEAL	4-26
ENGINE ASSEMBLY AND ADJUSTMENT	4-28
AUTOLUBE PUMP.....	4-28
CRANKSHAFT	4-32
TRANSMISSION AND SHIFTER	4-32
CRANKCASE (RIGHT)	4-33



**GEN
INFO** **1**



SPEC **2**




**INSP
ADJ** **3**




ENG **4**




CARB **5**



CHAS **6**



ELEC **7**



**TRBL
SHTG** **8**

MAGNETO ROTOR	4-36
SEGMENT, STOPPER LEVER AND SHIFT SHAFT	4-38
KICK AXLE AND KICK IDLE GEAR	4-38
CLUTCH PUSH LEVER	4-40
PRIMARY DRIVE GEAR AND CLUTCH	4-42
PISTON, CYLINDER AND CYLINDER HEAD	4-46
REMounting ENGINE	4-50

CHAPTER 5. CARBURETION

CARBURETOR	5-1
REMOVAL	5-2
DISASSEMBLY	5-3
INSPECTION	5-4
ASSEMBLY	5-6
INSTALLATION	5-8
ADJUSTMENT	5-9
 REED VALVE	 5-10
REMOVAL	5-11
DISASSEMBLY	5-11
INSPECTION	5-11
ASSEMBLY	5-12
INSTALLATION	5-13


CHAPTER 6. CHASSIS

FRONT WHEEL	6-1
REMOVAL	6-2
INSPECTION	6-2
INSTALLATION	6-4
 REAR WHEEL	 6-6
REMOVAL	6-7
INSPECTION	6-8
INSTALLATION	6-9
 FRONT BRAKE	 6-12
BRAKE PAD REPLACEMENT	6-14
CALIPER DISASSEMBLY	6-16
MASTER CYLINDER DISASSEMBLY	6-18

INSPECTION AND REPAIR	6-19
ASSEMBLY	6-22
AIR BLEEDING	6-26
FRONT FORK	6-28
REMOVAL	6-29
DISASSEMBLY	6-30
INSPECTION	6-32
ASSEMBLY	6-33
INSTALLATION	6-35
STEERING HEAD AND HANDLEBAR	6-37
REMOVAL	6-38
INSPECTION	6-40
INSTALLATION	6-42
REAR SHOCK ABSORBER AND SWINGARM	6-46
HANDLING NOTES	6-48
NOTES ON DISPOSAL	6-48
REMOVAL	6-49
INSPECTION	6-52
SIDE CLEARANCE ADJUSTMENT	6-53
INSTALLATION	6-55
DRIVE CHAIN AND SPROCKETS	6-57
REMOVAL	6-58
INSPECTION AND CLEANING	6-59
INSTALLATION	6-60

CHAPTER 7. ELECTRICAL

RT180A CIRCUIT DIAGRAM	7-1
COMPONENTS	7-1
COLOR CODE	7-1
ELECTRICAL COMPONENTS	7-2
SIGNAL SYSTEM	7-3
CIRCUIT SYSTEM	7-3
TROUBLESHOOTING	7-4
IGNITION SYSTEM	7-9
TROUBLESHOOTING	7-10



**GEN
INFO 1**



SPEC 2




**INSP
ADJ 3**




ENG 4




CARB 5



CHAS 6



ELEC 7




**TRBL
SHTG 8**

CHAPTER 8. TROUBLESHOOTING

STARTING FAILURE/HARD STARTING	8-1
FUEL SYSTEM	8-1
ELECTRICAL SYSTEM	8-2
COMPRESSION SYSTEM.....	8-3
POOR IDLE SPEED PERFORMANCE	8-3
POOR IDLE SPEED PERFORMANCE	8-3
POOR MEDIUM AND HIGH SPEED PERFORMANCE	8-4
FUEL SYSTEM	8-4
ELECTRICAL SYSTEM	8-4
COMPRESSION SYSTEM.....	8-5
FAULTY GEAR SHIFTING	8-6
HARD SHIFTING	8-6
CHANGE PEDAL DOES NOT MOVE.....	8-6
JUMP OUT GEAR	8-6
CLUTCH SLIPPING/Dragging	8-7
CLUTCH SLIPPING	8-7
CLUTCH DRAGGING	8-7
IMPROPER KICKING	8-8
SLIPPING	8-8
HARD KICKING	8-8
KICK CRANK NOT RETURNING	8-8
INSTABLE HANDLING	8-9
INSTABLE HANDLING	8-9
OVER-HEATING OR OVER-COOLING	8-10
OVER-HEATING	8-10
FAULTY BRAKE/Front Fork Oil Leakage AND	8-11
FRONT FORK MALFUNCTION.....	8-11
POOR BRAKING EFFECT	8-11
OIL LEAKAGE	8-11
MALFUNCTION	8-11

GENERAL INFORMATION



MACHINE IDENTIFICATION

VEHICLE IDENTIFICATION NUMBER


The vehicle identification number 1 is stamped into the right side of the steering head pipe.

NOTE: _____

The vehicle identification number is used to identify your machine and may be used to register your machine with the licensing authority in your state.

1

Starting Serial Number:
9C63VCAO*L0000101



ENGINE SERIAL NUMBER

The engine serial number 1 is stamped into the elevated part of the right rear section of the engine.


NOTE: _____

The first three digits of this number are for model identification; the remaining digits are the unit production number.

Starting Serial Number:
3VC - 000101

NOTE: _____


Designs and specifications are subject to change without notice.




**IMPORTANT INFORMATION
PREPARATION FOR REMOVAL**

1. Remove all dirt, mud, dust, and foreign material before removal and disassembly.


2. Use proper tools and cleaning equipment.
Refer to "SPECIAL TOOL".



3. When disassembling the machine, keep mated parts together. This includes gears, cylinders, pistons, and other parts that have been "mated" through normal wear. Mated parts must be reused as an assembly or replaced.



4. During the machine's disassembly, clean all parts and place them in trays in the order of disassembly. This will speed up assembly time and help assure that all parts are correctly reinstalled.




5. Keep away from fire.

ALL REPLACEMENT PARTS

1. We recommended to use Yamaha genuine parts for all replacements. Use oil and/or grease recommended by Yamaha for assembly and adjustment. Other brands may be similar in function and appearance, but inferior in quality.


GASKETS, OIL SEALS, AND O-RINGS

1. All gaskets, seals, and O-rings should be replaced when an engine is overhauled. All gasket surfaces, oil seal lips, and O-rings surfaces must be cleaned.
2. Properly oil all mating parts and bearings during reassembly. Apply grease to the oil seal lips.



LOCK WASHERS/PLATES AND COTTER PINS

1. All lock washers/plates ① and cotter pins must be replaced when they are removed. Lock tab(s) should be bent along the bolt or nut flat(s) after the bolt or nut has been properly tightened.




BEARINGS AND OIL SEALS

1. Install the bearing(s) and oil seal(s) with their manufacturer's marks or numbers facing outward. (In other words, the stamped letters must be on the side exposed to view.) When installing oil seal(s), apply a light coating of light-weight lithium base grease to the seal lip(s). Oil the bearings liberally when installing.


① Oil seal

CAUTION: _____

Do not use compressed air to spin the bearings dry. This causes damage to the bearing surfaces.



① Bearing


**CIRCLIPS**

1. All circlips should be inspected carefully before reassembly. Always replace piston pin clips after one use. Replace deformed circlips. When installing a circlip ①, make sure that the sharp edged corner ② is positioned opposite to the thrust ③ it receives. See the sectional view.

④ Shaft


SPECIAL TOOLS

The proper special tools are necessary for complete and accurate tune-up and assembly. Using the correct special tool will help prevent damage caused by the use of improper tools or improvised techniques.

**FOR TUNE UP**


1. Fuel Level Gauge
P/N. YM-01312-A

This gauge is used to measure the fuel level in the float chamber.




2. Engine Tachometer
P/N. YU-08036

This tool is needed for determining engine rpm.



3. Inductive Timing Light
P/N. YM-33277


This tool is necessary for adjusting ignition timing.



FOR ENGINE SERVICE


- 1. Universal Clutch Holder
P/N. YM-91042

This tool is used to hold the clutch when loosening or tightening the clutch boss locknut.




- 2. Universal Rotor Holder
P/N. YU-01235

This tool is used when loosening or tightening the flywheel magneto securing bolt.




- 3. Flywheel Puller
P/N. YM-01189

This tool is used for removing the flywheel.




- 4. Piston Pin Puller
P/N. YU-01304

This tool is used to remove the piston pin.




5. Crankcase Separating Tool
P/N. YU-01135

This tool is used to remove the crankshaft or separate the crankcase.



6. Crankshaft Installing Tool
P/N. YU-90050 ①
P/N. YU-90063 ②


These tools are used to install the crankshaft.



FOR CHASSIS SERVICE


1. T-Handle - ①
P/N. YM-01326
Front Fork Cylinder Holder - ②
P/N. YM-01300-1

This tool is used to loosen and tighten the front fork cylinder holding bolt.




2. Front Fork Seal Driver (Weight) - ①
P/N. YM-33963
Adapter - ②
P/N. YM-01369

These tools are used when installing the fork seal.



3. Ring Nut Wrench
P/N. YU-33975


This tool is used to loosen and tighten the steering ring nut.



FOR ELECTRICAL COMPONENTS

- 1. Dynamic Coil Tester
P/N. YU-34487

This tester is necessary for checking the ignition system components.



- 2. Pocket Tester
P/N. YU-03112

This tester is invaluable for checking the electrical system.



SPECIFICATIONS

GENERAL SPECIFICATIONS

Model	RT180A
Model Code Number Vehicle Identification Number Engine Serial Number	3VC1 9263VCA07K0000101 3VC-000101
Dimensions: Overall Length Overall Width Overall Height Seat Height Wheel Base Minimum Ground Clearance	2,050 mm (80.71 in) 860 mm (33.86 in) 1,175 mm (46.26 in) 860 mm (33.86 in) 1,345 mm (52.93 in) 290 mm (11.42 in)
Basic Weight: With Oil and Full Fuel Tank	112kg (247 lb)
Minimum Turning Radius:	2,200 mm (86.6 in)
Engine: Engine Type Induction System Cylinder Arrangement Displacement Bore x Stroke Compression Ratio Starting System Lubrication System	Air-cooled, 2-Stroke, gasoline Reed valve Forward Inclined Single Cylinder 176 cm ³ 64.5 x 54.0 mm (2.54 x 2.12 in) 6.5 : 1 Kick starter Separate lubrication (Yamaha Autolube)
Engine Oil: Type Capacity (Oil tank)	Yamalube "2" or air cooled 2-stroke engine oil 0.75 L (0.66 Imp qt, 0.79 US qt)
Transmission Oil: Type Capacity: Periodic Oil Change Total Amount	Yamalube "4", SAE 10W30 type SE motor oil or "GE" gear oil 0.55 L (0.48 Imp qt, 0.58 Us qt) 0.6 L 0.53 Imp qt, 0.63 Us qt)
Air Filter: Type	Wet element

2

GENERAL SPECIFICATIONS

SPEC



Model	RT180A													
Fuel: Type Fuel Tank Capacity: Full Amount Reserve Amount	Regular gasoline 13 L (2.86 Imp gal, 3.43 US gal) 1.1 L (0.24 Imp gal, 0.29 US gal)													
Carburetor: Type/Quantify Manufacturer	VM24SS/1pc MIKUNI													
Spark plug: Type/Quantity Manufacturer Plug Gap	B8ES/1 pc NGK 0.6 ~ 0.7 mm (0.024 ~ 0.028 in)													
Clutch: Type	Wet, multiple disc													
Transmission: Type Primary Reduction System Primary Reduction Ratio Secondary Reduction System Secondary Reduction Ratio Operation Gear Ratio	Constant mesh 6-speed Helical gear 71/22 (3.227) Chain drive 51/14 (3.643) Manual <table style="width: 100%; border: none;"> <tr> <td style="width: 30%; text-align: right;">1st</td> <td style="width: 70%;">35/11 (3.182)</td> </tr> <tr> <td style="text-align: right;">2nd</td> <td>29/15 (1.933)</td> </tr> <tr> <td style="text-align: right;">3rd</td> <td>26/19 (1.368)</td> </tr> <tr> <td style="text-align: right;">4th</td> <td>24/22 (1.091)</td> </tr> <tr> <td style="text-align: right;">5th</td> <td>22/23 (0.957)</td> </tr> <tr> <td style="text-align: right;">6th</td> <td>21/25 (0.840)</td> </tr> </table>		1st	35/11 (3.182)	2nd	29/15 (1.933)	3rd	26/19 (1.368)	4th	24/22 (1.091)	5th	22/23 (0.957)	6th	21/25 (0.840)
1st	35/11 (3.182)													
2nd	29/15 (1.933)													
3rd	26/19 (1.368)													
4th	24/22 (1.091)													
5th	22/23 (0.957)													
6th	21/25 (0.840)													
Chassis: Frame Type Caster Angle Trail	Semi Double Cradle 28.5° 119 mm (4.79 in)													
Tire: Type Size: Front Rear	With tube 80/100-21 100/100-18													
Cold Tire Pressure:	Front	Rear												
	100 kPa (1.0 kgf/cm ² , 15 psi)	100 kPa (1.0 kgf/cm ² , 15 psi)												





GENERAL SPECIFICATIONS




Model	RT180A
Brake: Front Brake Type Front Brake Operation Rear Brake Type Rear Brake Operation	Single disc brake Right hand operation Drum brake Right foot operation
Suspension: Front Suspension Type Rear Suspension Type	Telescopic fork Swingarm (Monocross)
Shock Absorber: Front Shock Absorber Rear Shock Absorber	Coil spring/Oil damper Coil and gas spring/Oil damper
Wheel Travel: Front Wheel Travel Rear Wheel Travel	200 mm (7.9 in) 150 mm (5.9 in)
Electrical: Ignition System Generator System	CDI Flywheel magneto



MAINTENANCE SPECIFICATIONS
ENGINE

Model	RT180A
<p>Cylinder Head: Warpage Limit</p> 	<p>0.03 mm (0.0012 in) *Lines indicate straightedge measurement</p>
<p>Cylinder: Bore Size Taper Limit Out of Round Limit</p>	<p>64.50 ~ 64.52 mm (2.539 ~ 2.540 in) 0.05 mm (0.002 in) 0.01 mm (0.0004 in)</p>
<p>Piston: Piston Size "D" Measuring Point "a"</p>  <p>Piston Off-Set Piston-to-Cylinder Clearance <Limit> Over Size: 1st 2nd</p>	<p>64.46 ~ 64.50 mm (2.538 ~ 2.539 in) 10 mm (0,4 in)</p> <p>0.5 mm (0.02 in) 0.035 ~ 0.040 mm (0.0014 ~ 0.0016 in) 0.1 mm (0.004 in) 64.75 mm (2.549 in) 65 mm (2.559 in)</p>
<p>Piston Ring: Sectional Sketch</p> <p>Top Ring</p>  <p>2nd Ring</p>  <p>End Gap (Installed) Top Ring 2nd Ring Side Clearance Top Ring Top Ring</p>	<p>Keystone type B = 1.5 mm (0.059 in) T = 2.6 mm (0.102 in)</p> <p>Keystone type B = 1.5 mm (0.059 in) T = 2.6 mm (0.102 in)</p> <p>0.3 ~ 0.5 mm (0.012 ~ 0.02 in) 0.3 ~ 0.5 mm (0.012 ~ 0.02 in) 0.03 ~ 0.05 mm (0.001 ~ 0.002 in) 0.03 ~ 0.05 mm (0.001 ~ 0.002 in)</p>



Model	RT180A
<p>Crankshaft: Crank Width "A" Runout Limit "B" Big End Side Clearance "C" <Limit> Small End Free Play "D"</p> 	<p>55.85 ~ 55.95 mm (2.19 ~ 2.20 in) 0.03 mm (0.0012 in) 0.15 ~ 0.70 mm (0.006 ~ 0.028 in) <1.0 mm (0.040 in)> 1.0 ~ 1.5 mm (0.039 ~ 0.059 in)</p>
<p>Clutch Friction Plate: Thickness Quantity Wear Limit Clutch Plate: Thickness Quantity Warpage Limit Clutch Spring: Free Length Quantity Minimum Free Length Clutch Release Method Push Rod Bending Limit</p>	<p>2.92 ~ 3.08 mm (0.115 ~ 0.121 in) 6 pcs 2.7 mm (0.106 in) 1.1 ~ 1.3 mm (0.043 ~ 0.051 in) 5 pcs 0.05 mm (0.002 in) 33 mm (1.299 in) 5 pcs 32 mm (1.260 in) Inner Push, Cam Push <0.5 mm (0.02 in)></p>
<p>Transmission: Main Axle Runout Limit Drive Axle Runout Limit</p>	<p>0.08 mm (0.003 in) 0.08 mm (0.003 in)</p>
<p>Shifter: Type Guide Bar Bending Limit</p>	<p>Guide bar 0.03 mm (0.0012 in)</p>
<p>Kick Starter: Type</p>	<p>Kick and mesh type</p>
<p>Air Filter: Oil Grade</p>	<p>Foam Air-Filter Oil</p>

MAINTENANCE SPECIFICATIONS

SPEC






Model	RT180A
Carburetor: I.D. Mark Main Jet (M.J.) Air Jet (A.J.) Jet Needle-Position (J.N.) Needle Jet (N.J.) Cutaway (C.A.) Pilot Outlet (P.O.) Pilot Jet (P.J.) Air Screw (A.S.) Bypass 1 (B.P. 1) Valve Seat Size (V.S.) Starter Jet (G.S.) Fuel Level (F.L.) Float Height (F.H.) Idling Speed	3VC00 # 130 ø0.5 5JP27-2 P-2 3.0 ø0.6 #27.5 1-1/2 turns out ø1.4 ø2.5 #20 25 ~ 27 mm (0.984 ~ 1.063 in) 20 ~ 22 mm (0.787 ~ 0.866 in) 1,450 ~ 1,550 r/min
Reed Valve: Valve Thickness Valve Stopper Height Valve Bending Limit	0.18 ~ 0.22 mm (0.007 ~ 0.009 in) 8.7 ~ 9.3 mm (0.342 ~ 0.366 in) 0.9 mm (0.035 in)
Lubrication System: Autolube Pump: Color Code Minimum Stroke Maximum Stroke Minimum Output Maximum Output Pulley Adjusting Mark	Blue 0.20 ~ 0.25 mm (0.008 ~ 0.010 in) 1.85 ~ 2.05 mm (0.073 ~ 0.08 in) 0.48 ~ 0.59 cm ³ per 200 strokes 4.40 ~ 4.87 cm ³ per 200 strokes at idle with cable slack eliminated

NOTE; _____
 Float level and fuel level are measured from the gasket mating surface of the carburetor body.

MAINTENANCE SPECIFICATIONS



Tightening Torque:						
Parts to be tightened	Qty.	Thread size	Tightening torque			Remarks
			Nm	m·kg	ft·lb	
Spark Plug	1	M14 x 1.25	25	2.5	18	
Cylinder Head						
Stud Bolt	4	M8 x 1.25	12	1.2	8.6	
Nut	4	M8 x 1.25	25	2.5	18	
Cylinder						
Stud Bolt	4	M10 x 1.25	15	1.5	11	
Nut	4	M10 x 1.25	35	3.5	25	
Oil Pump						
Screw	2	M5 x 0.8	8	0.8	5.8	
Carburetor Joint						
Bolt	4	M6 x 1.0	8	0.8	5.8	
Exhaust Pipe						
Nut	2	M6 x 1.0	11	1.1	7.9	
Stud Bolt	2	M6 x 1.0	5	0.5	3.6	
Transmission Oil Drain Bolt	1	M12 x 1.5	20	2.0	14	
Crankcase Cover						
Screw	15	M6 x 1.0	10	1.0	7.2	
Oil Pump Cover						
Screw	3	M6 x 1.0	8	0.8	5.8	
Crankcase						
Screw	12	M6 x 1.0	8	0.8	5.6	
Kick Crank Bass						
Bolt	1	M8 x 1.25	23	2.3	17	
Primary Drive Gear						
Nut	1	M12 x 1.0	60	6.0	43	
Clutch Boss						
Nut	1	M14 x 1.0	50	5.0	36	
Clutch Spring						
Bolt	5	M5 x 0.8	6	0.6	4.3	
Plate Cover						
Screw	2	M6 x 1.0	10	1.0	7.2	
Drive Sprocket						
Nut	1	M6 x 1.0	60	6.0	43	
Stopper Lever						
Bolt	1	M6 x 1.0	10	1.0	7.2	
Change Pedal						
Bolt	1	M6 x 1.0	11	1.1	7.9	
CDI Magneto Rotor						
Nut	1	M12 x 1.25	70	7.0	50	
Stator						
Screw	2	M6 x 1.0	8	0.8	5.8	



CHASSIS

Model	RT180A
Steering System: Bearing Type Upper Lower Bearing Size (Quantity): Upper Lower	Ball bearing Ball bearing 3/16 in (22 pcs.) 1/4 in (19 pcs.)
Front Suspension: Front Fork Travel Fork Spring Free Length <Limit> Spring Rate (K ₁) (K ₂) Stroke (K ₁) (K ₂) Optional Spring Oil Capacity Oil Grade	200 mm (7.87 in) 535 mm (21.06 in) 524 mm (20.6 in) 5.2 N/mm (0.52 kg/mm, 29.1 lb/in) 7.8 N/mm (0.78 kg/mm, 43.6 lb/in) 0 ~ 105 mm (0 ~ 4.1 in) 105 ~ 200 mm (4.1 ~ 7.9 in) NO 280 cm ³ Fork oil 10W or equivalent
Rear Suspension: Shock Absorber Travel Spring Free Length Fitting Length Spring Rate (K ₁) Stroke (K ₁) Spring Rate (K ₂) Stroke (K ₂) Optional Spring Enclosed Gas Pressure	82 mm (3.23 in) 258 mm (10.16 in) 245 mm (9.65 in) 40 N/mm (4.0 kg/mm, 224 lb/in) 0 ~ 67 mm (0 ~ 2.64 in) 66 N/mm (6.6 kg/mm, 369 lb/in) 67 ~ 82 mm (2.64 ~ 3.23 in) NO 150 kPa (15 kg/cm ² , 213 psi)
Swingarm: Free Play Limit	1.0 mm (0.04 in) Move swingarm end side to side
Front Wheel: Type Rim Size Rim Material Rim Runout Limit: Vertical Lateral	Spoke Wheel 1.85 x 21 Steel 2.0 mm (0.08 in) 2.0 mm (0.08 in)

MAINTENANCE SPECIFICATIONS

SPEC



Model	RT180A
Rear Wheel: Type Rim Size Rim Material Rim Runout Limit: Vertical Lateral	Spoke Wheel 2.15 x 18 Steel 2.0 mm (0.08 in) 2.0 mm (0.08 in)
Drive Chain: Type/Manufacturer Number of Links Chain Free Play	428H/DAIDO 122 40 mm (1.57 in)
Front Disc Brake: Type Disc Outside Diameter Disc Thickness Pad Thickness <Wear Limit> Master Cylinder Inside Diameter Caliper Cylinder Inside Diameter Brake Fluid Type	Single 245 mm (9.65 in) 4.0 mm (0.16 in) 6.8 mm (0.27 in) 0.8 mm (0.03 in) 12.7 mm (0.5 in) 38.1 mm (1.50 in) DOT N° 4 If DOT N° 4 is not available, DOT N° 3 can be used.
Rear Drum Brake: Type Brake Drum Inside Diameter <Limit> Shoe Spring Free Length Lining Thickness <Limit>	Leading, Trailing 130 mm (5.12 in) 131 mm (5.16 in) 36.5 mm (1.44 in) 4 mm (0.16 in) 2 mm (0.08 in)
Brake Lever and Brake Pedal: Brake Lever Free Play Brake Pedal Position Brake Pedal Free Play	10 ~ 20 mm (0.4 ~ 0.8 in) At end of brake lever 20 mm (0.8 in) Below top of footrest 20 ~ 30 mm (0.8 ~ 1.2 in)
Clutch Lever and Throttle Grip: Clutch Leve Free Play/position Throttle Cable Free Play	2 ~ 3 mm (0.08 ~ 0.12 in) 3 ~ 5 mm (0.12 ~ 0.20 in) at grip flange

MAINTENANCE SPECIFICATIONS



Tightening Torque:					
Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m·kg	ft·lb	
Front Fork, Steering:					
Handle Crown and Inner Tube	M8 x 1.25	23	2.3	17	Refer to "NOTE"
Handle Crown and Steering Shaft	M14 x 1.25	54	5.4	39	
Handlebar Holder	M8 x 1.25	15	1.5	11	
Steering Shaft and Ring Nut	M25 x 1.0	6	0.6	4.3	
Under Bracket Pinch Bolt	M8 x 1.25	23	2.3	17	
Engine Mounting:					
Front	M8 x 1.25	25	2.5	18	
Rear upper	M8 x 1.25	25	2.5	18	
Rear lower	M10 x 1.25	39	3.9	28	
Swingarm, Rear Shock Absorber:					
Pivot Shaft and Frame	M12 x 1.25	43	4.3	31	
Rear Shock Absorber and Frame	M10 x 1.25	25	2.5	18	
Wheels:					
Front Wheel Axle and Nut	M14 x 1.5	85	8.5	61	
Rear Wheel Axle and Nut	M14 x 1.5	85	8.5	61	
Front Brake Caliper	M10 x 1.25	35	3.5	25	
Union Bolt (Brake Hose)	M10 x 1.25	27	2.7	20	
Wheel Sprocket and Hub	M10 x 1.25	39	3.9	28	
Rear Wheel Hub Stud Bolt	M10 x 1.25	39	3.9	28	

NOTE:

1. First, tighten the ring nut approximately 38 Nm (3.8 m·kg, 27 ft·lb) by using the torque wrench, then loosen the ring nut one turn.
2. Retighten the ring nut to specification.

MAINTENANCE SPECIFICATIONS



Model	RT180A
Voltage: Ignition Timing (B.T.D.C.) Advancer Type	18° at 1,500 r/min Electrical type
<p style="text-align: center;">Ignition Timing (B.T.D.C.)</p> <p style="text-align: center;">Engine speed (x 1,000 r/min)</p>	
C.D.I.: Magneto Model/Manufacturer C.D.I. Unit Model/Manufacturer Pickup Coil Resistance (Color) Source Coil Resistance (Color)	42L - VO/YAMAHA 23K - MO/YAMAHA 90 ~ 110 Ω at 20 °C (68 °F) (White/Red - Black) 270 ~ 330 Ω at 20 °C (68 °F) (Black/Red - Black)
Ignition Coil: Model/Manufacturer Minimum Spark Gap Primary Coil Resistance Secondary Coil Resistance	3T2 - MO/YAMAHA 6 mm (0.24 in) 1.4 ~ 1.8 Ω at 20 °C (68 °F) 5.1 ~ 7.7 kΩ at 20 °C (68 °F)
Spark Plug Cap: Type Plug Cap Resistance	Rubber Type 5 kΩ

MAINTENANCE SPECIFICATIONS

SPEC




Charging System:	Flywheel magneto
Flywheel Magneto : Model/Manufacturer Charging Coil Resistance (Color) Lighting Coil Resistance (Color)	42L-VO/YAMAHA 0.28 ~ 0.34 Ω at 20 °C (68 °F) (White - Black) 0.42 ~ 0.52 Ω at 20 °C (68 °F) (Yellow - Black)
Oil Level Switch:	23 K-OO/YAMAHA
Indicator Light: Oil Level	12 V 3.4 W x 1 pc



GENERAL TORQUE SPECIFICATIONS

This chart specifies torque for standard fasteners with standard I.S.O. pitch threads. Torque specifications for special components or assemblies are included in the applicable sections of this book. To avoid warpage, tighten multifastener assemblies in a crisscross fashion, in progressive stages, until full torque is reached. Unless otherwise specified, torque specifications call for clean, dry threads. Components should be at room temperature.

A (Nut)	B (Bolt)	General torque specifications		
		Nm	m•kg	ft•lb
10 mm	6 mm	6	0.6	4.3
12 mm	8 mm	15	1.5	11
14 mm	10 mm	30	3.0	22
17 mm	12 mm	55	5.5	40
19 mm	14 mm	85	8.5	61
22 mm	16 mm	130	13.0	94



- A: Distance across flats
- B: Outside thread diameter

DEFINITION OF UNITS

Unit	Read	Definition	Measure
mm	millimeter	10^{-3} meter	Length
cm	centimeter	10^{-2} meter	Length
kg	kilogram	10^3 gram	Weight
N	Newton	$1 \text{ kg} \times \text{m}/\text{sec}^2$	Force
Nm	Newton meter	$\text{N} \times \text{m}$	Torque
m•kg	Meter kilogram	$\text{m} \times \text{kg}$	Torque
Pa	Pascal	N/m^2	Pressure
N/mm	Newton per millimeter	N/mm	Spring rate
L	Liter	—	Volume or Capacity
cm^3	Cubic centimeter	—	
r/min	Revolution per minute	—	Engine Speed

LUBRICATION POINTS AND LUBRICANT TYPE



LUBRICATION POINTS AND LUBRICANT TYPE

ENGINE

Lubrication Points (Part name)	Lubricant Type
Oil seal lips (All)	
O-rings (All)	
Bearing retainer Crankshaft bearings (Left and center) Needle bearings (Connecting rod) Main axle bearings Drive axle bearings Push lever bearing	
Crank pins	
Piston rings, piston pins and pistons	
Shaft (Autolube pump)	
Kick idle gear	
Kick axle	
Primary driven gear (Clutch housing)	
Push rod	
Push lever axle	
Sliding gear (Transmission)	
Free movement gear (Transmission)	
Guide bar (Shift forks)	
Crankcase mating surfaces	Quick gasket ®

LUBRICATION POINTS AND LUBRICANT TYPE




CHASSIS

Lubrication Points (Part name)	Lubricant Type
Ball bearing (Steering shaft)	
Bearing (Steering shaft)	
Pivot shaft (Swingarm)	
Oil seal lip (Swingarm, Steering shaft)	
Bearing (Swingarm)	
Collar (Swingarm)	
Throttle grip inner surface	
Lever pivots and cable end	
Oil seal lip (Wheels)	
Rear brake pedal boss	
Sidestand pivot	




CABLE ROUTING

- ① Throttle cable
- ② "OIL" warning indicator light
- ③ Clutch cable
- ④ Wireharness
- ⑤ Clamp
- ⑥ Brake hose
- ⑦ ENGINE STOP switch lead
- ⑧ Switch lead band



CABLE ROUTING

- ① Flywheel magneto lead
- ② Clutch cable holder
- ③ Clamp
- ④ Cable guide
- ⑤ Band
- ⑥ Clamp
- ⑦ Throttle cable
- ⑧ Oil pump cable
- ⑨ ENGINE STOP switch lead






CABLE ROUTING

- ① Band
- ② Clamp
- ③ Oil tank breather hose
- ④ Band
- ⑤ Clamp
- ⑥ Oil hose
- ⑦ C.D.I. unit lead
- ⑧ Band
- ⑨ Rectifier/Regulator lead

- A To flywheel magneto lead
- B To rectifier/regulator
- C To C.D.I. unit
- D Pass the clutch cable





PERIODIC INSPECTION AND ADJUSTMENT

INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

PERIODIC MAINTENANCE/LUBRICATION

ITEM	REMARKS	BREAK-IN 1 month	EVERY	
			6 months	12 months
Spark plug	Check condition. Clean or replace if necessary.	○	○	○
Air filter	Clean. Replace if necessary.	Every 20 ~ 40 hrs (More often in wet or dust areas)		
Carburetor*	Check idle speed/starter operation. Adjust if necessary.	○	○	○
Fuel line	Check fuel hose for cracks or damage. Replace if necessary.		○	○
Transmission oil*	Check oil level/oil leakage. Correct if necessary. Replace every 24 months. (Warm up engine before draining.)	REPLACE	○	○
Autolube pump*	Check operation. Correct if necessary. Air bleeding.	○	○	○
Front brake*	Check operation/fluid leakage/See NOTE. Correct if necessary.		○	○
Rear brake*	Check operation. Adjust if necessary.		○	○
Clutch*	Check operation. Adjust if necessary.		○	○
Rear arm pivot*	Check rear arm assembly for looseness. Correct if necessary. Moderately repack every 24 months**.	○		○
Wheels	Check balance/damage/runout/spoke tightness. Repair if necessary.		○	○
Wheel bearings*	Check bearings assembly for looseness/damage. Replace if damaged.		○	○
Steering bearing*	Check bearings assembly for looseness. Correct if necessary. Moderately repack every 24 months**.	○		○
Front forks*	Check operation/oil leakage. Repair if necessary.		○	○
Rear shock absorber*	Check operation/oil leakage. Repair if necessary.		○	○
Drive chain	Check chain slack/alignment. Adjust if necessary. Clean and lube.	Every ride (More often in wet or dusty areas)		
Fittings/Fasteners*	Check all chassis fittings and fasteners. Correct if necessary.	○	○	○
Sidestand*	Check operation. Repair if necessary.	○	○	○


*: It is recommended that these items be serviced by a Yamaha dealer or other qualified mechanic.

** : Medium weight wheel bearing grease.

NOTE:



Brake fluid replacement:

1. When disassembling the master cylinder or caliper cylinder, replace the brake fluid. Normally check the brake fluid level and add the fluid as required.
2. On the inner parts of the master cylinder and caliper cylinder, replace the oil seals every two years.
3. Replace the brake hoses every four years, or if cracked or damaged.




**ENGINE
IDLE SPEED ADJUSTMENT**

1. Adjust:
- Engine idle speed

Adjustment steps:	
<ul style="list-style-type: none"> • Turn in the pilot air screw ① until it is lightly seated. • Turn out the pilot air screw for the specified number of turns. 	
Pilot Air Screw Turns Out: 1-1/2 counterclockwise turns from seat	
<ul style="list-style-type: none"> • Start the engine and let it warm up. Turn the throttle stop screw ② until the idle speed is in the specified range. Use the inductive Tachometer. 	
Turn in	Idle speed becomes higher.
Turn out	Idle speed becomes lower.
	Inductive tachometer: P/N. YU-08036
	Engine idle speed: 1,450 ~ 1,550 r/min
<ul style="list-style-type: none"> • Turn the pilot air screw ① in or out 1/8 turn increments to achieve the highest speed with just the pilot air screw. • Once again, turn the throttle stop screw ② to attain the specified idle speed. 	


2. Check:
- Throttle cable free play
Refer to "THROTTLE CABLE FREE PLAY ADJUSTMENT" section.

THROTTLE CABLE FREE PLAY ADJUSTMENT


INSP	
ADJ	


THROTTLE CABLE FREE PLAY ADJUSTMENT NOTE:

Before adjusting the throttle cable free play, the engine idle speed should be adjusted.



1. Check:
 - Throttle cable free play @Out of specification → Adjust.

	Throttle cable free play: 3 ~ 5 mm (0.12 ~ 0.20 in)
---	---



2. Adjust:
 - Throttle cable free play


Adjustment steps:	
• Loosen the locknut ①.	
• Turn the adjuster ② in or out until the correct free play is obtained.	
Turn in	Free play is increased.
Turn out	Free play is decreased.
• Tighten the locknut.	

CARBURETOR CABLE FREE PLAY ADJUSTMENT

NOTE: _____

Before adjusting carburetor cable, throttle cable free play should be adjusted.

AUTOLUBE PUMP STROKE ADJUSTMENT



1. Pull up the adjuster cover ①.
2. Check:
 - Carburetor cable free play ②
 - Out of specification → Adjust.



Carburetor cable free play:
1.0 mm (0.04 in)

3. Adjust:
 - Carburetor cable free play.

Adjustment steps:

- Loosen the locknut ②.
- Turn the adjuster ③ in or out until the correct free play is obtained.


Turn in	Free play is increased.
---------	-------------------------

Turn out	Free play is decreased.
----------	-------------------------


- Tighten the locknut.

4. Push the adjuster cover down.

AUTOLUBE PUMP STROKE ADJUSTMENT



1. Remove:
 - Autolube pump cover ①
2. While running the engine at idle, observe the pump adjusting plate carefully. Stop the engine when the adjusting plate moves out to its limit.




3. Measure:
 - Gap ②
 - Out of specification → Adjust.
 - Measure the gap with the thickness gauge ① between the raised boss ② on the pump adjusting pulley and the adjusting plate ③.



Minimum pump stroke:
0.20 ~ 0.25 mm (0.008 ~ 0.010 in)

NOTE: _____
 When inserting the thickness gauge between the adjusting plate and the adjusting pulley, be careful so that neither the plate nor the pulley is moved. In other words, do not force the thickness gauge into the gap.




4. Adjust:
 Autolube pump minimum stroke

Adjustment steps:

- Remove the locknut ①, spring washer ② and adjusting plate ③.
- Adjust the pump stroke by adding or removing a shim ④


Add shim	Pump stroke is increased.
Remove shim	Pump stroke is decreased.

• Install the adjusting plate, spring washer and locknut.

	Locknut: 6 Nm (0.6 m·kg, 4,3 ft·lb)
---	---

• Recheck the minimum pump stroke. If out of specification, perform the above steps again.

5. Install:
 • Autolube pump cover

	Bolts (Autolube pump cover): 8 Nm (0.8 m·kg, 5.6 ft·lb)
---	---


6. Check:
 • Autolube pump cable free play


AUTOLUBE PUMP AIR BLEEDING

NOTE: _____
 The Autolube pump and delivery lines must be bled on the following occasions:


- Setting up a new machine out of the crate.
- Whenever the oil tank has run dry.
- Whenever any portion of the engine oil system is disconnected.

AUTOLUBE PUMP AIR BLEEDING


INSP	
ADJ	



1. Remove:
 - Autolube pump cover
2. Fill:
 - Oil tank ①

	Yamalube 2-cycle oil or air-cooled 2-stroke engine oil
---	---

② Oil tank filter cap




3. Air bleed:
 - Pump case and/or oil pipe

Air bleeding steps: <ul style="list-style-type: none">• Remove the bleed screw ①.• Keep the oil running out until air bubbles disappear.• When air bubbles are expelled completely, tighten the bleed screw.
NOTE: <ul style="list-style-type: none">• Check the bleed screw gasket, and if damaged, replace with a new one.• Place a rag or oil pan under the Autolube pump to catch oil.



4. Air bleed:
 - Pump distributor and/or delivery pipe.

Air bleeding steps: <ul style="list-style-type: none">• Remove the clip ①.• Start the engine.• Pull the pump cable ② all the way out to set the pump stroke to a maximum.
NOTE: <p>It is difficult to bleed the distributor completely with the pump stroke at a minimum, and therefore the pump stroke should be set to a maximum.</p> <ul style="list-style-type: none">• Keep the engine running at about 2,000 r/min for two minutes or so, and both distributor and delivery pipe can be completely bled.• Install the clip.



SPARK PLUG INSPECTION

INSP
ADJ




5. Install:
- Autolube pump cover



Screw (Autolube pump cover):
8 Nm (0.8 m·kg, 5.6 ft·lb)

SPARK PLUG INSPECTION

1. Remove:
- Spark plug
2. Inspect:
- Spark plug type
Incorrect → Replace.



Standard spark plug:
B8ES(NGK)

3. Inspect:
- Electrode ①
Wear/Damage → Replace.
 - Insulator ②
Abnormal color → Replace.
Normal color is a medium-to-light tan color.
4. Clean:
- Spark plug
Use a spark plug cleaner or wire brush.
5. Measure:
- Plug gap ③
Use a Wire Gauge or Feeler Gauge.
Out of specification → Regap.



Spark plug gap:
0.6 ~ 0.7 mm (0.024 ~ 0.028 in)

6. Tighten:
- Spark plug



Spark plug:
20 Nm (2.0 m·kg, 14 ft·lb)

NOTE:


- Before installing a spark plug, clean the gasket and plug surfaces.
- Finger-tighten the spark plug before torquing to specification.

IGNITION TIMING CHECK


Non-adjustable

ENGINE OIL LEVEL INSPECTION




1. Check:
 - Oil levelOil level low → Add sufficient oil.

	Recommended oil: Yamalube 2-cycle engine oil or air-cooled 2-stroke engine oil with "BIA certified for service TCW".
	Oil tank capacity: 0.75 L (0.66 Imp qt, 0.79 US qt)

OIL WARNING LIGHT CHECKING METHOD



TRANSMISSION OIL REPLACEMENT



CAUTION:

Always use the same type of engine oil; mixing oils may result in a harmful chemical reaction and lead to poor performance.

- ① "OIL" warning indicator light

TRANSMISSION OIL LEVEL INSPECTION

1. Inspect:

- Transmission oil level
- Oil level low → Add sufficient oil

Transmission oil level inspection steps:

- Place the machine on a level place.
- Warm up the engine for several minutes, and stop it.
- Rest the oil dipstick ① on the threads of the hole.

NOTE:

- Wait a few minutes until level settles before inspecting.
- Position machine straight up when inspecting oil level, a slight tilt to the side can produce false readings.

Inspect:

- Oil level
- Oil level should be between maximum ② and minimum ③ marks.
- Oil level low → Add oil to proper level.



Recommended oil:


Yamalube "4", SAE 10W30 Type SE Motor Oil or "GL" Gear Oil

NOTE:

Recommended engine oil classification: API Service "SE", "SF" type or equivalent (e.g. "SF-SE", "SF-SE-CC", "SF-SE-SD" etc.).


CAUTION:

- Do not add any chemical additives. Transmission oil also lubricates the clutch and additives could cause clutch slippage.
- Be sure no foreign material enters the crankcase.




TRANSMISSION OIL REPLACEMENT

1. Warm up the engine for several minutes.
2. Place an open container under the engine.
3. Remove:
 - Oil filler cap ①
 - Drain plug ②
 Drain transmission oil.




4. Inspect:
 - Gasket (Drain plug) ①
 - O-ring (Oil cap) ②
 Damage → Replace.

5. Install:
 - Drain plug

	Drain plug: 20 Nm (2.0 m · kg, 14 ft · lb)
---	--

6. Fill:
 - Crankcase

	Recommended oil: Yamalube "4", SAE 10W30 Type SE Motor Oil or "GL" Gear Oil. Periodic oil change: 0.55 L (0.48 Imp qt, 0.58 US qt)
---	--

NOTE: _____
 Recommended engine oil classification: API Service "SE", "SF" type or equivalent (e.g. "SF-SE", "SF-SE-CC", "SF-SE-SD" etc.).

CAUTION: _____


- Do not add any chemical additives. Transmission oil also lubricates the clutch and additives could cause clutch slippage.
- Be sure no foreign material enters the crankcase.

CLUTCH ADJUSTMENT

INSP	
ADJ	


- 7. Install:
 - Oil filter cap
- 8. Inspect:
 - Oil leaks
 - Oil level

NOTE: _____
Wipe off any oil spilled on the crankcase.



CLUTCH ADJUSTMENT Free Play Adjustment

- 1. Check:
 - Clutch cable free play @Out of specification → Adjust.


	Free Play: 2~3 mm (0.08~0.12in)
---	---

- 2. Adjust:
 - Clutch cable free play

Adjustment steps: <ul style="list-style-type: none">• Loosen the locknut ①.• Turn the adjuster ② in or out until the correct free play is obtained.	
Turn in	Free play is increased.
Turn out	Free play is decreased.
• Tighten the locknut.	

CLUTCH ADJUSTMENT

INSP
ADJ



Mechanism Adjustment

1. Loosen:
 - Locknuts ①
2. Turn in the adjusters ②

3. Disconnect:

- Autolube pump cable ①
- Autolube pump hoses ②

Refer to the "AUTOLUBE PUMP CABLE AND HOSE" section in CHAPTER 4.

4. Drain




- Transmission oil
- Refer to the "TRANSMISSION OIL REPLACEMENT" section.

5. Loosen:

- Rear brake adjuster

6. Remove:

- Kick crank ③
- Crankcase cover (right) ④



7. Adjust:

- Adjuster (Push rod # 1) ①

Adjustment steps:

- Loosen the locknut ②.
- Move the push lever ③ forward until it stops.
- With the push lever in this position, turn the adjuster ① to align the mark ④ on the end of the push lever with the projection ⑤ on the crankcase.
- Tighten the locknut ②.



Locknut:

8 Nm (0.8m·kg, 5.8 ft·lb)

8. Install:

- Crankcase cover (right) ①
- Kick crank ②



Screw (Crankcase cover):

10 Nm (1.0 m·kg, 7.2 ft·lb)

Drain Plug (Oil):

20 Nm (2.0 m·kg, 14 ft·lb)

Bolt (Kick crank):

23 Nm (2.3 m·kg, 17 ft·lb)

NOTE:


- When installing the crankcase cover, engage the autolube pump drive gear with its driven gear and slowly turn the autolube pump shaft, if you need.
- Tighten the screws (Crankcase cover) in a crisscross pattern.
- Install the kick crank so that it does not contact the case.

9. Adjust:

- Rear brake free play
Refer to the "REAR BRAKE ADJUSTMENT" section.

AIR FILTER CLEANING


INSP
ADJ



10. Install:
 - Gasket (Autolube pump cover) ①
11. Connect:
 - Autolube pump hoses ②
 - Autolube pump cable ③
12. Adjust:
 - Clutch cable free play
Refer to the "FREE PLAY ADJUSTMENT" section.
13. Fill:
 - Crankcase
Refer to the "TRANSMISSION OIL REPLACEMENT" section.





Recommended oil:
Yamalube "4", SAE 10W30 Type
SE Motor Oil or "GL" Gear Oil.
Periodic oil change:
0.55 L (0.48 Imp qt, 0.58 US qt)



14. Air bleeding:
 - Autolube pump
Refer to the "AUTOLUBE PUMP AIR BLEEDING" section.
15. Install:
 - Autolube pump cover ①



Screw (Autolube pump cover):
8 Nm (0.8 m·kg, 5.6 ft·lb)



AIR FILTER CLEANING


1. Remove:
 - Side cover (Left)
 - Filter case cover ①
2. Remove:
 - Screw (air filter assembly)
 - Element guide 1 ①
 - Air filter element ②
 - Element guide 2 ③

CAUTION: _____

The engine should never be run without the air cleaner element; excessive piston and/or cylinder wear may result.

3. Inspect:

- Air filter element ②
 - Element guide ①
 - Element guide ③
- Damage → Replace.



4. Clean:

- Air filter element

Cleaning steps:

- Wash the element with solvent ①.
- Remove the remaining solvent by squeezing the element.
- Apply the foam-air-filter oil ② to the entire surface of the element.
- Wrap the element with a clean rag, and squeeze out the excess oil.

NOTE: _____

The element should be wet but not dripping.

CAUTION: _____

Do not twist the filter element when squeezing it.

⚠ WARNING _____

Never use low flash point solvents such as gasoline to clean the air filter element. Such solvent may lead to a fire or explosion.


5. Clean the inside of the air filter case and the case cover, using a cloth dampened with solvent.
6. Grease the entire sealing edge of the element with soap-base lithium grease.
7. Install:
 - Element guide ②
 - Air filter element
 - Element guide ①
 - Screws

CAUTION: _____

Make sure the element edge fits into the corresponding element groove.





8. Install:
 - Filter case cover
 - Side cover (Left) ①



CARBURETOR JOINT INSPECTION


1. Inspect:
 - Carburetor joint ①
Cracks/Damage → Replace.
Refer to the "REED VALVE" section in CHAPTER 6 for replacement.
2. Check the tightening torque of the carburetor joint securing bolts.

	<p>Bolt (Carburetor joint): 8 Nm (0.8 m·kg, 5.8 ft·lb)</p>
---	---



FUEL LINE INSPECTION

1. Inspect:
 - Fuel hose ①
Cracks/Damage → Replace.
Loose connection → Connect properly.




CRANKCASE VENTILATION HOSE INSPECTION

1. Inspect:
 - Crankcase ventilation hose ①
Cracks/Damage → Replace.


CAUTION:

Make sure the crankcase ventilation hose is routed correctly.




EXHAUST SYSTEM INSPECTION

1. Inspect:
 - Gasket (Exhaust pipe) ①
 - Joint (Silencer) ②
Damage → Replace.
Exhaust gas leakage → Repair.
 - Exhaust pipe ③
 - Silencer ④
Cracked/Dent/Damage → Repair or replace.
2. Tighten:
 - Exhaust pipe
 - Muffler

	Nut ⑤ (Exhaust pipe): 11 Nm (1.1 m·kg, 7.9 ft·lb)
---	---



ENGINE OIL LINE INSPECTION/ Y.E.I.S. HOSE INSPECTION



ENGINE OIL LINE INSPECTION


1. Remove:
 - Autolube pump cover
2. Inspect:
 - Oil hose ①
 - Oil delivery hose ②
 - Cracks/Damage → Replace.
 - Loose connection → Correct properly.

3. Install:
 - Autolube pump cover



Y.E.I.S HOSE INSPECTION


1. Inspect:
 - Y.E.I.S. hose ①
 - Cracks/Damage → Replace.



CHASSIS

FRONT BRAKE ADJUSTMENT

1. Check:
 - Brake lever free play **a**
 - Out of specification → Adjust.

 **Free play:**
5 ~ 8 mm (0.20 ~ 0.31 in)

2. Adjust:
 - Brake lever free play

Adjustment steps:

- Loosen the locknut **2**.
- Turn the adjuster **1** in or out until the specified free play is obtained.


Turn in	Free play is decreased.
---------	-------------------------

Turn out	Free play is increased.
----------	-------------------------

- Tighten the locknut.

CAUTION:


Proper lever free play is essential to avoid excessive brake drag.



REAR BRAKE ADJUSTMENT

Rear Brake Pedal Height Adjustment

1. Check:
 - Brake pedal height **a**
 - Out of specification → Adjust.

 **Brake pedal height:**
20 mm (0.8 in)
Below top of footrest.

2. Adjust:
 - Brake pedal height

Adjustment steps:


- Loosen the locknut **1**.
- Turn the adjuster **2** in or out until the specified pedal height is obtained.

BRAKE FLUID INSPECTION

INSP
ADJ





Turn in	Pedal height is increased.
Turn out	Pedal height is decreased.
• Tighten the locknut.	



Rear Brake Free Play Adjustment


1. Check:
 - Brake pedal free play $\text{\textcircled{a}}$
 - Out of specification \rightarrow Adjust.

	Brake pedal free play: 20 ~ 30 mm (0.8 ~ 1.2 in)
---	--




2. Adjust:
 - Rear brake pedal free play

Adjustment steps:	
• Turn the adjuster $\text{\textcircled{1}}$ in or out until the specified free play is obtained.	
Turn in	Free play is decreased.
Turn out	Free play is increased.



BRAKE FLUID INSPECTION

1. Place the machine on a level surface.
2. Inspect:
 - Brake fluid level
 - Fluid level is below "LOWER" level line $\text{\textcircled{1}}$
 - \rightarrow Replenish.


	Recommended brake fluid: DOT #4 If DOT #4 is not available, #3 can be used.
---	---

NOTE: _____

- Position the machine straight up when inspecting the brake fluid level.
- When inspecting the front brake fluid level, make sure the master cylinder top is horizontal by turning the handlebars.


⚠ WARNING

- Use only the designated quality brake fluid: otherwise, the rubber seals may deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid: mixing fluids may result in a harmful chemical reaction and lead to poor performance.
- Be careful that water does not enter the master cylinder when refilling. Water will significantly lower the boiling point of the fluid and may result in a vapor lock.




FRONT BRAKE PAD INSPECTION

1. Remove:
 - Rubber plug
2. Inspect:
 - Wear limit (a)
Out of specification → Replace pads.


	Wear limit: 0.8 mm (0.03 in)
---	---

Refer to "BRAKE PAD REPLACEMENT" section in CHAPTER 6.



REAR BRAKE SHOE INSPECTION

1. Activate the brake pedal.
2. Inspect:
 - Wear indicator ①
Indicator at wear limit line ② → Replace brake shoes.
Refer to "REAR WHEEL" section in CHAPTER 6.



BRAKE HOSE INSPECTION

1. Inspect:
 - Brake hose ①
Cracks/Wear/Damage → Replace.

DRIVE CHAIN SLACK ADJUSTMENT


NOTE: _____

Before checking and/or adjusting, rotate the rear wheel several revolutions and check slack at several points to find the tightest point. Check and adjust the chain slack with the rear wheel in this "tightest" position.


1. Place the machine on a level surface, and hold it in an upright position.

NOTE: _____

Both wheels should be on the ground without a rider on the machine.



2. Check:
 - Drive chain slack ②
Out of specification → Adjust.

	Drive chain slack: 40 mm (1.6 in)
---	--

NOTE: _____



Slack check should be made with the tensioner in the relaxed position (not touching the chain).

DRIVE CHAIN SLACK ADJUSTMENT

INSP
ADJ



3. Adjust:
- Drive chain slack



Adjustment steps:

CAUTION:

Too little chain slack will overload the engine and over vital parts; keep the slack within the specified limits.

- Remove the cotter pin ①.
- Loosen the axle nut ②.
- Turn both chain pullers (left and right) ③ clockwise or counterclockwise until the specified slack is obtained.

NOTE:

Turn each chain puller exactly the same amount to maintain correct axle alignment. (There are marks on each side of swingarm and on each chain puller; use them to check for proper alignment).

- Tighten the axle nut to specification, while pushing up or down on the chain, making it tight.



Axle nut:
85 Nm (8.5 m·kg, 61 ft·lb)

- Install the cotter pin.

CAUTION:

Do not loosen the axle nut after torque tightening. If the axle nut groove is not aligned with the cotter pin hole, align the groove with the hole by tightening up on the axle nut.

⚠ WARNING

Always use a new cotter pin.

DRIVE CHAIN LUBRICATION

The chain consists of many parts which work with each other. If the chain is not maintained properly, it will wear out rapidly. This service is especially important when riding in dust conditions.

1. Use Yamaha chain and cable Lube or other brand of spray type chain lubricant. First, remove all dirt and mud from the chain with a brush or cloth, then spray the lubricant between both rows of side plates and on all center rollers.
2. To clean the chain, remove the chain from the machine, dip it in solvent, and clean out as much dirt as possible. Take the chain out of the solvent and dry it. Immediately lubricate the chain to prevent rust.




Recommended lubricant:
Yamaha Chain and Cable Lube or
SAE 10W30 Motor Oil

STEERING HEAD ADJUSTMENT

⚠ WARNING


Securely support the machine so there is no danger of it falling over.

1. Elevate the front wheel by placing a suitable stand under the engine.
2. Check:
 - Steering assembly bearing
Grasp the bottom of the forks and gently rock the fork assembly back and forth.
Looseness → Adjust steering head.



STEERING HEAD ADJUSTMENT

INSP ADJ	



3. Adjust:
- Steering head

Adjustment steps:

- Remove the side covers, seat, and fuel tank.
- Loosen the pinch bolts (Handle crown) ① and flange bolt (Steering stem) ②.
- Tighten the ring nut using the Ring Nut Wrench ③.



Ring nut wrench:
P/N. YU-33975

NOTE: _____
Set the torque wrench to the ring nut wrench so that they form a right angle.



Ring nut (initial tightening):
38 Nm (3.8 m·kg, 27 ft·lb)

- Loosen the ring nut one turn.
- Retighten the ring nut using the Ring Nut Wrench.

⚠ WARNING _____

Avoid over-tightening.



Ring nut (final tightening):
6 Nm (0.6 m·kg, 4.3 ft·lb)

NOTE: _____
Recheck the steering head by turning the steering from lock to lock, after adjusting steering head.
If steering is binding, loosen the ring nut slightly.
If steering is loose, repeat the adjustment steps.

- Tighten the flange bolt (Steering stem) ② and pinch bolts (Handle crown) ①.



Flange bolt (Steering stem):
54 Nm (5.4 m·kg, 39 ft·lb)


Pinch bolt (Handle crown):
23 Nm (2.3 m·kg, 17 ft·lb)

- Install the fuel tank, seat and side covers.

FRONT FORK INSPECTION

⚠ WARNING

Securely support the machine so there is no danger of it falling over.




1. Place the machine on a level place.
2. Loosen the clamps and pull up the Fork cover boots.
3. Check:
 - Inner tube ①
Scratch/Damage → Replace.
 - Oil seal ②
Excessive oil leakage → Replace.
 - Boot
Torn → Replace.
4. Hold the machine in the upright position and apply the front brake.
5. Check:
 - Operation
Pump the front fork up and down several times.
Unsmooth operation → Repair.
Refer to "FRONT FORK" section in CHAPTER 5.

REAR SHOCK ABSORBER ADJUSTMENT

⚠ WARNING

This shock absorber contains highly pressurized nitrogen gas. Read and understand the following information before handling shock absorber. The manufacture cannot be held responsible for property damage or personal injury that may result from improper handling.

- Do not tamper with or attempt to open the cylinder assembly.
- Do not subject shock absorber to an open flame or other high heat source. This may cause the unit to explode due to excessive gas pressure.
- Do not deform or damage the cylinder in any way. Cylinder damage will result in poor damping performance.



1. Adjust:
- Spring preload

Adjustment steps:

- Elevate the rear wheels by placing the suitable stand.
- Remove both side covers, seat and fuel tank.


Turn adjuster to "Hard" ①	Increase the spring preload.
---------------------------	------------------------------

Turn adjuster to "Soft" ②	Decrease the spring preload.
---------------------------	------------------------------

	Soft		STD	Hard	
Adjusting position	1	2	3	4	5

- Install the fuel tank, seat and both side covers.

③ Spring preload adjuster




TIRE INSPECTION

1. Measure:
- Air pressure
 - Out of specification → Adjust.

⚠ WARNING

Tire inflation pressure should be checked and adjusted when the temperature of the tire equals the ambient air temperature.

Cold tire pressure	Front	Rear
Off road riding	100 kPa (1.0 kgf/cm ² , 15 psi)	100 kPa (1.0 kgf/cm ² , 15 psi)



2. Inspect:
- Tire surfaces
 - Wear/Damage → Replace.

	Minimum tire tread depth: (Front and Rear) 4.5 mm (11.4 in)
--	--

- ① Tread depth
- ② Side wall

⚠ WARNING

- It is dangerous to ride with a worn-out tire. When the tire tread reaches minimum tire tread depth, replace the tire immediately.
- Patching a punctured tube is not recommended.

If it is absolutely necessary to do so, use great care and replace the tube as soon as possible with a good quality replacement.

WHEEL INSPECTION

1. Inspect:
 - Wheels
Damage/Bends → Replace.


NOTE:

Always balance the wheel when a tire or wheel has been changed or replaced.

⚠ WARNING


Never attempt even small repairs to the wheel.

2. Tighten:
 - Valve stem locknut

	1.5 Nm (0.15 m·kg, 1.1 ft·lb)
---	-------------------------------

⚠ WARNING

Ride conservatively after installing a tire to allow it to seat itself properly on the rim.



SPOKE INSPECTION AND TIGHTENING

1. Inspect:
 - Spokes
Bend/Damage → Replace.
Loose spoke → Retighten evenly.
2. Tighten:
 - Spokes

NOTE:

Be sure to retighten these spokes before and after Break-in.



Nipple:
6 Nm (0.6 m·kg, 4.3 ft·lb)

CABLE INSPECTION AND LUBRICATION

⚠ WARNING

Damaged cable sheath may cause corrosion and interfere with the cable movement. Replace damaged cables as soon as possible.

Cable


1. Inspect:
 - Cable sheath
 - Cable end
Damage → Replace.
2. Check:
 - Cable operation
Unsmooth operation → Lubricate.



Recommended lubricant:
Yamaha Chain and Cable Lube
or SAE 10W30 Motor Oil

NOTE:

Hold cable end upward and apply several drops of lubricant into cable.



3. Apply the grease to the throttle cable end and cable guide groove on inside of throttle-housing ①.



Lithium soap base grease



Brake and clutch levers

1. Lubricate the pivoting parts of each lever.




Recommended lubricant:
Yamaha Chain and Cable Lube
or SAE-10W30 Motor Oil

Brake pedal

1. Lubricate the pivoting parts.



Recommended Lubricant:
Yamaha Chain and Cable Lube
or SAE-10W30 Motor Oil



Sidestand

1. Lubricate the pivoting parts.



Recommended lubricant:
Yamaha Chain and Cable Lube
or SAE-10W30 Motor Oil



ENGINE OVERHAUL

ENGINE REMOVAL

NOTE:

It is not necessary to remove the engine in order to remove the following components:

- Cylinder head
- Cylinder
- Piston and piston ring
- Clutch
- Primary drive gear
- Kick axle
- Shift shaft
- Magneto rotor
- Stator
- Autolube pump

SIDE COVERS

1. Remove
 - Side cover (Right)
 - Side cover (Left)
 - Seat

4

FUEL TANK

1. Turn the fuel cock to "OFF" position and disconnect the fuel hose ①.

2. Remove:
 - Fuel tank




TRANSMISSION OIL

1. Drain:

- Transmission oil

Refer to the "TRANSMISSION OIL REPLACEMENT" section in the CHAPTER 3.



EXHAUST PIPE

1. Loosen:

- Screw (Muffler joint) ①

2. Remove:


- Gasket (Exhaust pipe)
- Bracket screw
- Exhaust pipe ②

CARBURETOR

1. Remove:

- Fuel tank
- Carburetor


Refer to the "CARBURETOR - REMOVAL" section in the CHAPTER 6.



AUTOLUBE PUMP CABLE AND HOSE

1. Remove:

- Autolube pump cover ①




2. Disconnect:

- Oil hose ①
- Gasket (Autolube pump cover) ②

NOTE:

Plug the oil hose so that oil will not run out of the oil tank.



3. Remove:

- Stopper clip (pump cable) ①
- Clip (pump cable outer) ②

4. Disconnect:

- Autolube pump cable ③


NOTE:

Turn the pump pulley counterclockwise by finger to make pump cable loose enough for its end to be removed from the pulley.

CLUTCH CABLE

1. Loosen:

- Adjuster (Clutch cable) ①




2. Disconnect:

- Clutch cable ②
- (from clutch push lever ③)

**LEADS AND HOSE**

1. Disconnect:

- Spark plug lead ①




2. Disconnect:

- CDI magneto leads ①

3. Remove:


- YEIS chamber hose ②





DRIVE CHAIN


1. Remove:
 - Change pedal ①
 - Crankcase cover (Left) ②
 - Gasket (Crankcase cover)




2. Straighten:
 - Lock washer tab ①
3. Loosen:
 - Nut (Drive sprocket) ②

NOTE:

When loosening the nut (drive sprocket), apply the rear brake pedal and put the transmission in 6th gear.





4. Remove:
 - Drive chain ①
 - Nut (Drive sprocket) ②
 - Lock washer ③
 - Drive sprocket ④
 - Spacer collar ⑤



ENGINE REMOVAL

1. Remove:
 - Bolt (Engine mount - rear upper) ①
 - Bolt (Engine mount - front) ②
2. Remove:
 - Bolt (Engine mount - Rear lower) ③





3. Remove:
 - Engine assembly
(from left side)


ENGINE DISASSEMBLY CYLINDER HEAD, CYLINDER AND PISTON

NOTE: _____
 With the engine mounted, the cylinder head, cylinder and piston can be maintained by removing the following parts.

- Side covers (Right and left)
- Seat
- Fuel tank
- Exhaust pipe
- YEIS hose
- Carburetor




1. Remove:
 - Spark plug ①



2. Remove:
 - Cylinder head ①
 - Gasket (Cylinder head)

NOTE: _____
 • Loosen the nuts starting with upper left, lower right, then upper right and lower left.
 • Loosen each nut 1/4 turn, and remove them after all nuts are loosened.




3. Remove:
- Clutch cable guide ①
 - Cylinder base nuts ②
 - Cylinder ③
 - Gasket (cylinder)
 - Dowel pins

NOTE: _____
Loosen each nut 1/4 turn, and remove them after all nuts are loosened.



4. Remove:
- Piston pin clip ①

NOTE: _____
Before removing piston pin circlip, cover crankcase with a clean rag to prevent circlip from falling into crankcase cavity.



5. Remove:
- Piston pin ①
 - Piston ②
 - Small end bearing ③

NOTE: _____
Before removing the piston pin, deburr the clip groove and pin hole area. If the piston pin groove is deburred and piston pin is still difficult to remove, use Piston Pin Puller.


	Piston pin puller: P/N. YU-01304
--	--

CAUTION: _____
Do not use a hammer to drive the piston pin out.


CLUTCH AND PRIMARY DRIVE GEAR

NOTE: _____
With the engine mounted, the clutch, and primary drive gear can be maintained by removing the following parts.


- Brake pedal
- Kick crank
- Crankcase cover (right)




1. Remove:
- Kick crank ①



2. Remove:
- Crankcase cover (Right)
 - Dowel pins
 - Gasket (Crankcase cover)




3. Remove:
- Bolts ①
 - Clutch springs ②
 - Pressure plate ③
 - Friction plates ④
 - Clutch plates ⑤
 - Clutch dumper ⑥
 - Nut (Clutch boss) ⑦
 - Lock washer ⑧
 - Clutch boss ⑨
 - Washer ⑩
 - Clutch housing ⑪
 - Collar ⑫
 - Thrust plate ⑬
 - Ball ⑭
 - Push rod #1 ⑮
 - Push rod #2 ⑯
 - Push plate ⑰



- NOTE:**
- Before loosening the nut (Clutch boss) ⑦ straighten the lock washer tab.
 - Hold the clutch boss to loosen the nut (Clutch boss) by the Universal Clutch Holder ⑱.




**Universal clutch holder:
YM-91042**




4. Loosen:
- Nut (Primary drive gear) ①


NOTE: _____
 Hold the magneto rotor to loosen the nut (Primary drive gear) ① by the Universal Rotor Holder ②.




	Universal rotor holder: YU-01235
--	--



5. Remove:
- Nut (Primary drive gear) ①
 - Plain washer ②
 - Primary drive gear ③
 - Straight key ④



6. Remove:
- Spacer collar ①
 - Oil seal retainer ②




CLUTCH PUSH LEVER

1. Unhook:
 - Return spring (Push lever) ①
2. Remove:
 - Push level (Clutch) ②
 - Return spring ①
 - Washer ③
 - Holding screw (Push lever) ④
 - Washer ⑤


**KICK AXLE AND KICK IDLE GEAR****NOTE:** _____

With the engine mounted, the kick axle and kick idle gear can be maintained by removing the following parts.

- Brake pedal
- Autolube pump cable and hoses
- Kick crank
- Crankcase cover (Right)
- Clutch

**1. Remove:**

- Circlip ①
- Washer ②
- Kick idle gear ③
- Washer ④
- Circlip ⑤

**2. Unhook:**

- Return spring (kick axle) ①


3. Remove:

- Kick axle ② (pull straight out)



SHIFT SHAFT AND STOPPER LEVER**NOTE:** _____

With the engine mounted, the shift shaft can be maintained by removing the following parts.

- Brake pedal
- Autolube pump cable and hoses
- Kick crank
- Crankcase cover (right)
- Clutch



1. Remove:
- Circlip ①
 - Shift lever ②
 - Shift shaft ③
 - Stopper lever ④



ROTOR

NOTE: _____

With the engine mounted, the rotor can be maintained by removing the following parts.


- Crankcase cover (Left)

1. Remove:


- Nut (rotor) ①
- Plain washer

NOTE: _____

Hold the rotor to loosen the nut (Rotor) by the Universal Rotor Holder ②.




Universal rotor holder:
P/N. YU-01235




2. Remove:
- Rotor ①
 - Woodruff key

NOTE: _____
 When removing the rotor, use the Rotor Puller ② .


	<p>Rotor puller: P/N YM-01189</p>
--	---



3. Disconnect:
- Neutral switch lead ①




4. Remove:
- Stator ①



CRANKCASE (LEFT)

1. Remove:
- Crankcase (Left)

NOTE: _____
 • Loosen each screw 1/4 turn, and remove them after all are loosened.

**Removal steps:**

- Attach the Crankcase Separating Tool ① .



Crankcase separating tool:
P/N. YU-01135


NOTE:

Fully tighten the tool holding bolts, but make sure the tool body is parallel with the case. If necessary, one screw may be backed out slightly to level tool body.

- As pressure is applied, alternately tap on the front engine mounting boss, and transmission shafts.
- Then, remove the crankcase (right).


CAUTION:

- Use soft hammer to tap on the case half. Tap only on reinforced portions of case.
- Do not tap on gasket mating surface.
- Work slowly and carefully.
- Make sure the case halves separate evenly.
- If one end "hangs up", take pressure off the push screw, realign, and start over. If the cases do not separate, check for a remaining case screw or fitting.
- Do not force.




2. Remove:

- Dowel pins ①
- Damper collar ②



3. Remove:

- Bearing retainer ①


**SHIFTER AND TRANSMISSION**

1. Remove:

- Guide bars ①
- Shift cam ②
- Shift forks ③


NOTE: _____

Note the position of each part. Pay particular attention to the location and direction of shift forks.



2. Remove:

- Transmission assembly
- If necessary, tap lightly on the transmission drive axle with a soft hammer.

**CRANKSHAFT**

1. Remove:

- Crankshaft ①

NOTE: _____

If necessary, remove the crankshaft with the Crankcase Separating Tool ②.




Crankcase separating tool:
P/N. YU-01135

- Fully tighten the tool holding bolts, but make sure the tool body is parallel with the case. If necessary, one screw may be backed out slightly to level tool body.


AUTOLUBE PUMP ASSEMBLY**NOTE:** _____

With the engine mounted, the autolube pump assembly can be maintained by removing the following parts.

- Pump case cover
- Autolube pump cable and hoses
- Brake pedal
- Kick crank
- Crankcase cover (Right)



1. Remove:
 - Circlip ①
 - Lock washer ②
 - Drive gear ③
 - Pin ④
 - Autolube pump ⑤
 - Gasket ⑥
 - Washer ⑦
 - Drive shaft (Autolube pump) ⑧



INSPECTION AND REPAIR CYLINDER HEAD


1. Eliminate:
 - Carbon deposits
Use a rounded scraper ①

CAUTION: _____

Take care to avoid damaging the spark plug threads. Do not use a sharp instrument. Avoid scratching the aluminum.

2. Measure:
 - Cylinder head warpage
Out of specification → Resurface.

	<p>Warpage limit: 0.03 mm (0.0012 in)</p>
--	--





Warpage measurement and resurfacement steps:

- Attach a straight edge 1 on the cylinder head and measure the warpage using a thickness gauge 2 .
- If the warpage is out of specification, resurface the cylinder head.
- Place a 400 ~ 600 grit wet sandpaper on the surface plate, and resurface the head using a figure-eight sanding pattern.

NOTE:

Rotate the head several times to avoid removing too much material from one side.



CYLINDER AND PISTON

1. Eliminate:


- Carbon deposits
Use a rounded scraper

CAUTION:

Do not use a sharp instrument and avoid damaging or scratching.

2. Inspect:

- Cylinder wall
Wear/Scratches → Rebore or replace.



3. Eliminate:

- Carbon deposits
(from piston crown and ring grooves)

4. Inspect:


- Piston crown
Burrs/Nicks/Damage → Replace.



5. Eliminate:
- Score marks and carbon deposits (from piston wall)
- Use 600 ~ 800 grit wet sandpaper

NOTE: _____
 Sand in a crisscross pattern. Do not sand excessively.

6. Inspect:
- Piston wall
- Wear/Scratches/Damage → Replace.




7. Measure:
- Piston-to-cylinder clearance

Measurement steps:

First step:


- Measure the cylinder bore "C" with a Cylinder Bore Gauge.

NOTE: _____
 Measure the cylinder bore "C" in parallel to and at right angles to the crankshaft. Then, find the average of the measurements.

	Standard	Wear limit
Cylinder bore "C"	64.50 ~ 64.53 mm (2.539 ~ 2.540 in)	64.6 mm (2.543 in)
Taper "T"	—	0.05 mm (0.0019 in)
Out of round "R"	—	0.01 mm (0.0004 in)

C = Maximum D
T = (Maximum D₁ or D₂) - (Maximum D₅ or D₆)
R = (Maximum D₁, D₃ or D₅) - (Maximum D₂, D₄ or D₆)

- If out of specification, rebore or replace cylinder, and replace piston and piston rings as a set



2nd step:

- Measure the piston skirt diameter "P" with a micrometer.

Ⓐ 10.0 mm (0.40 in) from the piston bottom edge



Piston size P

Standard	64.46 ~ 64.50 mm (2.538 ~ 2.539 in)
-----------------	--

Oversize 1	64.75 mm (2.55 in)
-------------------	---------------------------

Oversize 2	65.00 mm (2.56 in)
-------------------	---------------------------

- If out of specification, replace piston and piston rings as a set.

3rd step:

- Calculate the piston-to-cylinder clearance with following formula:

Piston-to-cylinder clearance =
Cylinder bore "C" -
Piston skirt diameter "P"

- If out of specification, rebore or replace cylinder, and replace piston and piston rings as a set.




Piston-to-cylinder clearance:

0.035 ~ 0.040 mm


(0.0014 ~ 0.0016 in)


Limit: 0.1 mm (0.004 in)




PISTON RINGS

- Measure:
 - Side clearance
 - Out of specification → Replace piston and/or rings.
 - Use a Feeler gauge ①.


	Side clearance	Top	0.030 ~ 0.050 mm (0.0012 ~ 0.0020 in)
		2nd	0.030 ~ 0.050 mm (0.0012 ~ 0.0020 in)



- Install:
 - Piston ring (into cylinder)
 - Push the ring with the piston crown.
- Measure:
 - End gap
 - Out of specification → Replace rings as a set.
 - Use a Feeler Gauge ①.





	End gap	Top	0.30 ~ 0.50 mm (0.012 ~ 0.020 in)
		2nd	0.30 ~ 0.50 mm (0.012 ~ 0.020 in)

Oversize piston ring	
Oversize 1	25
Oversize 2	50



PISTON PIN BEARING

- Lubricate:
 - Small end bearing ①
 - Piston pin ② (lightly)
- install:
 - Small end bearing ①
 - Piston pin ② (into small end ③ of connecting rod)



3. Check:

- Free play
There should be no noticeable for the play. Free play exists → Inspect the connecting rod, pin, and bearing for wear/Replace the pin and/or connecting rod as required.

4. Install:

- Piston pin
(into piston pin hole)

5. Check:

- Free play (when the piston pin is in place in the piston)
There should be no noticeable for the play. Free play exists → Replace piston pin and/or piston.

6. Inspect:

- Piston pin and bearing
Signs of heat discoloration → Replace.

CLUTCH

1. Inspect:

- Friction plate
Damage/Wear → Replace friction plates as a set.

2. Measure:

- Friction plate thickness
Out of specification → Replace friction plate as a set.

Wear limit: 2.7 mm (0.106 in)


3. Inspect:

- Clutch plate
Damage → Replace clutch plates as a set.

4. Measure:


- Clutch plate warp
Out of specification → Replace clutch plate as a set.
Use a surface plate and Feeler Gauge ①

Warp limit: 0.05 mm (0.002 in)



5. Inspect:

- Clutch damper ①
Wear/Damage → Replace.




6. Measure:

- Clutch spring free length
Out of specification → Replace spring as a set.



**Clutch spring minimum length:
32.0 mm (1.260 in)**




7. Inspect:

- Dogs on the clutch housing
Cracks/Wear/Damage → Deburr or replace.
- Clutch housing bearing
Scoring/Wear/Damage → Replace clutch housing.

NOTE: _____

Scoring on the clutch housing dogs will cause erratic operation.




8. Inspect:

- Clutch boss splines
Scoring/Wear/Damage → Replace clutch housing.


NOTE: _____

Scoring on the clutch boss splines will cause erratic operation.



9. Check:

- Circumferential play
Free play exists → Replace clutch housing assembly.




10. Measure:

- Push rod # 2 runout
- Out of specification → Replace.
- Use a V-Block and Dial Gauge.




Runout limit:
0.15 mm (0.006 in)




11. Inspect:

- Push rod # 1 runout
- Roll the guide bar on a flat surface.
- Bends → Replace.



12. Inspect:


- Push lever ①
- Return spring ②
- Wear/Damage → Replace.



PRIMARY DRIVE

1. Inspect:


- Primary drive gear teeth ①
- Primary driven gear teeth ②
- Wear/Damage → Replace both gears.
- Excessive noises during operation → Replace both gears.



TRANSMISSION AND SHIFTER


1. Inspect:

- Shift fork cam follower ①
- Shift fork pawl ②
- Scoring/Bends/Wear → Replace.



2. Inspect:

- Shift cam groove ①
- Shift cam segment ②
Wear/Damage → Replace shift cam assembly.
- Shift cam bearing
Bearing turns roughly → Replace shift cam assembly.




3. Inspect:

- Guide bar
Roll the guide bar on a surface.
Bends → Replace.


⚠ WARNING

Do not attempt to straighten a bent guide bar.



4. Check:


- Shift fork movement
Unsmooth operation → Replace shift fork and/or guide bar.



5. Measure:


- Axle runout (Main and Drive)
Use centering device and dial gauge.
Out of specification → Replace bent axle.

	<p>Runout limit: 0.08 mm (0.003 in)</p>
--	---



6. Inspect:

- Gear teeth
Blue discoloration/Pitting/Wear → Replace.
- Mated dogs
Rounded edges/Cracks/Missing portions → Replace




7. Check:

- Proper gear engagement (each gear to its counter part)
Incorrect → Reassemble.
- Gear movement
Roughness → Replace.


8. Inspect:

- Circlips
Damage/Looseness/Bends → Replace.

**KICK STARTER**


1. Inspect:

- Kick axle ①
- Kick gear teeth ②
- Kick idle gear teeth ③
Damage/Wear → Replace both gears.



2. Inspect:

- Return spring (Kick axle)
Wear/Damage → Replace.




3. Measure:

- Kick clip tension
Out of specification → Replace.
Use a Spring Gauge ①.

Kick clip tension:
0.8 ~ 1.2 kg (1.76 ~ 2.65 lb)


CAUTION:

Do not try to bend the clip.



SHIFT SHAFT AND STOPPER LEVER


1. Inspect:
 - Shift shaft ①
 - Shift lever ②
Bend/Wear/Damage → Replace.
2. Inspect:
 - Stopper lever ③
Roller turns roughly → Replace.
Bend/Damage → Replace.
3. Inspect:
 - Return spring (shift shaft) ④
 - Return spring (shift lever) ⑤
 - Return spring (stopper lever) ⑥
Wear/Damage → Replace.



CRANKSHAFT


1. Measure:
 - Runout **A**
Use a centering device and Dial Gauge.
Out of specification → Replace or repair.

Runout limit:
0.03 mm (0.0012 in)



2. Measure:
 - Small end free play **B**
Use a Dial Gauge.
Out of specification → Replace the defective parts.


Small end free play:
1.0 ~ 1.5 mm (0.039 ~ 0.059 in)



3. Measure:
 - Big end side clearance **C**
Use a Feeler Gauge ①.
Out of specification → Replace the defective parts.



Big end side clearance:
 0.15 ~ 0.70 mm (0.006 ~ 0.028 in)
 <Limit>:
 <1.0 mm (0.040 in)>




4. Measure:

- Crank width ①
 Out of specification → Replace or repair.



Crank width:
 55.85 ~ 55.95 mm
 (2.199 ~ 2.203 in)



5. Inspect:

- Crankshaft bearings ①
 Pitting/Damage → Replace.

NOTE:

Lubricate the bearings immediately after examining them to prevent rust.

AUTOLUBE PUMP

Wear or an internal malfunction may cause pump output to vary from the factory setting. This situation is, however, extremely rare. If improper output is suspected, inspect the following:

1. Inspect:

- Delivery line
 Obstructions → Blow out.
- Pump body seal/Crankcase cover seal
 Wear/Damage → Replace.

2. Inspect:

- Allowing air
 Air exists → Air bleed.
 Refer to the "AUTOLUBE PUMP AIR BLEEDING" section in the CHAPTER 3.

3. Check:


- Pump output
 Out of specification → Adjust.

**Minimum output/200 Stroke:**


0.48 ~ 0.59 cm³ (0.017 ~ 0.021 Imp oz,
0.016 ~ 0.020 US oz)

Maximum output/200 Stroke:


4.40 ~ 4.87 cm³ (0.155 ~ 0.171 Imp oz,
0.149 ~ 0.165 US oz)

**4. Inspect:**


- Drive gear (autolube pump) ①
 - Drive shaft (autolube pump) ②
 - Pivot collar (drive shaft) ③
- Wear/Damage → Replace.

**CRANKCASE**

1. Thoroughly wash the case halves in mild solvent.
2. Clean all the gasket mating surfaces and crankcase mating surfaces thoroughly.
3. Inspect:
 - Crankcase
Cracks/Damage → Replace.
 - Oil delivery passages
Clog → Blow out with compressed air.

**BEARINGS AND OIL SEALS**


1. Inspect:
 - Bearings
Pitting/Damage → Replace.
2. Inspect:
 - Oil seals
Damage/Wear → Replace






AUTOLUBE PUMP

- | | | |
|-----------------|----------------------|-------------------|
| ① Autolube pump | ⑥ Oil seal | ⑪ Adjusting plate |
| ② Gasket | ⑦ Circlip | ⑫ Shim |
| ③ Washer | ⑧ Autolube pump gear | ⑬ Bleed screw |
| ④ Drive shaft | ⑨ Lock washer | |
| ⑤ Pin | ⑩ Clip | |





**ENGINE ASSEMBLY AND
ADJUSTMENT
AUTOLUBE PUMP**

1. Lubricate:
- Oil seal lips ①



**Lightweight lithium-soap
base grease**

2. Install:
- Drive shaft (Autolube pump) ②
 - Circlip ③
 - Pin ④
 - Drive gear (autolube pump) ⑤
 - Lock washer ⑥
 - Gasket ⑦
 - Washer ⑧
 - Autolube pump ⑨



**Screw (Autolube pump):
5 Nm (0.5 m·kg, 3.6 ft·lb)**

CAUTION: _____

- Always use a new circlip.
- Always use a new gasket.





CRANKSHAFT/PISTON/BALANCER

- | | | |
|-------------------|---------------------|----------------|
| ① Oil seal | ⑧ Small end bearing | ⑮ Crank (left) |
| ② Collar | ⑨ Straight key | ⑯ Woodruff key |
| ③ Bearing | ⑩ Crank (right) | ⑰ Bearing |
| ④ Piston ring set | ⑪ Thrust bearing | ⑱ Oil seal |
| ⑤ Piston | ⑫ Connecting rod | ⑲ Circlip |
| ⑥ piston pin | ⑬ Crank pin | |
| ⑦ piston pin clip | ⑭ Big end bearing | |

A	PISTON TO CYLINDER CLEARANCE: 0.035 ~ 0.040 mm (0.0014 ~ 0.0016 in)
	END GAP (INSTALLED):
	Top ring
B	0.30 ~ 0.50 mm (0.012 ~ 0.020 in)
	2nd ring
	0.30 ~ 0.50 mm (0.012 ~ 0.020 in)


C	CRANKSHAFT:
A:	55.85 ~ 55.95 mm (2.199 ~ 2.203 in)
B:	0.03 mm (0.0012 in)
C:	0.15 ~ 0.70 mm (0.006 ~ 0.028 in) <Limit> 1.0 mm (0.04 in)
D:	1.0 ~ 1.5 mm (0.039 ~ 0.059 in)





TRANSMISSION


- | | | |
|-----------------------|------------------|------------------|
| ① Main axle | ⑨ Drive axle | ⑬ Shim |
| ② 2nd pinion gear | ⑩ 1st wheel gear | ⑭ Oil seal |
| ③ 3rd/4th pinion gear | ⑪ 2nd wheel gear | ⑮ Drive sprocket |
| ④ 5th pinion gear | ⑫ 3rd wheel gear | ⑯ Lock washer |
| ⑤ 6th pinion gear | ⑬ 4th wheel gear | ⑰ Circlip |
| ⑥ Plain washer | ⑭ 5th wheel gear | ⑱ Collar |
| ⑦ Circlip | ⑮ 6th wheel gear | ⑲ Bearing |
| ⑧ Cylindrical bearing | ⑯ Special washer | |





SHIFTER

- | | | |
|-----------------|-----------------------|-----------------|
| ① Shift cam | ⑥ Circlip | ⑪ Securing bolt |
| ② Neutral point | ⑦ Cylindrical bearing | ⑫ Shift fork #1 |
| ③ Segment | ⑧ Dowel pin | ⑬ Shift fork #2 |
| ④ Dowel pin | ⑨ Stopper lever | ⑭ Guide bar #2 |
| ⑤ Side plate | ⑩ Return spring | ⑮ Guide bar #1 |






CRANKSHAFT

CAUTION:

To protect the crankshaft against scratches or to facilitate the operation of the installation, apply the grease to the oil seal lips, and apply the engine oil to each bearing.



1. Install:
 - Crankshaft (into left case half)


NOTE:

- Attach the Crankshaft Installing Tool to install the crankshaft.




Crankshaft installing tool:
P/N. YU-90050
P/N. YU-90063

- Hold the connecting rod at top dead center with one hand while turning the nut of the Installing Tool with the other. Operate the Installing Tool until the crankshaft bottoms against the bearing.



TRANSMISSION AND SHIFTER


1. Install:
 - Transmission assembly (into left case half)



2. Install:
 - Shift forks ①
 - Shift cam ②
 - Guide bars ③

NOTE:

Each shift fork is identified by a number cast on its side. All the numbers should face the left side.



3. Lubricate:


- Transmission component parts



**Yamalube "4", SAE10W30 type
SE motor oil or "GL" Gear Oil**

4. Check:

- Shifter operation
- Unsmooth operation → Repair.




CRANKCASE (RIGHT)

1. Install:

- Bearing retainer ①



**Screw (bearing retainer):
10 Nm (1.0 m·kg, 7.2 ft·lb)
USE LOCTITE ®**



2. Apply:


- Yamaha Bond No. 4 ①
(to mating surface of both crankcase halves)



**Yamaha Bond No. 4
ACC-11001-30-00**

3. Install:

- Damper collar ②
- Dowel pins ③




4. Install:

- Crankcase (Right)

Installation step:

- Apply the lithium soap base grease to the oil seal lips.
- Fit the right crankcase onto the left case.
- Tap lightly on the case with a soft hammer.



- Tighten the bolts (crankcase).

NOTE: _____

Before installing and torquing the bolts (Crankcase), be sure to check whether the transmission is functioning properly by manually rotating the shift cam either way.


NOTE: _____

Tighten the bolts (crankcase) in stage, using a crisscross pattern.



Bolts (crankcase):

8 Nm (0.8 m · kg, 5.8 ft · lb)



5. Apply:

- 2-stroke oil
(to crank pin, bearing and oil delivery hole)


6. Check:


- Crankshaft and transmission operation
Unsmooth operation → Repair.



MAGNETO ROTOR


- ① Stator assembly
- ② Rotor
- ③ Plate washer
- ④ Spring washer







MAGNETO ROTOR

1. Install:
 - Stator ①


	Screw (stator): 8 Nm (0.8 m·kg, 5.8 ft·lb) Use LOCTITE®
---	--



2. Connect:
 - Neutral switch lead ①




3. Install:
 - Woodruff key ①
 - Rotor ②
 - Plain washer ③
 - Spring washer ④
 - Nut (rotor) ⑤



- NOTE:** _____
- Clean the tapered portions of the crankshaft and rotor.
 - When installing the rotor, make sure the key is properly seated in the key way of the crankshaft.
 - Hold the rotor by the Rotor Holder ① to tighten the nut ②.


	Universal rotor holder: P/N. YU-01235
---	---

	Nut (rotor) 70 Nm (7.0 m·kg, 50 ft·lb)
---	--



SHIFT SHAFT

- | | | |
|---------------|----------------|----------------------|
| ① Shift lever | ④ Shift shaft | ⑦ Shift lever roller |
| ② Spring | ⑤ Oil seal | ⑧ Plate washer |
| ③ Circlip | ⑥ Change pedal | ⑨ Shaft |



11 Nm (1.1 m·kg, 7.9 ft·lb)




SEGMENT, STOPPER LEVER AND SHIFT SHAFT


1. Install:
- Segment

NOTE: _____

Align the index mask on the segment ① with the index mark on the shift cam ②.



2. Install:
- Return spring ①
 - Stopper lever ②

	Bolt (stopper lever): 10 Nm (1.0 m·kg, 7.2 ft·lb)
---	---


NOTE: _____

Mesh the stopper lever with the shift cam.

3. Install:
- Shift shaft ③
 - Shift lever ④
 - Circlip ⑤

NOTE: _____

Apply the grease to the oil seal lip ⑥.



4. Check:
- Shift pawl ① position
- Check the clearance ① and ②, if they are not equal → Adjust with adjusting screw ③ so that clearances are equal.


2 Shift cam

KICK AXLE AND KICK IDLE GEAR

1. Install:
- Kick axle assembly ①

NOTE: _____

- Make sure tha the kick stopper ② is stopped at the projection ③ of the crankcase.
- Make sure the kick clip ④ is engaged with the crankcase hole ⑤.







KICK AXLE

- ① Kick crank
- ② Oil seal
- ③ Spring guide
- ④ Kick spring


- ⑤ Washer
- ⑥ Kick gear
- ⑦ Clip
- ⑧ Kick axle

- ⑨ Circlip
- ⑩ Washer
- ⑪ Kick idle gear





2. Set the kick spring ① to the spring hook ②.




3. Install:

- Circlip ①
- Washer ②
- Kick idle gear ③
- Washer ④
- Circlip ⑤

4. Check:

- Kick axle operation


Use the kick crank.
Unsmooth operation → Repair.



CLUTCH PUSH LEVER

1. Lubricate:

- Oil seal (Lip) ①
- Washer ②
- Push lever axle ③



2. Install:

- Washer ①
- Return spring ②
- Push lever ③


3. Set the return spring ② to the spring hook ⑤.


- Screw ④



CLUTCH AND PRIMARY DRIVE GEAR

- | | | |
|------------------|------------------|----------------------|
| ① Clutch spring | ⑦ Clutch damper | ⑬ Ball |
| ② Pressure plate | ⑧ Clutch boss | ⑭ Push rod #2 |
| ③ Push plate | ⑨ Plain washer | ⑮ Push lever axle |
| ④ Push rod #1 | ⑩ Clutch housing | ⑯ Return spring |
| ⑤ Clutch plate | ⑪ Collar | ⑰ Oil seal |
| ⑥ Friction plate | ⑫ Washer plain | ⑱ Primary drive gear |





PRIMARY DRIVE GEAR AND CLUTCH

1. Install:


- Oil seal retainer ①
- Spacer collar ②



Oil seal retainer:
10 Nm (1.0 m·kg 7.2 ft·lb)


NOTE: _____

Before installing the spacer collar ②, grease the oil seal lip ③.



2. Install:

- Straight key ①
- Primary drive gear ②
- Conical spring washer ③
- Nut (primary drive gear) ④



3. Tighten:

- Nut (Primary drive gear) ①




Nut (Primary drive gear):
60 Nm (6.0 m·kg, 43.4 ft·lb)

NOTE: _____

Hold the rotor to tighten the nut (primary drive gear) ① by the Universal Rotor Holder ②.



Universal rotor holder:
P/N. YU-01235



5. Lubricate:

- Push rod # 2 ①
- Ball ②



Lithium soap base grease

6. Install:




- Push rod # 2 ①
- Ball ②
- Thrust plate ③
- Collar ④
- Clutch housing ⑤
- Thrust washer ⑥
- Clutch boss ⑦
- Lock washer ⑧
- Nut (Clutch boss) ⑨

⚠ WARNING

Always use a new lock washer.

NOTE:

Install the lock washer ① in proper position



7. Tighten:

- Nut (Clutch boss) ①



Nut (Clutch boss):
50 Nm (5.0 m·kg, 36 ft·lb)


NOTE:

Hold the clutch boss to tighten the nut ① (clutch boss) by the Universal Clutch Holder ②.



Universal clutch holder:
P/N. YM-91042

8. Bend the lock washer tab along the nut flats.



9. Install:


- Friction plates ①
- Clutch plates ②
- Clutch damper ③

Installation steps:

- Install the friction plate onto the clutch boss.
- Install the clutch plate so as to locate the projection ④ at # 1.
- Install the friction plate with the larger inside diameter onto the clutch boss.
- Install the clutch damper onto the clutch plate.
- Next install the remaining clutch plates and friction plates alternately on the clutch boss.
- Be sure to install a clutch plate with projection offset approximately 60° from previous plate projection.
- Continue this procedure in a clockwise direction until all clutch plates are installed.


NOTE: _____

Before installing a friction and clutch plates apply sufficient coating of transmission oil to each plate.




10. Install:

- Push rod # 1 ①
- Pressure plate ②
- Clutch springs ③
- Bolts (Pressure plate) ④




11. Tighten:
- Bolts (Pressure plate)

	Bolt (Pressure plate): 6 Nm (0.6 m·kg, 4.3 ft·lb)
---	--

NOTE: _____
 Tighten the bolts (Pressure plate) in stage, using a crisscross pattern.


12. Adjust:
- Clutch mechanism free play
- Refer to the "CLUTCH MECHANISM ADJUSTMENT" section in the CHAPTER 3 .



13. Install:
- Gasket (Crankcase cover)
 - Dowel pins
 - Crankcase cover (Right) ①
 - Drain plug (Transmission oil) ②


NOTE: _____
 Tighten the screws (Crankcase cover) in stage, using a crisscross pattern.


⚠ WARNING _____
 Always use a new gasket.


	Screw (Crankcase cover): 10 Nm (1.0 m·kg, 7.2 ft·lb) Drain plug (Transmission oil): 20 Nm (2.0 m·kg, 14 ft·lb)
---	---

14. Install:
- Kick crank ①

CAUTION: _____
 Be sure to install the kick crank in such a way that it does not make contact with the crank case cover.



	Bolt (Kick crank): 23 Nm (2.3 m·kg, 17 ft·lb)
---	--



PISTON, CYLINDER AND CYLINDER HEAD

1. Install:


- Bearing ①
- Piston ②
- Piston pin ③
- Piston pin clips ④

NOTE:

- Apply 2-stroke engine oil to the piston pin, bearing, piston pins and piston skirt areas.
- The arrow on the piston must point to the front of the engine.
- Before installing the piston pin clip, cover the crankcase with a clean towel or rag so you will not accidentally drop the pin clip and material into the crankcase.


⚠ WARNING

Always use a new piston pin clip.



CAUTION:

Do not allow the clip open ends to meet the piston pin slot.



2. Check:

- Piston ring position

CAUTION:


- Make sure ring ends are properly fitted around ring locating pins in piston grooves.
- Be sure to check the manufacture's marks or numbers stamped on the rings are on the top side of the rings.


3. Install:

- Gasket (Cylinder) ①

⚠ WARNING


Always use a new gasket.





4. Install:
- Cylinder ①
 - Clutch cable guide

NOTE: _____
 Install the cylinder with one hand while compressing the piston rings with the other hand.



5. Tighten:
- Nuts (Cylinder)



Nut (Cylinder):
35 Nm (3.5 m·kg, 25 ft·lb)


NOTE: _____
 Tighten the nuts in stage, using a crisscross pattern.

- ① Clutch cable guide

6. Install:
- Gasket (Cylinder head)
 - Cylinder head

⚠ WARNING _____

Always use a new gasket.




7. Tighten:
- Nuts (Cylinder head)



Nut (Cylinder head):
25 Nm (2.5 m·kg, 18 ft·lb)

NOTE: _____
 Tighten the nuts in stage, using a crisscross pattern.



8. Install:


- Spark plug ①





Spark Plug:
25 Nm (2.5 m·kg, 18 ft·lb)

CYLINDER HEAD AND CYLINDER

- ① Spark plug
- ② Cylinder head
- ③ Cylinder head gasket
- ④ Cylinder
- ⑤ Cylinder gasket





REMounting ENGINE

Reverse the "ENGINE REMOVAL" procedure.
Note the following points.


1. Install:
 - Engine assembly (to left side)
 - Mounting bolts



Mounting bolts:

- Bolt ① (Front):**
25 Nm (2.5 m · kg, 18 ft · lb).
- Bolt ② (Rear upper):**
25 Nm (2.5 m · kg, 18 ft · lb).
- Bolt ③ (Rear lower):**
39 Nm (3.9 m · kg, 28 ft · lb)

NOTE: _____
Temporary tighten the bolts before tightening them to specification.




2. Install:
 - Spacer collar ①
 - Drive sprocket ②
 - Lock washer ③.
 - Nut (drive sprocket) ④
 - Drive chain ⑤


NOTE: _____
Before installing the spacer collar ①, grease the oil seal lip.



- Nut (drive sprocket):**
60 Nm (6.0 m · kg, 43 ft · lb)



3. Bend the lock washer tab along the nut flats.



4. Install:

- Gasket (Crankcase cover)
- Crankcase cover (Left) ①
- Change pedal ②

NOTE:

Tighten the screws (Crankcase cover) in stage, using a crisscross pattern.




Screw (Crankcase cover):
 10 Nm (1.0 m·kg, 7.2 ft·lb)
Bolt (Change pedal):
 11 Nm (1.1 m·kg, 7.9 ft·lb)

5. Adjust:

- Drive chain slack
 Refer to the "DRIVE CHAIN SLACK ADJUSTMENT" section in the CHAPTER 3.



Drive chain slack:
 40 mm (1.57 in)



6. Adjust:

- Clutch cable free play @
 Refer to the "CLUTCH ADJUSTMENT" section in the CHAPTER 3.




Free play:
 2 ~ 3 mm (0.08 ~ 0.12 in)



7. Air bleeding:

- Autolube pump

Refer to the "AUTOLUBE PUMP AIR BLEEDING" section in the CHAPTER 3.




8. Install:

- Autolube pump cover ①



Bolt (autolube pump cover):
8 Nm (0.8 m·kg, 5.6 ft·lb)



9. Install:

- Gasket (exhaust pipe)
- Exhaust pipe



Nut ① (Exhaust pipe):
11 Nm (1.1 m·kg, 7.9 ft·lb)

⚠ WARNING

Always use a new gasket.

10. Fill:

- Crankcase

Refer to the "TRANSMISSION OIL REPLACEMENT" section in the CHAPTER 3.



Total amount:
0.6 L (0.53 Imp qt, 0.63 US qt)




CARBURETION

CARBURETOR

- ① Cap
- ② Throttle valve spring
- ③ Starter plunger
- ④ Throttle stop screw
- ⑤ Pilot air screw
- ⑥ Throttle valve
- ⑦ Needle set
- ⑧ Pilot jet
- ⑨ Needle jet
- ⑩ O-Ring
- ⑪ Main jet
- ⑫ Needle valve set
- ⑬ Float
- ⑭ Drain bolt

SPECIFICATIONS

MAIN JET (M.J.)	#130
MAIN AIR JET (M.A.J.)	φ0.5
JET NEEDLE (J.N.)	5JP27-2
NEEDLE JET (N.J.)	Px2
PILOT JET (P.J.)	#27.5
PILOT AIR SCREW (P.A.S.)	1-1/2
FLOAT HEIGHT (F.H.)	20 ~ 22 mm
ENGINE IDLING SPEED	1,450 ~ 1,550 r/min






REMOVAL

NOTE:

The following parts can be cleaned and inspected without disassembly.

- Throttle valve
- Starter plunger
- Throttle stop screw




1. Turn the fuel cock to "OFF" position.
2. Disconnect:
 - Fuel hose ①

⚠ WARNING

Gasoline is highly flammable. Avoid spilling fuel on the hot engine.

3. Disconnect:
 - Oil delivery hose
4. Loosen:
 - Screws (Carburetor damp) ②
5. Remove:
 - Carburetor top ③
 - Carburetor ④




6. Remove:
 - Throttle valve ①
 - Return spring ②



DISASSEMBLY


1. Remove:

- Hoses ①




2. Remove:

- Starter plunger assembly ①




3. Remove:

- Float chamber ①
- Gasket (Float chamber) ②




4. Remove:


- Float pin ①
- Float ②
- Needle valve ③




5. Remove:

- Valve seat ①
- Main jet ②
- Pilot jet ③
- Needle jet ④






6. Remove:
- Throttle stop screw ①
 - Pilot air screw ②




7. Remove:
- Jet needle ①




INSPECTION

1. Inspect:
- Carburetor mixing chamber body
Contamination → Clean.

NOTE: _____
Use a petroleum based solvent for cleaning.
Blow out all passages and jets with compressed air.




2. Inspect:
- Carburetor float chamber body
Contamination → Clean.




3. Inspect:
- Valve seat ①
 - Needle valve ②
 - Gasket ③
- Wear/Damage/Contamination → Replace as a set.

NOTE: _____
Always replace the needle valve and seat as a set.




4. Inspect:
- Starter plunger ①
 - Wear/Contamination → Replace


5. Check:
- Free movement
 - Stick → Replace.
- Insert the throttle valve into the carburetor body, and check for free movement.



6. Inspect:
- Throttle stop screw ①
 - Pilot air screw ②
 - O-ring ③
 - Wear/Damage → Replace.




7. Inspect:
- Jet needle ①
 - Bends/Wear → Replace.




8. Inspect:
- Throttle valve ①
 - Wear/Damage → Replace.

9. Check:
- Free movement
 - Stick → Replace.
- Insert the throttle valve into the carburetor body, and check for free movement.



10. Inspect:
- Float ①
 - Damage → Replace.



11. Inspect:

- Main jet ①
 - Needle jet ②
 - Pilot jet ③
- Contamination → Clean.

NOTE: _____

Blow out the jets with compressed air.

ASSEMBLY


Reverse the "DISASSEMBLY" procedures. Note the following points.

CAUTION: _____

Before reassembling, wash the all parts with a clean gasoline.

1. Connect:

- Throttle cable




2. Install:

- Valve seat ①
- Main jet ②
- Pilot jet ③
- Needle jet ④

NOTE: _____

Align the knock pin ⑤ with the pin slot in the needle jet.



3. Measure:

- Float height ⑥
- Out of specification → Adjust.



Float height (F.H.) :
20 ~ 22 mm (0.787 ~ 0.866 in)





Measurement and adjustment steps:

- Hold the carburetor in an upside down position.
- Measure the distance from the mating surface of the float chamber (gasket removed) to the top of the float.

NOTE:

The float arm should be resting on the needle valve, but not compressing the needle valve.

- If the float height is not within specification, inspect the valve seat and needle valve.
- If either is worn, replace them both.
- Adjust the float height by bending the float tang ① on the float.
- Recheck the float height.



4. Install:

- Float chamber ①
- Gasket (Float chamber) ③

⚠ WARNING

Always use a new gasket.

5. Tighten:


- Screw (Float chamber)



	<p>Screw (Float chamber): 2 Nm (0.2 m·kg, 1.4 ft·lb)</p>
--	---

6. Install:

- Starter plunger ①

	<p>Nut (Starter plunger): 3.5 Nm (0.35 m·kg, 2.5 ft·lb)</p>
--	--





7. Install:
- Throttle valve

NOTE: _____
Align the groove ① of the throttle valve with the projection of the carburetor body.

INSTALLATION

Reverse the "REMOVAL" procedures.
Note the following points.

1. Install:
- Carburetor assembly ①

NOTE: _____
Align the groove ② of the carburetor joint with the projection ③ of the carburetor body.

2. Adjust:
- Idle speed
Refer to the "IDLE SPEED ADJUSTMENT" section in the CHAPTER 3.


	Engine idle speed 1,450 ~ 1,550 r/min
--	---

3. Adjust:
- Throttle cable free play
Refer to the "THROTTLE CABLE FREE PLAY ADJUSTMENT" section in the CHAPTER 3.

	Throttle cable free play: 3 ~ 5 mm (0.12 ~ 0.20 in)
--	---

4. Adjust:
- Carburetor cable free play
Refer to the "CARBURETOR CABLE FREE PLAY ADJUSTMENT" section in the CHAPTER 3.

	Carburetor cable free play: 1.0 mm (0.04 in)
--	--



ADJUSTMENT

Fuel Level Adjustment

1. Measure:

- Fuel level (a)

Out of specification → Adjust.



Fuel level (a):

-0.5 ~ + 0.5 mm

(- 0.02 ~ + 0.02 in)

In the middle of the float chamber
below the carburetor body edge

Fuel level measurement and adjustment steps:


- Place the machine on a level surface.
- Use a garage jack under the engine to ensure that the carburetor is positioned vertically.
- Connect the Fuel Level Gauge (1) to the drain pipe (2).



Fuel level gauge:


P/N. YM-01312-A

- Loosen the drain screw (3) and warm up the engine for several minutes.
- Measure the fuel level (a) with the gauge.
- If the fuel level is incorrect, adjust the fuel level.
- Remove the carburetor.
- Inspect the valve seat and needle valve.
- If either is worn, replace them both.
- Adjust float level by bending the float tang (4) slightly.
- Install the carburetor.
- Recheck the fuel level.



REED VALVE

- ① Reed valve assembly
- ② Reed valve
- ③ Stopper plate
- ④ Gasket
- ⑤ Carburetor joint
- ⑥ Y.E.I.S. chamber






REMOVAL

1. Remove:


- Carburetor

Refer to the "CARBURETOR-REMOVAL" section.



2. Remove:

- YEIS chamber ①
- Carburetor joint ②




3. Remove:

- Reed valve assembly ①
- Gasket ②

DISASSEMBLY

1. Remove:


- Reed valve stopper ①
- Reed valve ②




INSPECTION


1. Inspect:

- Reed valve ①
 - Reed valve stopper ②
- Cracks/Damage → Replace.







2. Measure:
- Reed valve bending limit (a)
Out of specification → Replace.

 **Reed valve bending limit:**
0.4 mm (0.035 in)


① Surface plate




3. Measure:
- Reed valve stopper height (a)
Out of specification → Replace.

 **Reed valve stopper height:**
8.7 ~ 9.3 mm (0.342 ~ 0.366 in)

① Surface plate



4. Inspect:
- Carburetor Joint ①
 - Y.E.I.S. chamber ②
Cracks/Damage → Replace.




ASSEMBLY


Reverse the "DISASSEMBLY" procedure.
Note the following points.

1. Install:
- Reed valves
 - Reed valve stoppers

NOTE:

- Place the reed valve ① with its concave facing the reed valve seat ②.
- Fit the reed valve stopper cut with the corresponding cut on the reed valve.






2. Tighten:
- Screws (Reed valve) ①



Screws (reed valve):
1 Nm (0.1 m·kg, 0.7 ft·lb)
Use LOCTITE ®

NOTE: _____
 Tighten each screw gradually to avoid warping




INSTALLATION

Reverse the "REMOVAL" procedure.
 Note the following points.

1. Install:
- Gasket (New) ①
 - Reed valve assembly ②

⚠ WARNING _____

A damaged gasket may cause the engine revs to accelerate. Always use a new gasket.



2. Install:
- Carburetor joint ①



Bolt (carburetor joint):
8 Nm (0.8 m·kg, 5.8 ft·lb)


Y.E.I.S. chamber ②

CHASSIS

FRONT WHEEL

- ① Wheel axle
- ② Collar
- ③ Dust cover
- ④ Oil seal
- ⑤ Bearing
- ⑥ Spacer (flange)
- ⑦ Spacer (bearing)
- ⑧ Bearing
- ⑨ Gear unit (speedometer)
- ⑩ Oil seal
- ⑪ Front wheel
- ⑫ Cotter pin

Basic weight: With oil and full fuel tank	112 kg (247 lb)	
Cold tire pressure	Front	Rear
Off-road riding	100 kPa (1.0 kg/cm² 15 psi)	100 kPa (1.0 kg/cm² 15 psi)






REMOVAL

⚠ WARNING

Support the machine securely so there is no danger of it falling over.

1. Elevate the front wheel by placing a suitable stand under the engine.




2. Remove:

- Colter pin ①
- Nut (axle) ②
- Front wheel axle ③
- Front wheel ④
- Gear unit (speedometer) ⑤
- Spacer collar ⑥

NOTE:

Do not depress the brake lever when the wheel is off the machine otherwise the brake pads will be forced shut.



INSPECTION


1. Eliminate any corrosion from parts.
2. Inspect:
 - Front wheel axle
Roll the axle on a flat surface.
Bends → Replace.

⚠ WARNING


Do not attempt to straighten a bent axle.

3. Inspect:



- Wheel
Cracks/Bends/Warpage → Replace.



4. Measure:
- Wheel runout
Out of specification → Check the wheel and bearing play.

 **Rim runout limits.**
Vertical ①: 2.0 mm (0.08 in)
Lateral ②: 2.0 mm (0.08 in)

5. Check:
- Wheel bearings
Bearings allow play in the wheel hub or wheel turns roughly → Replace.
 - Oil seals
Wear/Damage → Replace.



Wheel bearing and oil seal replacement steps:


- Clean the outside of the wheel hub.
- Remove the oil seal ① using a flat-head screw driver.

NOTE: _____
 Place a rag ② against the outer edge to protect this edge.


- Remove the bearing using a general bearing puller.
- Install the new bearing and oil seal by reversing the previous steps.

NOTE: _____
 Use a socket ③ that matches the outside diameter of the race of the bearing and oil seal.

CAUTION: _____
Do not strike the center race or balls of the bearing. Contact should be made only with the outer race.



340-012



341-009

6. Check:

- Wheel balance

Wheel is not statically balanced if it comes to rest at the same point after several light rotations.

Out of balance → Install appropriate balance weight at lightest point (on top).

NOTE:

Balance wheel with brake disc installed.

⚠ WARNING

- After mounting a tire, ride conservatively to allow proper tire to rim seating. Failure to do so may cause an accident resulting in machine damage and possible operator injury.
- After a tire repair or replacement, be sure to torque tighten the valve stem locknut ① to specification.



Valve stem locknut:

1.5 Nm (0.15 m·kg, 1.1 ft·lb)

INSTALLATION

Reverse the removal procedure.


Note the following points.

1. Lubricate:


- Front wheel axle
- Bearing
- Oil seal (lip and inside)

2. Inspect:

- Cover gear unit
- Wear/Leakage/Damage → Replace.




3. Install:
- Gear unit assembly




4. Install:
- Front wheel assembly
 - Front wheel axle


NOTE: _____
 Be sure the boss on the outer fork tube is pressed against the projection on the gear unit housing.



5. Tighten:
- Nut (Front wheel axle)

 **Nut (Front wheel axle):**
85 Nm (8.5 m · kg, 61 ft · lb)

NOTE: _____
 Do not loosen the axle nut after torque tightening. If the axle nut groove is not aligned with the wheel shaft cotter pin hole, align groove to hole by tightening up on the axle nut.








6. Install:
- Cotter pin (new) ①

⚠ WARNING _____
Always use a new cotter pin.

REAR WHEEL

- ① Drive chain puller
- ② Collar
- ③ Brake cam lever
- ④ Plate indicator
- ⑤ Brake shoe plate
- ⑥ Cam shaft
- ⑦ Brake shoe
- ⑧ Oil seal
- ⑨ Bearing
- ⑩ Collar
- ⑪ Spacer
- ⑫ Bearing
- ⑬ Oil seal
- ⑭ Collar
- ⑮ Drive chain
- ⑯ Driven sprocket
- ⑰ Hub
- ⑱ Rear wheel





REMOVAL

1. Elevate the rear wheel by placing a suitable stand under the engine.

⚠ WARNING

Support the machine securely so there is no danger of it falling over.


2. Remove:

- Adjuster (rear brake) ①
- Pin ②
- Spring ③
- Cotter pin ④
- Nut (Rear Wheel axle) ⑤
- Washer ⑥
- Chain puller (Left) ⑦

3. Push the rear wheel forward and remove the drive chain from the driven sprocket.

4. Remove:


- Rear wheel axle
- Chain puller
- Rear wheel
- Spacer collar ①



6. Remove:
- Brake cam lever ①
 - Wear indicator ②
 - Spring (Brake shoe) ③
 - Brake shoes ④
 - Brake cam shaft ⑤


INSPECTION:

1. Eliminate any corrosion from parts.
2. Inspect:
Refer to "FRONT WHEEL - INSPECTION" section.




3. Inspect:
 - Brake lining surface
Glazed areas → Remove.
Use coarse sand paper.


NOTE: _____
After using the sand paper, clean of the polished particles with cloth.



4. Measure:
 - Brake lining thickness ①
Out of specification → Replace.

	Brake lining thickness:
	4 mm (0.16 in)
	Wear limit:
	2 mm (0.08 in)


NOTE: _____
Replace the brake shoes as a set if either is found to be worn to the wear limit.



5. Inspect:


- Brake drum inner surface
- Oil/Scratches → Remove.


Oil	Use a rag soaked in lacquer thinner or solvent.
Scratches	Use emery cloth (lightly and evenly polishing).



6. Measure:

- Brake drum inside diameter @
- Out of specification → Replace.

	Brake drum wear limit: 131 mm (5.16 in)
---	---



INSTALLATION:

Reverse the removal procedure.

Note the following points:

1. Install:


- Brake cam shaft ①
- Wear indicator ②

NOTE: _____

- Apply the lithium soap base grease onto the brake cam shaft.
- Align the slot @ in the brake cam shaft with the projection b on the wear indicator.

CAUTION: _____

Wipe off the excess grease.





2. Install:

- Brake cam lever ①

NOTE: _____

Install the brake cam lever as shown.


	Bolt (Brake cam lever): 10 Nm (1.0 m·kg, 7.2 ft·lb)
---	---



3. Apply:
- Lithium soap base grease
- Onto the brake cam lever ① and pivot shaft ②.

CAUTION: _____

Wipe off the excess grease.



4. Install:
- Brake shoes ①
 - Springs (Brake shoes) ②

! WARNING _____

When installing the spring and brake shoe, take care not to damage the spring and not to apply grease to the brake shoes.

5. Lubricate:
- Rear wheel axle
 - Oil seals (Lip and inside)



Lithium soap base grease

6. Install:
- Rear wheel assembly


7. Adjust:
- Drive chain slack




**Drive chain slack:
40 mm (1.61 in)**

Refer to the "DRIVE CHAIN SLACK ADJUSTMENT" section in CHAPTER 3.

8. Tighten:
- Nut (Rear wheel axle)

	<p>Nut (Rear wheel axle): 85 Nm (8.5 m·kg, 61 ft·lb)</p>
---	---



9. Install:
- Cotter pin ①


CAUTION: _____

Do not loosen the axle nut after torque tightening. If the axle nut groove is not aligned with the cotter pin hole, align groove with the hole by tightening up on the axle nut.

⚠ WARNING _____

Always use a new cotter pin.


10. Adjust:
- Rear brake pedal free play
Refer to "CHAPTER 3 - REAR BRAKE ADJUSTMENT" section.

	<p>Rear brake pedal free play: 20 ~ 30 mm (0.8 ~ 1.2 in)</p>
---	---


FRONT BRAKE

- ① Air bleed screw
- ② Retaining bolt
- ③ Pad spring
- ④ Brake pads
- ⑤ Shim
- ⑥ Dust seal
- ⑦ Piston seal
- ⑧ Piston
- ⑨ Brake disc

* Be sure to position the pad so that its round side 4 is backward A .
Be sure to position the shim 5 so that its arrow mark is upward.



- ① Union bolt
- ② Copper washer
- ③ Master cylinder
- ④ Diaphragm
- ⑤ Master cylinder kit
- ⑥ Brake hose




CAUTION: _____


Disc brake components rarely require disassembly. Do not disassemble components unless absolutely necessary. If any hydraulic connection in the system is opened, the entire system should be disassembled, drained, cleaned and then properly filled and bled upon reassembly. Do not use solvents on brake internal components. Solvents will cause seals to swell and distort. Use only clean brake fluid for cleaning. Use care with brake fluid. Brake fluid is injurious to eyes and will damage painted surfaces and plastic parts.

BRAKE PAD REPLACEMENT**NOTE:** _____

It is not necessary to disassemble the brake caliper and brake hose to replace the brake pads.




1. Remove:
 - Retaining bolt (Caliper body) ①
2. Turn the caliper body counterclockwise.



3. Remove:
 - Brake pads ①
 - Pad springs ②

NOTE: _____

- Replace the pad springs as a set if pad replacement is required.
- Replace the pads as a set if either is found to be worn to the wear limit (a).




 **Wear limit:**
0.8 mm (0.031 in)

① Wear indicator

4. Install:

- Pad springs ①
- Brake pads ②




Installation steps:


- Be careful to install the pad springs ① in proper position as shown.
- Install the brake pads ②.


NOTE:


Be sure to position the pad with the arrow ③ to up side.



- Connect a suitable hose ④ tightly to the caliper bleed screw. Then, place the other end of this hose into an open container.
- Loosen the caliper bleed screw and push the piston into the caliper by your finger.
- Tighten the caliper bleed screw.




 **Caliper bleed screw:**
6 Nm (0.6 m · kg, 4.3 ft · lb)




5. Lubricate:
- Retaining bolt (caliper body) ①

	Lithium soap base grease
---	---------------------------------

6. Tighten:
- Retaining bolt (caliper body) ①

	Retaining bolt (Caliper body): 18 Nm (1.8 m·kg, 13 ft·lb)
---	--



7. Inspect:
- Brake fluid level
Refer to the "BRAKE FLUID INSPECTION" section in the CHAPTER 3.


① "LOWER" lever line

8. Check:
- Brake lever operation
A softy or spongy filling → Bleed brake system.
Refer to the "AIR BLEEDING" section.


CALIPER DISASSEMBLY

1. Remove:
- Union bolt ①
 - Cooper washers ②

NOTE: _____
Place the open hose end into a container and pump the oil fluid out carefully.



2. Remove:
- Retaining bolt (Caliper body)
 - Brake pads ①
 - Pad springs ②
- Refer to the "BRAKE PAD REPLACEMENT" section.




3. Remove:

- Caliper body ①
- Caliper bracket ②

NOTE: _____

Before removing the caliper body from the bracket, disconnect the dust boot ③ from the guide shaft ④ on the bracket.



4. Remove:

- Caliper piston ①
- Clip ②
- Dust seal ③

Removal steps:

- Blow moderately compressed air into the hose joint opening to force out the caliper piston from the caliper body.

⚠ WARNING _____

- Never try to pry the caliper piston.
- Cover the piston with a rag 5. Use care so that piston does not cause injury as it is expelled from the cylinder.

- Remove the clip ①, using a thin screw driver ②.

CAUTION: _____

- When removing the clip take care not to damage the dust seal and caliper body.

- Remove the dust seal and piston seal.



MASTER CYLINDER DISASSEMBLY**NOTE:**

Drain the brake system of the brake fluid before removing the master cylinder.


1. Remove:

- Brake lever
- Return spring (Brake lever)

2. Pull back the brake hose cover from the master cylinder.


3. Remove:

- Union bolt ①
- Copper washers




4. Remove:

- Bracket (Master cylinder) ①
- Master cylinder ②



5. Remove:

- Cap (Master cylinder) ①
- Diaphragm ②
- Dust boot
- Circlip ④
- Master cylinder kit ⑤






INSPECTION AND REPAIR

Recommended brake component replacement schedule:	
Brake pads	As required
Piston seal, dust seal	Every two years
Brake hoses	Every four years
Brake fluid	Replace only when brakes or disassembled

⚠ WARNING

All internal parts should be cleaned in new brake fluid only. Do not use solvents.




1. Inspect:

- Caliper piston ①
Scratches/Rust/Wear → Replace.
- Caliper cylinder ②
Wear/Scratches → Replace.


⚠ WARNING

Replace the piston seal and dust seal whenever a caliper is disassembled.




2. Inspect:

- Caliper body
- Caliper bracket
Cracks/Damage → Replace.
- Oil delivery passage (Caliper body)
Blow out with compressed air.
- Slide collar (Caliper body) ①
- Guide shaft (Caliper bracket) ②
Rust/Wear/Damage → Replace.
- Slider boot (Caliper body)
- Dust boot (Guide pin - Bracket)
Wear/Damage → Replace.


**3 Inspect:**

- Master cylinder
Wear/Scratches → Replace the caliper assembly.
- Master cylinder body
Cracks/Damage → Replace.
- Oil delivery passage (Caliper body)
Blow out with compressed air.

**4. Inspect:**

- Master cylinder kit ①
Scratches/Wear/Damage → Replace.
- Diaphragm ②
Wear/Damage → Replace.
- Brake hose
Cracks/Wear/Damage → Replace.

FRONT BRAKE

CHAS

5. Measure:


- Brake pads (thickness) **(a)**
Out of specification → Replace.



Wear limit **(a):**
0.8 mm (0.031 in)

NOTE:

- Replace the pad spring as a set if pad replacement is required.
- Replace the pads as a set if either is found to be worn to the wear limit.



6. Inspect:

- Brake disc
Wear/Damage → Replace.

7. Measure:

- Brake disc deflection
Use Dial Gauge **(1)**
Out of specification → Inspect wheel runout.
If wheel runout is not in good condition, replace.



Maximum deflection:
0.15 mm (0.006 in)

- Brake disc thickness **(a)**
Out of specification → Replace.



Minimum thickness:
3.5 mm (0.14 in)

NOTE:

Tighten the bolts (Brake disc) in stage, using a crisscross pattern.



Bolt (Brake disc):
20 Nm (2.0 m·kg, 14 ft·lb)
Use LOCTITE®



ASSEMBLY



⚠ WARNING

- All internal parts should be cleaned in new brake fluid only.
- Internal parts should be lubricated with brake fluid when installed.



Recommended brake fluid:
DOT #3 or DOT #4

- Replace the piston seal and dust seal whenever a caliper is disassembled.



Front Brake

1. Install:

- Master cylinder kit ①
- Circlip ②
- Dust boot ③

2. Install:


- Master cylinder

NOTE:

- Install the master cylinder bracket with the "UP" mark ① facing upward.
- Tighten first the upper bolt, then the lower bolt.



Bolts (Master cylinder bracket):
9 Nm (0.9 m · kg, 6.5 ft · lb)




3. Install:

- Return spring (brake lever) ①
- Brake lever ②

NOTE:

Apply lithium soap base grease to the brake lever pivot.




4. Install:

- Piston seal ①
- Dust seal ②
- Caliper piston ③

⚠ WARNING

Always use new piston seal and dust seal.



5. Install:

- Caliper bracket ①



Caliper bracket:
35 Nm (3.5 m·kg, 25 ft·lb)

6. Install:

- Pad springs
- Brake pads

Refer to the "BRAKE PAD REPLACEMENT" section.

7. Install:

- Caliper body ②

NOTE:


Apply the lithium-soap base grease onto the caliper guide shaft and retaining bolt.

CAUTION:

- Take care not to allow grease to touch the brake pads.
- Wipe off any excess grease.




Retaining bolt (Caliper body):
18 Nm (1.8 m·kg, 13 ft·lb)



8. Install:
- Copper washers
 - Brake hose
 - Union bolt



Union bolt:
27 Nm (2.7 m·kg, 19 ft·lb)




CAUTION:

When installing the brake hoses ① to the caliper and master cylinder, lightly touch the brake pipe with the projection ②.

WARNING

- Proper hose routing is essential to insure safe machine operation. Refer to "CABLE ROUTING".
- Always use new copper washers.




9. Cover the brake hose connecting point on the master cylinder with the brake hose cover.

10. Fill:
- Master cylinder tank
To "LOWER" level line ①



Recommended brake fluid:
DOT #4 or DOT #3
If DOT #4 is not available,
#3 can be used.


**CAUTION:**

Brake fluid may erode painted surfaces or plastic parts. Always clean up spilled fluid immediately.

⚠ WARNING

- Use only the designated quality brake fluid: otherwise, the rubber seals may deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid: mixing fluids may result in a chemical reaction and lead to poor performance.
- Be careful that water does not enter the master cylinder when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.

11. Bleed the air completely from the brake system.
Refer to the "AIR BLEEDING" section.



12. Install:


- Diaphragm ①
- Cap (Master cylinder) ②



Screw (Master cylinder):
2 Nm (0.2 m·kg, 1.4 ft·lb)

13. Inspect:

- Brake fluid level
Refer to the "BRAKE FLUID INSPECTION" section in CHAPTER 3.



14. Adjust:

- Front brake lever free play (a)



Free play (a) :

10 ~ 20 mm (0.4 ~ 0.8 in)

Refer to the "FRONT BRAKE ADJUSTMENT" section in CHAPTER 3.


AIR BLEEDING

⚠ WARNING

Bleed the brake system if:

- The system has been disassembled.
- A brake hose has been loosened or removed.
- The brake fluid is very low.
- The brake operation is faulty.

A dangerous loss of braking performance may occur if the brake system is not properly bled.



1. Bleed:
 - Brake fluid

Air bleeding steps:

- a. Add proper brake fluid to the reservoir.
- b. Install the diaphragm. Be careful not to spill any fluid or allow the reservoir to overflow.
- c. Connect the clear plastic tube ① tightly to the caliper bleed screw.
- d. Place the other end of the tube into a container.
- e. Slowly apply the brake lever several times.
- f. Pull the lever in. Hold the lever in position.
- g. Loosen the bleed screw ② and allow the lever to travel towards its limit.
- h. Tighten the bleed screw when the lever limit has been reached, then release the lever.


Bleed screw:

6 Nm (0.6 m · kg, 4.3 ft · lb)

- i. Repeat steps (e) to (h) until all of the air bubbles have been removed from the system.


NOTE: _____

If bleeding is difficult, it may be necessary to let the brake fluid system stabilize for a few hours. Repeat the bleeding procedure when the tiny bubbles in the system have disappeared.

- j. Add brake fluid to the level line on the reservoir.

FRONT FORK

- ① Cap
- ② O-Ring
- ③ Cap bolt
- ④ Fork spring
- ⑤ Inner fork tube
- ⑥ Damper rod
- ⑦ Oil lock pieces
- ⑧ Circlip
- ⑨ Dust seal
- ⑩ Oil seal
- ⑪ Outer fork tube
- ⑫ Fork boot
- ⑬ Band



REMOVAL

⚠ WARNING


Support the machine securely so there is no danger of it falling over.

1. Elevate the front wheel by placing a suitable stand under the engine.

2. Remove:


- Front wheel

Refer to the "FRONT WHEEL - REMOVAL" section.



3. Remove:

- Holder (Brake hose) ①
- Brake caliper assembly ②



4. Loosen:

- Pinch bolts (Handle crown) ①
- Cap bolt ②
- Pinch bolts (Under bracket) ③


⚠ WARNING

Support the fork before loosening the pinch bolts.




5. Remove:

- Front fork




DISASSEMBLY

1. Remove:
 - Clamps (Upper ① and lower ②)
 - Fork boot ③



2. Remove:
 - Cap bolt ①
 - Fork spring ②




3. Drain:
 - Fork oil
4. Remove:
 - Dust cover ①
 - Retaining clip ②

Use a thin slotted-head screwdriver.

CAUTION: _____


Take care not to scratch the inner tube.




5. Remove:
 - Bolt (Damper rod) ①
 - Spring washer ②

NOTE: _____


Hold the damper rod to loosen the bolt (Damper rod) by the T-Handle ① and Holder ②.



T-Handle:
YM-01326
Holder:
P/N. YM-01300-1



6. Remove:
- Damper rod ①
 - Rebound spring ②
(From inner fork tube ③)




7. Remove:
- Inner fork tube

Removal steps:


- Hold the fork leg horizontally.
- Pull out the inner fork tube from the outer tube forcibly, but carefully.

CAUTION:

Avoid bottoming the inner tube in the outer tube during the above procedure, as the oil lock piece will be damaged.



8. Remove:
- Oil seal
 - Oil lock piece




INSPECTION

1. Inspect:
 - Inner fork tube ①
 - Outer fork tube ②
 Scratches/Bends/Damage → Replace.


⚠ WARNING

Do not attempt to straighten a bent inner fork tube as this may dangerously weaken the tube.




2. Measure:
 - Fork spring free length ①
 Out of specification → Replace.

 **Minimum free length ①:**
524 mm (0.52 kg/mm, 29.1 lb/in)



3. Inspect:
 - Damper rod ①
Wear/Damage → Replace.
Contamination → Blow out all oil passages with compressed air.
 - Piston ring ②
 - Rebound spring ③
Wear/Damage → Replace.




4. Inspect:
 - O-Ring (Cap bolt) ①
 - Oil lock piece ②
 Damage → Replace.

ASSEMBLY

Reverse the "DISASSEMBLY" procedure.
Note the following points.

NOTE: _____


- In front fork reassembly, be sure to use following new parts.
 - * Guide
 - * Slide bush
 - * Oil seal
 - * Dust seal
- Make sure all components are clean before reassembly.




1. Install:
- Damper rod ①

CAUTION: _____


Allow the damper rod to slide slowly down the inner fork tube until it protrudes from the bottom, being careful not to damage the inner fork tube.




2. Install:
- Oil lock piece ①
(To damper rod)
3. Lubricate:
- Inner fork tube (Outer surface) ②


	FORK OIL 10W or EQUIVALENT
---	-----------------------------------

- ③ Outer fork tube



4. Tighten:
- Bolt (Damper rod)


	Bolt (Damper rod): 23 Nm (2.3 m · kg, 17 ft · lb) Use LOCTITE®
---	---



NOTE: _____
 Hold the damper rod to tighten the bolt (Damper rod) by the T-Handle ① and Holder ②.



T-Handle:
 YM-01326
Holder:
 P/N. YM-01300-1



5. Install:
 • Oil seal ①
 Use the Fork Seal Driver Weight ② and Adapter ③.



Fork seal driver weight:
 YM-33963
Adapter:
 YM-01369


④ Washer

CAUTION: _____

Be sure oil seal numbered side face upward.

NOTE: _____


Before installing the oil seal, apply the lithium soap base grease onto the oil seal lip.



6. Install:
 • Dust seal ①
 Use the Fork Seal Driver Weight ② and Adapter ③.



Fork seal driver weight:
 YM-33963
Adapter:
 YM-01369




7. Install:
 • Retaining clip ①


NOTE: _____

Fit the retaining clip ① correctly in the groove ② in the outer tube.


③ Dust seal

8. Fill:
- Front fork

	Oil capacity: 280 cm ³
	Recommended oil: Fork oil 10WT or equivalent After filling, slowly pump the fork up and down to distribute oil



9. Measure:
- Oil level (a)
- Out of specification → Add or reduce oil.


	Fork oil level: 370 mm
	Below the top of inner tube fully rebounded without fork spring.

NOTE: _____
Place the fork in upright position.

10. Install:
- Fork spring
 - Cap bolt

NOTE: _____
Apply lithium soap base grease to the O-ring (Cap bolt).


11. Before installing the front fork, temporary tighten the cap bolt.



INSTALLATION


Reverse the "REMOVAL" procedure.
Note the following points.

1. Install:
- Front fork
- Temporary tighten the pinch bolts.

**NOTE:**

Position the inner fork tube end in such a way that it is projected with (a) from the top of the handle crown.

Projected length:
10 mm (0.4 in)

**2. Tighten:**

- Pinch bolts ① (Under bracket)
- Cap bolt ②
- Pinch bolts ③ (Handle crown)




Pinch bolt (Under bracket):
23 Nm (2.3 m·kg, 17 ft·lb)

Cap bolt:

24 Nm (2.4 m·kg, 17 ft·lb)

Pinch bolt (Handle crown):

23 Nm (2.3 m·kg, 17 ft·lb)

**3. Install:**

- Brake caliper assembly ①
- Holder (Brake hose) ②




Bolt (Caliper bracket):

35 Nm (3.5 m·kg, 25 ft·lb)

Bolt (Brake hose holder):

10 Nm (1.0 m·kg, 7.2 ft·lb)

**4. Install:**

- Front wheel

Refer to the "FRONT WHEEL - INSTALLATION" section.




Wheel axle nut (Front):

85 Nm (8.5 m·kg, 61 ft·lb)

STEERING HEAD AND HANDLEBARS

- | | | |
|----------------------------|--------------------------|--------------------------|
| ① Handlebar | ⑥ Ring nut | ⑪ Bearing race 2 (Upper) |
| ② Handlebar grip (Right) | ⑦ Cover | ⑫ Bearing race 2 (Lower) |
| ③ Handlebar grip (Left) | ⑧ Bearing race 1 (Upper) | ⑬ Ball 2 |
| ④ Handlebar holder (Upper) | ⑨ Ball | ⑭ Oil light indicator |
| ⑤ Handle crown | ⑩ Bearing race 1 (Lower) | |




REMOVAL


⚠ WARNING

Securely support the machine so there is no danger of it falling over.

1. Elevate the front wheel by placing a suitable stand under the engine.
2. Remove
 - Front wheel
Refer to the "FRONT WHEEL - REMOVAL" section.
 - Front fork
Refer to the "FRONT FORK - REMOVAL" section.




3. Remove:
 - Bolts ① (Front fender)
 - Front fender ②
 - Washers ③




4. Remove:
 - Bolts ① (Number plate)
 - Washer ②
 - Number plate ③

5. Remove:
 - Bands ①
 - Master cylinder assembly ②




6. Disconnect:
- Clutch cable ①
(From clutch cable pivot)

7. Loosen:
- Screws (Throttle cable housing) ①




8. Remove:
- Handlebar holders ①
 - Handlebar

NOTE: _____
 For complete removal of the handlebar, be sure to clear the throttle cable housing.





9. Remove:
- Flange bolt (steering stem) ①
 - Handlebar crown ②



10. Remove:
- Ring nut ①
 - Under bracket ②


NOTE: _____
 When removing the ring nut, use the Ring Nut Wrench ③.




 **Ring nut wrench:**
YU-33975

⚠ WARNING

Support the lower bracket so that it may not fall down.




11. Remove:
- Bearing cover ①
 - Bearing race ① and ② (Upper and lower) ②
 - Ball ③




INSPECTION

1. Wash the bearing in a solvent.
2. Inspect:
 - Bearing races ①
Pitting/Damage → Replace.
 - Dust seal ②
Wear/Damage → Replace.



Bearing race replacement steps:

- Remove the bearing races on the head pipe using long rod ① and the hammer as shown.
- Remove the bearing race on the steering stem using the floor chisel ② and the hammer as shown.
- Install the new dust seal and races.




NOTE:


- Always replace bearings and races as a set.
- Replace the dust seal whenever the steering head is disassembled.

CAUTION:

If the bearing race is not fitted squarely, the head pipe could be damaged.



3. Inspect:
- Handlebar crown ①
 - Under bracket ②
(With steering stem)
- Cracks/Bends/Damage → Replace.



4. Inspect:
- Handlebar
- Bends/Cracks/Damage → Replace.

⚠ WARNING

Do not attempt to straighten a bent handlebar as this may weaken the handlebar.


Handlebar replacement steps:

- Remove the handlebar grip, and lever holder.
- Install the lever holder to a new handlebar.
- Apply a light coat of an adhesive for rubber on the left handlebar end.
- Install the handlebar grip.

NOTE: _____
Wipe off excess adhesive with a clean rag.

⚠ WARNING

Leave the handlebar intact until the adhesive becomes dry enough to make the grip and handlebar stick securely.



INSTALLATION

Reverses the "REMOVAL" procedures.
Note the following points.


1. Lubricate:
 - Bearing races ①
 - Bearings

	Lithium-soap Base Grease
---	---------------------------------



2. Install:
 - Ball bearings
 - Arrange the balls around, and apply more grease


Ball quantity/size: Upper 22 pcs/3/16 in Lower 19 pcs/1/4 in



3. Install:
 - Ball race (Top-Upper)
 - Bearing cover ①
 - Under bracket ②
 - Ring nut ③

⚠ WARNING

Hold the bracket until it is secured.




4. Tighten:
 - Ring nut ①

Tightening steps:

- Tighten the ring nut using the Ring Nut Wrench ②.

	Ring nut wrench: YU - 33975
---	---------------------------------------

NOTE: _____
Set the torque wrench to the ring nut wrench so that they form a right angle.

	Ring nut (Initial Tightening): 38 Nm (3.8 m·kg, 27 ft·lb)
---	---

- Loosen the ring nut one turn.


- Retighten the ring nut using the Ring Nut Wrench.

⚠ WARNING

Avoid over-tightening.




Ring nut (Final Tightening):
6 Nm (0.6 m·kg, 4.3 ft·lb)



5. Install:
- Handlebar crown ①
 - Flange bolt (Steering stem) ②

NOTE:

Temporarily tighten the flange bolt and pinch bolt.




6. Install:
- Front fork
- Refer to the "FRONT FORK - INSTALLATION" section.



Pinch Bolt (Under bracket):
23 Nm (2.3 m·kg, 17 ft·lb)

NOTE:


- In this stage, temporarily tighten the pinch bolts (Handlebar crown).
- Apply lithium soap base grease to the O-ring (Cap Bolt).




7. Tighten:
- Flange bolt (Steering stem) ①
 - Pinch bolts (Handlebar crown) ②



Flange Bolt (Steering stem):
54 Nm (5.4 m·kg, 39 ft·lb)
Pinch Bolt (Handlebar Crown):
23 Nm (2.3 m·kg, 17 ft·lb)




8. Install:
- Handlebar
 - Handlebar holders

 **Bolt (Handlebar holder):**
15 Nm (1.5 m·kg, 11 ft·lb)


NOTE: _____
The upper handlebar holder should be installed with the punch mark ① forward **A**.

CAUTION: _____

First tighten the bolts on the front side of the handlebar holder, and then tighten the bolts on the rear side.




NOTE: _____
Before installing the handlebar onto the handlebar crown, apply a light coat of lithium soap base grease onto the handlebar end and install the throttle housing to the handlebar.



9. Install:
- Brake master cylinder

NOTE: _____
• Install the master cylinder bracket with the "UP" mark facing upward.
• Tighten first the upper bolt, then the lower bolt.

 **Bolts (Master cylinder bracket):**
9 Nm (0.9 m·kg, 6.5 ft·lb)

10. Install:
- Clutch cable

NOTE: _____
Apply a light coat of lithium soap base grease onto the clutch cable end.

11. Install:


- Front wheel

Refer to the "FRONT WHEEL - INSTALLATION" section.



Front wheel axle:

85 Nm (8.5 m-kg, 61 ft-lb)



12. Adjust:

- Clutch cable free play **a**

Refer to the "CLUTCH ADJUSTMENT" section in CHAPTER 3.




Free play:

2 ~ 3 mm (0.08 ~ 0.12 in)

REAR SHOCK ABSORBER AND SWINGARM

- ① Rear shock absorber assembly
- ② Spring
- ③ Bush

SPRING PRELOAD (INSTALLED):
STANDARD LENGTH:
245 mm (9.64 in)
A MINIMUM LENGTH:
241 mm (9.49 in)
MAXIMUM LENGTH:
249 mm (9.80 in)




25 Nm (2.5 m·kg, 18 ft·lb)



REAR SHOCK ABSORBER AND SWINGARM



- | | | |
|-----------------|--------------------|------------------|
| ① Swingarm | ⑨ Spring washer | ⑰ Bolt |
| ② Bush 1 | ⑩ Bolt with washer | ⑱ Torsion spring |
| ③ Bush 2 | ⑪ Tensioner arm | ⑲ Chain guard |
| ④ Swingarm bush | ⑫ Oil seal | ⑳ Thrust cover |
| ⑤ Shim | ⑬ Tensioner | ㉑ Bush |
| ⑥ Thrust cover | ⑭ Chain guide | ㉒ Seal |
| ⑦ Pivot shaft | ⑮ Nut | |
| ⑧ Self lock nut | ⑯ Pan head screw | |




HANDLING NOTES

⚠ WARNING

This shock absorber contains highly pressurized nitrogen gas. Read and understand the following information before handling the shock absorber. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling.

- Do not tamper with or attempt to open the cylinder assembly.
- Do not subject shock absorber to an open flame or other high heat source. This may cause the unit to explode due to excessive gas pressure.
- Do not deform or damage the cylinder in any way. Cylinder damage will result in poor damping performance.
- Take care not to scratch the contact surface of the piston rod with the cylinder or oil could leak out.
- When scrapping the shock absorber, refer to the "NOTES ON DISPOSAL" section.



NOTES ON DISPOSAL

Shock absorber disposal steps:

Gas pressure must be released before disposing of shock absorber. To do so, drill ① a 2 ~ 3 mm (0.08 ~ 0.12 in) hole through the cylinder wall at a point 15 ~ 20 mm (0.6 ~ 0.8 in) from the end of the gas chamber.

⚠ WARNING

Wear eye protection to prevent eye damage from escaping gas and/or metal chips.



REMOVAL


⚠ WARNING

Securely support the machine so there is not danger of it falling over.

Rear shock absorber

1. Remove:
 - Side covers (left and right)
 - Seat
 - Fuel tank


2. Elevate the rear wheel by placing a suitable stand under the engine.



3. Remove:
 - Cotter pin ①
 - Washer ②
 - Thrust cover ③
 - Clevis pin ④

⚠ WARNING


When removing the clevis pin ④, hold the swingarm so that it does not drop downwards when the clevis pin removed.



4. Remove:
 - Cotter pin ①
 - Nut ②
 - Washer ③
 - Bolt (Shock absorber - Upper) ④



5. Remove:
- Rear wheel
Refer to the "REAR WHEEL - REMOVAL" section.




6. Remove:
- Rear shock absorber ①

Swingarm


⚠ WARNING

Securely support the machine so there is no danger of it falling over.

1. Elevate the rear wheel by placing a suitable stand under the engine.
2. Remove:
 - Rear shock absorber
Refer to the "REAR SHOCK ABSORBER" section.
3. Remove:
 - Rear wheel
Refer to the "REAR WHEEL - REMOVAL" section.



4. Remove:
 - Bolts (Chain guard) ①



5. Check:
- Swingarm free play

Inspection steps:

- Check the tightening torque of the pivot shaft (swingarm) securing nut ①.





Nut (swingarm-pivot shaft):
43 Nm (4.3 m·kg, 31 ft·lb)

- Check the swingarm side play **A** by moving it from side to side.
- If side play is noticeable, check the collar and bushings or adjust the shim.




Side play (At end of swingarm):
1.0 mm (0.04 in)


- Check the swingarm vertical movement **B** by moving it up and down.
- If vertical movement is tight, bound or rough, check the collar and bushings or adjust the shim.



6. Disconnect:
- Joint (Drive chain) ①


7. Remove:
- Chain tensioner ①
 - Pivot shaft ②
 - Swingarm ③





8. Remove:

- Thrust covers ①
- Bushings (Swingarm) ②
- Seal ③
- Shim ④




INSPECTION

Shock Absorber

1. Inspect:


- Shock absorber rod
Bends/Damage → Replace the shock absorber assembly.
- Shock absorber
Oil leaks/Gas leaks → Replace the shock absorber assembly.
- Spring
Wear/Damage → Replace the shock absorber assembly.
- Bushings ①.
Wear/Damage → Replace.
- Thrust covers ②
- Bolt ③
Wear/Bends/Damage → Replace.
- Clevis pin ④
Wear/Damage → Replace.



Swingarm

1. Inspect:

- Swingarm
Crack/Bend/Damage → Replace.




2. Inspect:

- Pivot shaft ①
Roll the axle on a flat surface.
Bends → Replace.

⚠ WARNING

Do not attempt to straighten a bent axle.

3. Wash the swingarm pivoting parts in a solvent.




4. Inspect:


- Pivot shaft ①
- Thrust cover ②
- Bushings (Swingarm) ③
Pitting/Damage → Replace.
- Washer plate ④
- Spring washer ⑤
- Nut ⑥
Scratches/Damage → Replace.
- Seal ⑦
Wear/Damage → Replace.

SIDE CLEARANCE ADJUSTMENT

1. Measure:

- Collar length ①
Out of specification → Replace.




 **Inner Collar length:**
165.2 ~ 165.4 mm (6.504 ~ 6.512 in)

2. Measure:

- Pivot width (Swingarm) (b)

3. Calculate:

- Swingarm side clearance
Out of specification → Adjust side clearance using shim.
By using formula given below.




Side clearance:
= (a) - (b)

Side clearance:
Less than 0.3 mm (0.012 in)

If the side clearance is out of specification, adjust it to specification by installing the adjust shim at positions, C and D.

NOTE: _____

- The adjust shim is available only in the 0.3 mm (0.012 in) - thick type.
- When only one shim is required, install it on the left side, and when two shims are necessary, install them on both right and left sides.



Example:

If the inner collar length
(a) = 165.4 mm (6.512 in)
and the pivot width

(b) = 164.9 mm (6.492 in)

Side clearance
= 165.4 - 164.9 = 0.5 mm

Then, install the one shim on the left side.

NOTE: _____

After installing the shim, the side clearance should be 0.2 mm (0.008 in).



Shim thickness:
0.3 mm (0.0012 in)




INSTALLATION

Rear shock Absorber


Reverse the "REMOVAL" procedure.
Note the following points.

1. Apply:
 - Lithium soap base grease
To clevis pin and mounting bolt



2. Tighten:
 - Nut (Shock absorber)

	Nut (Shock absorber): 25 Nm (2.5 m·kg, 18 ft·lb)
--	--



3. Install:
 - Clevis pin
 - Shock absorber
 - Cotter pin

⚠ WARNING


Always use a new cotter pin.

4. Adjust:
 - Rear shock absorber
Refer to the 'REAR SHOCK ABSORBER ADJUSTMENT' section in CHAPTER 3.


Swingarm


Reverse the "REMOVAL" procedure.
Note the following points.

1. Apply:
 - Lithium soap base grease
To bushings pivoting, shaft, collar and inside of thrust cover.





2. Tighten:
- Nut (Pivot shaft) ①

	Nut ① (Pivot shaft): 43 Nm (4.3 m·kg, 31 ft·lb)
---	---




3. Tighten:
- Bolts (Chain guard) ①
 - Nut (Chain tensiner) ②


	Bolt (Chain guard): 4 Nm (0.4 m·kg, 2.9 ft·lb)
	Nut (chain tensiner): 7 Nm (0.7 m·kg, 5.1 ft·lb)




4. Install:
- Rear wheel
Refer to "REAR WHEEL - INSTALLATION" section.

	Nut (Rear wheel axle): 85 Nm (8.5 m·kg, 61 ft·lb)
---	---

5. Install:
- Rear shock absorber
Refer to the "REAR SHOCK ABSORBER" section.




6. Adjust:
- Drive chain slack ②
Refer to the "DRIVE CHAIN SLACK ADJUSTMENT" section in CHAPTER 3.

	Drive chain slack: 40 mm (1.81 in)
---	--

DRIVE CHAIN AND SPROCKETS

- ① Drive sprocket
- ② Chain joint
- ③ Drive chain
- ④ Stud bolt
- ⑤ Nut
- ⑥ Plate washer

	DRIVE CHAIN:
	TYPE: 428 H
A	N° OF LINKS: 122
	DRIVE CHAIN SLACK:
	40 mm (1.57 in)




39 Nm (3.9 m·kg, 28 ft·lb)

NOTE: _____
 Before removing the drive chain and sprocket, drive chain stretch should be checked.


REMOVAL

1. Remove:
 - Crankcase cover (Left) ①




2. Straighten:
 - Lock washer tab ①
3. Loosen:
 - Nut (Drive sprocket) ②

NOTE: _____
 When loosening the drive sprocket nut, apply the rear brake pedal and shift transmission to the 6th position.




4. Remove:
 - Clip (Master link) ①
 - Plate (Master link) ②
 - Master link ③
 - Drive chain ④




5. Remove:
 - Chain tensioner ①
 - Drive sprocket

6. Remove:
 - Rear wheel
 Refer to the "REAR WHEEL - REMOVAL" section.




7. Remove:
 - Driven sprocket ①



INSPECTION AND CLEANING


1. Check:

- Drive chain stretch
Pull ② the chain away from the driven sprocket.
Distance chain/sprocket higher than 1/2 tooth ① → Replace drive chain.




2. Clean:

- Drive chain
Place it in solvent, and brush off as much dirt as possible. Then remove the chain from the solvent and dry the chain.




3. Inspect:

- Rollers ①
- Side plates ②
Damage/Wear → Replace drive chain.



4. Check:


- Drive chain stiffness
Stiff → Replace drive chain.



5. Inspect:

- Drive sprocket
More than 1/2 tooth ① wear → Replace sprocket.
Bent teeth → Replace sprocket

- ② Correct
- ③ Roller
- ④ Sprocket



Drive sprocket replacement steps:

- Straighten the lock washer ① tabs and remove the driven sprocket ②.
- Install a new driven sprocket and lock washers.


⚠ WARNING

Always use new lock washers.




Nut (Driven sprocket):
39 Nm (3.9 m·kg, 28 ft·lb)

- Bend the lock washer tabs along the nut flats.



6. Inspect:

- Chain tensioner
Wear/Damage → Replace.



INSTALLATION


Reverse the "REMOVAL" procedure.
Note the following points.

1. Install:

- Rear wheel
Refer to the "REAR WHEEL - INSTALLATION" section.





Nut (Rear Wheel axle):
85 Nm (8.5 m·kg, 61 ft·lb)
Bolt (Swingarm end):
8 Nm (0.3 m·kg, 2.2 ft·lb)



2. Install:
- Lock washer ①
 - Drive sprocket ②
 - Drive chain ③

3. Tighten:
- Nut (Drive sprocket) ④

	Nut (Drive sprocket): 60 Nm (6.0 m·kg, 43 ft·lb)
---	--




4. Bend the lock washer tab along the nut flats.


⚠ WARNING

Always use a new lock washer (drive sprocket). Make sure that the clip ① is installed in the correct direction. Otherwise, the drive chain will be separated.

A Turning direction



5. Adjust:
- Drive chain slack ⑥
- Refer to the "DRIVE CHAIN SLACK ADJUSTMENT" section in CHAPTER 3.


	Drive chain slack: 40 mm (1.57 in)
---	--

ELECTRICAL

RT180A CIRCUIT DIAGRAM

COMPONENTS

- ① Spark plug
- ② Ignition coil
- ③ C.D.I. Magneto
- ④ C.D.I. Unit
- ⑤ Rectifier/regulator
- ⑥ Resistor
- ⑦ Oil level indicator light
- ⑧ Oil level gauge
- ⑨ Neutral switch
- ⑩ "ENGINE STOP" switch




COLOR CODE

B	Black	Ch	Chocolate	W/R	White/Red
R	Red	Dg	Dark green	W/L	White/Blue
O	Orange	Sb	Sky blue	Y/R	Yellow/Red
L	Blue	Br	Brown	G/R	Green/Red
P	Pink	L/Y	Blue/Yellow	G/Y	Green/Yellow
Y	Yellow	B/Y	Black/Yellow	G/W	Green/White
G	Green	B/W	Black/White	Br/W	Brown/White
W	White	B/R	Black/Red	L/R	Blue/Red

ELECTRICAL COMPONENTS (1)

- ① Wireharness
- ② "OIL" level indicator light
- ③ Ignition coil
- ④ Rectifier/Regulator
- ⑤ Resistor
- ⑥ C.D.I. Unit
- ⑦ "NEUTRAL" switch
- ⑧ "OIL" level gauge

<p>IGNITION COIL: PRIMARY COIL RESISTANCE 1.44 ~ 1.76 Ω at 20 °C (68 °F) SECONDARY COIL RESISTANCE 5.12 ~ 7.68 kΩ at 20 °C(68 °F)</p>
--






SIGNAL SYSTEM

CIRCUIT SYSTEM

NOTE:

For the color codes, see page 7-1.





TROUBLESHOOTING

"OIL" INDICATOR LIGHT DOES NOT COME ON.**Procedure:****Check:**

1. Bulb
2. Bulb socket
3. Resistor
4. Oil Level gauge (Diode)
5. Oil level gauge
6. Neutral switch
7. Lighting coil
8. Wiring connection (entire lighting system)

NOTE:

Remove the following parts before troubleshooting.

- 1) Side covers (Left and right)
- 2) Seat
- 3) Fuel tank
- 4) Oil tank cover

Use the following special tool in this troubleshooting.




Pocket tester:
90890-03112



1. Bulb

- Remove the bulb.
Connect the Pocket Tester ($\Omega \times 1$) to the bulb.

Tester (+) Lead → Terminal ①
Tester (-) Lead → Terminal ②



- Check the bulb for continuity.

NOCONTINUITY


Replace bulb.



2. Bulb socket

- Disconnect the indicator lights lead ① from the wire harness.
- Connect the Pocket Tester ($\Omega \times 1$) to the lead

Tester (+) Lead → Brown ① Terminal
Tester (-) Lead → Green/Blue ② Terminal



- Check the bulb socket for continuity.

NOCONTINUITY

Replace bulb socket.





3. Resistor

- Disconnect the resistor lead.
- Connect the pocket tester ($\Omega \times 10$) to the resistor lead.

Tester (+) lead → Red lead ①
 Tester (-) lead → Brown lead ②

- Measure the resistor resistance.

Resistor resistance:
17 Ω at 20 °C

OUT OF SPECIFICATION

Replace resistor

MEETS SPECIFICATION

4. Oil level gauge

- Remove the oil level gauge from the oil tank.
- Disconnect the oil level gauge coupler from the wireharness.
- Connect the Pocket Tester ($\Omega \times 1$) to the oil level gauge.

Tester (+) Lead → Black/Red ① Terminal
 Tester (-) Lead → Sky blue ② Terminal

- Check the oil level gauge for continuity.

NOCONTINUITY

Replace oil level gauge

CONTINUITY





5.Oil level gauge


- Connect the Pocket Tester ($\Omega \times 1$) to the oil level switch.

Tester (+) Lead \rightarrow Black/Red ① Terminal
Tester (-) Lead \rightarrow Black ② Terminal


- Hold the oil level gauge in an upright and upside down position.
- Check the oil level gauge for continuity.

Switch position	Good condition		Bad condition	
	○	X	X	○
Upright position	○	X	X	○
Up side down position	X	○	X	○

○ : Continuity X : Nocontinuity



Replace oil level gauge.



6.Neutral switch

- Disconnect the C.D.I. magneto lead from the wireharness.
- Connect the Pocke Tester ($\Omega \times 1$) to the neutral switch.

Tester (+) Lead \rightarrow Sky blue ① Terminal
Tester (-) Lead \rightarrow Frame Ground ②



- Shift the transmission in neutral gear.
- Check the neutral switch for continuity.

Transmission position	Good condition	Bad condition		
Neutral	○	×	×	○
Gear	×	○	×	○

○ : Continuity × : Nocontinuity

BAD CONDITION

Replace neutral switch.


GOOD CONDITION

7. Lighting coil resistance

- Disconnect the C.D.I. magneto leads (Yellow and White) from the wireharness.
- Connect the Pocket Tester ($\Omega \times 1$) to the lighting coil coupler.

Tester (+) Lead → Yellow ① and white ② Terminals

Tester (-) Lead → Black ③ Terminal



- Measure the lighting coil resistances



Lighting coil resistances

Yellow - Black:
0.42 ~ 0.52 Ω at 20 °C (68 °F)

White - Black:
0.28 ~ 0.34 Ω at 20 °C (68 °F)

OUT OF SPECIFICATION

Replace stator assembly.

BOTH MEETS SPECIFICATION

8. Wiring connection

- Check the entire lighting system for secure connections. Refer to the "WIRING DIAGRAM" section.

POOR CONNECTION

Correct.

CORRECT

Rectifier/Regulator is faulty, replace it.




Previous circuit-diagram shows ignition circuit in circuit diagram.

NOTE: _____

For the color codes, see page 7-1.

- ① CDI magneto
- ② CDI unit
- ③ Ignition coil
- ④ Spark plug
- ⑤ "ENGINE STOP" switch
- ⑥ Neutral switch
- ⑦ "OIL" indicator light
- ⑧ "Oil" level gauge





TROUBLESHOOTING

**IF IGNITION SYSTEM SHOULD BECOME INOPERATIVE
(NO SPARK OR INTERMITTENT SPARK)**

Procedure

Check;

- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Spark plug 2. Ignition spark gap 3. Spark plug cap resistance 4. Ignition coil resistance | <ol style="list-style-type: none"> 5. "ENGINE STOP" switch 6. Source coil resistance 7. Pickup coil resistance 8. Wiring connection
(Entire ignition system) |
|---|--|

NOTE:

Remove the following parts before troubleshooting.


- 1) Side cover (Left)
- 2) Side cover (Right)
- 3) Seat
- 4) Fuel tank

Use the following special tools in this troubleshooting.

	<p>Pocket tester: P/N. YU - 03112</p>
--	--

	<p>Dynamic spark tester: P/N. YU - 34487</p>
--	---

1. Spark plug	
<ul style="list-style-type: none"> • Check the spark plug condition • Check the spark plug gap. Refer to the "SPARK PLUG INSPECTION" section in the CHAPTER 3. 	
<p>Standard spark plug: B8ES (N.G.K.)</p>	
	<p>Spark plug gap: 0.6 ~ 0.7 mm (0.24 ~ 0.28 in)</p>



Repair or replace spark plug.







2. Ignition spark gap

- Disconnect the spark plug cap from the spark plug.
- Connect the Dynamic Spark Tester ① to the spark plug and spark plug cap ②, and set the specified spark gap.

- Start the engine.
- Check the ignition spark condition.

 **Minimum spark gap:**
6 mm (0.24 in)




Ignition circuit is good.




3. Spark plug cap resistance

- Remove the spark plug cap.
- Connect the Pocket Tester ($\Omega \times 1k$) to the spark plug cap.

- Check the spark plug cap for specified resistance.

 **Spark plug cap resistance:**
4 ~ 6 k Ω at 20 °C (69 °F)



Replace spark plug cap.





<p>4. Ignition coil resistance</p> <ul style="list-style-type: none"> • Disconnect the ignition coil lead (Black/White) from the wireharness. • Connect the Pocket Tester ($\Omega \times 1$) to the ignition coil. 	
<p>Tester (+) Lead → (B/W) ① Terminal Tester (-) Lead → Ignition Coil Base ②</p>	
<ul style="list-style-type: none"> • Measure the primary coil resistance. 	
	<p>Primary coil resistance: 0.7 ~ 1.1 Ω at 20 °C (68 °F)</p>
<ul style="list-style-type: none"> • Connect the Pocket Tester ($\Omega \times 1$) to the ignition coil. 	
<p>Tester (+) Lead → Spark Plug Lead ① Tester (-) Lead → Ignition Coil Base ②</p>	
<ul style="list-style-type: none"> • Measure the Secondary coil resistance. 	
	<p>Secondary coil resistance: 5.7 ~ 8.5 kΩ at 20 °C (68 °F)</p>

OUT OF SPECIFICATION

Replace ignition coil.


MEETS SPECIFICATION



5. "ENGINE STOP" switch

- Disconnect the "ENGINE STOP" switch leads (Black/White and Black) from the wireharness.
- Connect the Pocket Tester ($\Omega \times 1$) to the "ENGINE STOP" switch.


Tester (+) Lead \rightarrow Black/White ① Lead
Tester (-) Lead \rightarrow Black ② Lead



- Turn the "ENGINE STOP" switch to "OFF" and "RUN".
- Check the "ENGINE STOP" switch for continuity.

Switch position	Good condition		Bad condition		
RUN	X		○	X	○
OFF	○		X	X	○

○: Continuity X: Nocontinuity



BAD CONDITION

Replace handlebar switch.





6. Source coil resistance

- Disconnect the C.D.I. magneto leads (Black/Red and Black) from the wireharness.
- Connect the Pocket Tester ($\Omega \times 100$) to the source coil.

Tester (+) Lead → Black/Red ① Terminal
Tester (-) Lead → Black ② Terminal

- Measure the source coil resistance.

Source coil resistance:
270 ~ 330 Ω at 20 °C (68 °F)

MEETS SPECIFICATION

OUT OF SPECIFICATION

Replace source coil.


7. Pickup coil resistance

- Disconnect the C.D.I. magneto leads (White/Red and Black) from the wireharness.
- Connect the Pocket Tester ($\Omega \times 100$) to the pickup coil.

Tester (+) Lead → White/Red ① Terminal
Tester (-) Lead → Black ② Terminal

IGNITION SYSTEM

ELEC



TROUBLESHOOTING

NOTE:

The following troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to troubleshooting. Refer to the relative procedure in this manual for inspection, adjustment and replacement of parts.

STARTING FAILURE/HARD STARTING

FUEL SYSTEM

PROBABLE CAUSE


<p>Fuel tank</p> <hr/> <p>Fuel cock</p> <hr/> <p>Carburetor</p> <hr/> <p>Air cleaner</p>	<ul style="list-style-type: none"> • Empty • Clogged fuel filter • Clogged fuel breather hose • Contaminated fuel or fuel containing water or foreign material <hr/> <ul style="list-style-type: none"> • Clogged fuel hose <hr/> <ul style="list-style-type: none"> • Contaminated fuel or fuel containing water or foreign material • Clogged pilot jet • Clogged pilot air passage • Sucked-in air • Deformed float • Groove-worn needle valve • Improperly sealed valve seat • Improperly adjusted fuel level • Improperly set pilot jet • Clogged starter jet • Starter plunger malfunction • Improperly adjusted starter cable <hr/> <ul style="list-style-type: none"> • Clogged air filter
--	--

STARTING FAILURE/HARD STARTING

TRBL SHTG	?
--------------	---

ELECTRICAL SYSTEM

PROBABLE CAUSE




STARTING FAILURE/HARD STARTING/POOR IDLE SPEED PERFORMANCE



COMPRESSION SYSTEM


PROBABLE CAUSE



POOR IDLE SPEED PERFORMANCE

POOR IDLE SPEED PERFORMANCE


PROBABLE CAUSE



POOR MEDIUM AND HIGH SPEED PERFORMANCE


FUEL SYSTEM

PROBABLE CAUSE



ELECTRICAL SYSTEM

PROBABLE CAUSE




POOR MEDIUM AND HIGH SPEED PERFORMANCE




COMPRESSION SYSTEM

PROBABLE CAUSE




FAULTY GEAR SHIFTING


HARD SHIFTING



CHANGE PEDAL DOES NOT MOVE




JUMP-OUT GEAR



CLUTCH SLIPPING/Dragging


CLUTCH SLIPPING

PROBABLE CAUSE




CLUTCH DRAGGING

PROBABLE CAUSE




IMPROPER KICKING


SLIPPING



HARD KICKING




KICK CRANK NOT RETURNING



INSTABLE HANDLING

INSTABLE HANDLING


PROBABLE CAUSE



OVERHEATING OR OVER-COOLING

OVERHEATING

PROBABLE CAUSE



FAULTY BRAKE/FRONT FORK OIL LEAKAGE AND FRONT FORK MALFUNCTION

TRBL
SHTG

?

FAULTY BRAKE

POOR BRAKING EFFECT

└ Disc brake

PROBABLE CAUSE

- Worn brake pad
- Worn brake disc
- Air in brake fluid
- Leaking brake fluid
- Faulty cylinder kit cup
- Faulty caliper kit seal
- Loose union bolt
- Broken brake hose
- Oily or greasy brake disc
- Oily or greasy brake pad
- Improper brake fluid level

FRONT FORK OIL LEAKAGE AND FRONT FORK MALFUNCTION

OIL LEAKAGE

PROBABLE CAUSE

- Bent, damaged or rusty inner tube
- Damaged or cracked outer tube
- Damaged oil seal lip
- Improperly installed oil seal
- Improper oil level (too much)
- Loose damper rod holding bolt
- Broken cap bolt O-ring
- Loose drain bolt
- Damaged drain bolt gasket

MALFUNCTION

PROBABLE CAUSE

- Bent, deformed or damaged inner tube
- Bent or deformed outer tube
- Damaged fork spring
- Worn or damaged slide metal
- Bent or damaged damper rod
- Improper oil viscosity
- Improper oil level