

YAMAHA

OWNER'S SERVICE MANUAL

TY80B

www.legends-yamaha-enduros.com

451-28199-11

NOTICE

Yamaha Motor Company is confident you will enjoy your new Yamaha to the utmost. We have made every effort to provide you with a safe, well-engineered and constructed product.

This Owner's Service Manual will acquaint you with several features and maintenance procedures concerning your Yamaha. However, if you are unfamiliar with the product, or the features or procedures outlined within this manual, we strongly urge you to consult your Authorized Yamaha Dealer for additional information.

www.legends-yamaha-enduros.com
TY80B OWNER'S SERVICE MANUAL

1975

FIRST EDITION JUNE 1974

**ALL RIGHTS RESERVED BY YAMAHA MOTOR COMPANY
LIMITED, JAPAN. PRINTED IN JAPAN. LIT-11624-51-01**

FOREWORD

Yamaha's TY80B Trials is a completely new model designed solely for the rigors of Trials competition. Production is limited. Each unit is assembled and checked according to the same rigorous principles as our championship road racing and motocross models.

This Owner's Service Manual is included with your TY80B to provide basic information for operation and maintenance. Additional information regarding major repairs, such as crankcase disassembly, can be found within the GT80A Service Manual and various other information and training manuals available from your Authorized Yamaha Dealer.

www.legends-yamaha-enduros.com

Oveaseas Service Dept.
International Division
Yamaha Motor Company, Ltd.

GENERAL VIEW




Fig. 1



Fig. 2

TABLE OF CONTENTS

VIEW

I.	MACHINE IDENTIFICATION	1
II.	SPECIFICATIONS.....	2
III.	MAINTENANCE SPECIFICATIONS	5
IV.	NOMENCLATURE	9
V.	BASIC INSTRUCTIONS	11
VI.	OPERATION	21
VII.	MECHANICAL ADJUSTMENTS.....	26
VIII.	MAINTENANCE AND MINOR REPAIRS.....	40
IX.	CHASSIS AND SUSPENSION	107
X.	ELECTRICAL SYSTEM	130
XI.	MISCELLANEOUS	137

www.legends-yamaha-enduros.com

Yamaha Motor Corp.

I. MACHINE IDENTIFICATION

The frame serial number is located on the right-hand side of the headstock assembly. The first three digits identify the model. This is followed by a dash. The remaining digits identify the production number of the unit. Yamaha production begins -000101.


The engine serial number is located on a raised boss on the upper left-hand side of the engine.

Engine identification follows the same code as frame identification.

Normally, both serial numbers are identical; however, on occasion they may be two or three numbers off.


Note:

Always check your registration papers against the actual machine serial numbers. If any discrepancy is found, have it corrected immediately.



1. Frame serial number

Fig. 3



1. Engine serial number

Fig. 4

II. SPECIFICATIONS

These specifications are for general use. For a more complete list refer to Maintenance Specifications and/or the GT80A Service Manual.

DIMENSIONS/WEIGHTS:	
Overall length	61.4 ins. (1,560 mm.)
Overall width	27.2 ins. (690 mm.)
Overall height	35.0 ins. (890 mm.)
Wheelbase	40.4 ins. (1,025 mm.)
Minimum ground clearance	0.0 ins. (000 mm.)
Seat height (unloaded)	23.6 ins. (600 mm.)
Machine net weight	000 lbs. (00 kgs.)
ENGINE:	
Type	2-stroke, gasoline, "Torque Induction"
Bore/stroke	1.575 × 1.563 ins. (47 × 42 mm.)
Displacement	2.99 cu.in. (72 c.c.)
Starting system	Primary kick
Lubricating system	Separate lubrication (Yamaha Autolube)
CARBURETION:	
Manufacturer/type/effective venturi dia.	T.K. V16P-3 16 mm.-dia.
Idle r.p.m.	1,250 ~ 1,350 r.p.m.
Main jet	#86
Needle jet	2,080

Jet needle #/clip position	049/2 position
Air jet (turns out)	1-1/2
Float level	0.91 in. (23.0 mm.)
Cut away	1.0
Air cleaner type	Wet, foam
CLUTCH:	
Type	Wet, multiple-disk
Primary drive system	Gear
Primary drive ratio	68/19 (3.578)
TRANSMISSION:	
Type	Constant mesh, 4-speed forward
Reduction ratio	1st www.legends-yamaha.com 39/12 (3.250)
	2nd 34/17 (2.000)
	3rd 30/21 (1.428)
	4th 27/24 (1.125)
SECONDARY DRIVE:	
Type/size	DK420/92L
Reduction ratio	41/12 (3.417)
ELECTRICAL:	
Ignition type/timing	Magneto ignition, 0.71 in. (1.8 mm.) B.T.D.C.
Spark plug/MFR/type/gap	N.G.K./B-6HS/ 0.019 ~ 0.023 in. (0.5 ~ 0.6 mm.)

CHASSIS:

Frame type	Double cradle type
Front suspension/type/travel	Telescopic fork 3.9 ins. (100 mm.)
Rear suspension/type/travel	Swing arm 2.6 ins. (65 mm.)
Steering lock-to-lock (degrees)	70°
Front caster/trail	63°30' 2.9 ins. (74 mm.)
Tire/size/tread type	2.50—16—4PR Trials universal
Nominal pressure	20 lbs/in. ² (1.4 kgs/cm. ²)
Rear tire size/tread type	3.00—14—4PR Trials universal
Nominal pressure	28 lbs/in. ² (2.0 kgs/cm. ²)
Front brake type/actuating method	Internal expansion/right hand operation
Rear brake type/actuating method	Internal expansion/right hand operation

www.legends-yamaha-enduros.com

VOLUMES/TYPE FLUID:

Gasoline tank/type	2.5 liters, low-lead gasoline
Oil tank/type	0.22 liter, Yamalube 2-cycle
Transmission/type	500 ~ 550 c.c., Yamalube 4-cycle
Front fork (each)/type	85 c.c., Yamaha fork oil

Note:

The Research and Engineering Departments of Yamaha are continually striving to further perfect all models. Improvements and modifications are therefore inevitable.

In light of this fact, all specifications within this manual are subject to change without notice to the owner. Information regarding changes is forwarded to all Authorized Yamaha Dealers as soon as available. If a discrepancy is noted, please consult your dealer.

www.legends-yamaha-enduros.com

III. MAINTENANCE SPECIFICATIONS


Page	Item	Nominal (New)	Minimum (Allowable)	Maximum (Allowable)
32 ~ 35	AUTOLUBE: Minimum pump stroke (At idle)	—	0.012 in. (0.30 mm.)	0.014 in. (0.35 mm.)
	Maximum pump stroke (At full throttle)	—	0.065 in. (1.65 mm.)	0.071 in. (1.80 mm.)
	MAGNETO/IGNITION: Ignition source coil resistance	1.5Ω.	—	—

133	Secondary ignition coil resistance (Primary)	1.02Ω.	—	—
133	Secondary ignition coil resistance (Secondary)	6.0KΩ.	—	—
37 ~ 39	Ignition timing	B.T.D.C. 0.071 in. (1.8 mm.)	—	—
39 • 80	Ignition point gap		0.012 in. (0.3 mm.)	0.016 in. (0.4 mm.)
135•136	Condenser capacity	0.3μF		
ENGINE — TOP END:				
69	Cylinder taper	0.0034 in. (0.008 mm.)	—	0.002 in. (0.05 mm.)
69	Cylinder out of round	—	—	0.0002 in. (0.005 mm.)
73	Piston clearance	—	0.014 in. (0.035 mm.)	0.0016 in. (0.040 mm.)
70	Top ring end gap (Free)	Approximately 0.3 in. (7.5 mm.)	—	—
71	Top ring end gap (Installed)	—	0.006 in. (0.15 mm.)	0.014 in. (0.35 mm.)
70	2nd ring end gap (Free)	Approximately 0.16 in. (14 mm.)	—	—
71	2nd ring end gap (Installed)	—	0.006 in. (0.15 mm.)	0.014 in. (0.35 mm.)

71	Ring/ring groove clearance	—	0.001 in. (0.03 mm.)	0.003 in. (0.08 mm.)
76	Connecting rod axial play	—	0.03 in. (0.8 mm.)	0.08 in. (2.0 mm.)
76	Connecting rod/crank web clearance	—	0.016 in. (0.4 mm.)	0.020 in. (0.5 mm.)
77	Compression pressure	5.5 kgs/cm. ² (650 ~ 700 r.p.m.)	—	—
ENGINE — CLUTCH:				
88	Friction plate thickness	0.14 in. (3.5 mm.)	0.126 in. (3.2 mm.)	—
88	Clutch plate warp allowance	—	—	0.002 in. (0.05 mm.)
91	Spring free length	1.24 ins. (31.5 mm.)	1.2 ins. (30.5 mm.)	—
92	Spring set length difference	—	—	0.04 in. (1 mm.)
91	Primary driven gear (Clutch Hsg.) end play	0.006 in. (0.15 mm.)	0.004 in. (0.10 mm.)	0.012 in. (0.30 mm.)
CHASSIS:				
109	Front brake shoe diameter	3.74 ins. (95 mm.)	3.54 ins. (90 mm.)	—
113	Rear brake shoe diameter	4.33 ins. (110 mm.)	4.13 ins. (105 mm.)	—
115	Wheel run-out limits, vertical	—	—	0.08 in. (2 mm.)

115	Wheel run-out limits, lateral	—	0.08 in. (2 mm.)
—	Front fork spring free length	11.9 ins. (302.5 mm.)	—
—	Rear shock spring free length	8.43 ins. (214 mm.)	—
TORQUE VALUES:			
20	Transmission drain plug	3.5 ~ 4.0 m-kgs.	—
120	Front fork cap bolt	3.5 ~ 4.0 m-kgs.	—
—	Front axle securing nut	3.5 ~ 4.0 m-kgs.	—
29	Rear axle securing nut	4.0 ~ 4.5 m-kgs.	—
69	Cylinder head nut	1.0 m-kg.	—
81	Flywheel securing nut	3.5 ~ 4.0 m-kgs.	—
90	Clutch securing nut	4.0 ~ 4.5 m-kgs.	—
100	Drive sprocket securing nut	4.0 ~ 4.5 m-kgs.	—
100	Driven sprocket securing bolt(s)	2.0 m-kgs.	—

IV. NOMENCLATURE



1. Front brake lever
2. Rear brake pedal
3. Clutch lever
4. Throttle
5. Kick crank
6. Kill button
7. Frame serial number
8. Engine serial number

Fig. 5

- 9. Fuel petcock
- 10. Starter jet
- 11. Shift lever
- 12. Oil tank





Fig. 6

V. BASIC INSTRUCTIONS

A. CONTROL FUNCTIONS

1. Kill switch

The kill switch is the positive type. Push the switch forward for ignition off. Pull the switch toward you for ignition on.



1. Kill switch


Fig. 7

2. Autolube tank

The Autolube tank is located below the left side of the seat. A window is situated at the lower portion of the tank to provide an indication.

When oil level decreases within the tank, add oil. (See Autolube section for filling instructions.)

www.legends-yamaha-enduros.com



1. Autolube tank

Fig. 8

3. Fuel tank and petcock


The fuel tank incorporates a threaded plastic filler cap. The cap has a vent tube which is routed to the front of the tank and down alongside the frame down tube.

The fuel tank petcock is situated to the left side of the fuel tank. Turn the petcock lever to the vertical position and fuel will flow to the carburetor. Turn lever to the horizontal position to shut off fuel supply to the carburetor.



Fig. 9

www.legends-yamaha-enduros.com



- 1. Stop
- 2. Stop
- 3. On

Fig. 10

4. Front brake lever

Located on the right handlebar. The front brake lever actuates the single leading-shoe front brake when brake lever is squeezed.





Fig. 11

5. Rear brake pedal

Located directly in front of the right-hand rider's footrest. The rear brake pedal actuates the single leading-shoe rear brake when the pedal is depressed.

www.legends-yamaha-enduros.com



1. Footrest

2. Brake pedal

Fig. 12

6. Clutch lever

Located on the left handlebar. The clutch lever will disengage the clutch when the lever is squeezed




Fig. 13

7. Throttle

The throttle is the positive-return type, and is located on the right handlebar.

www.legends-yamaha-enduros.com





Fig. 14

8. Kick crank


The kick starter crank is located on the right, rear side of the engine. Set up the right footrest. Rotate the crank lever out, press your foot upon it firmly, push down until the gears engage the primary drive train and kick briskly to start the engine.



1. Footrest

Fig. 15

www.legends-yamaha-enduros.com



1. Kick crank

Fig. 16

9. Shift lever

The transmission shift lever is located on the left-hand side of the machine directly in front of the rider's footrest. The shift mechanism is of the ratcheting type and controls gear selection for the 4-speed transmission.

1. Reduction
2. Neutral
3. First
4. Second
5. Third
6. Fourth
7. Acceleration




Fig. 17

10. Carburetor starter jet

The carburetor starter jet is located on the left side of the carburetor assembly. The jet is designed to supply an extra rich fuel/air mixture for cold engine starts. It is actuated by a lever. Push the lever down to turn the jet on. Always disengage the lever after the engine is running smoothly. Never ride the machine with the lever down.

www.legends-yamaha-enduros.com




Fig. 18

11. Drive chain tensioner

The drive chain tensioner is located on the underside of the drive chain midway between the drive and driven sprockets.

The tensioner is designed to remove small amounts of excessive chain slack, thereby reducing the "lurch" caused by rapid throttle changes.

B. GASOLINE AND OIL

1. Gasoline

Use gasoline with an octane rating of 86+.


Some regular gasolines and most midrange gasolines have such ratings. High-test or Ethyl grade gasolines usually have octane ratings in excess of 94.

Always use fresh, name-brand gasoline.

Low-lead or unleaded gasolines are suitable provided they meet the minimum (86+) octane requirements.

Caution:

With the Autolube feature it is unnecessary and even harmful to the engine to mix oil with the gasoline. Never mix oil with the gasoline. Always use straight gasoline.



1. Chain tensioner

Fig. 19

2. Oil

a. Autolube oil

We recommend that your first choice be Yamalube which can be purchased from any Authorized Yamaha Dealer. If for any reason you should use another type, the oil should meet or exceed BIA certification "TC-W". Check container top or label for service specification.

Caution:

Under extremely cold conditions (+32 degrees Fahrenheit or below) some oils become very thick and will not flow as readily to the Autolube pump. This may cause oil pump starvation. Yamalube will flow normally to the pump at ambient temperatures to zero degrees Fahrenheit.

3. Autolube tank

Always check Autolube tank oil level before operating machine.

- a. Remove seat.
- b. Remove cap.
- c. Top off tank. Re-install cap and seat.




Fig. 20




Fig. 21

4. Transmission

To check level, start the engine and let it run for several minutes to warm and distribute oil. Clean the dip stick. Set it on the case threads in a level position. Remove and check level.

Note:

Be sure the machine is level and on both wheels.

The stick has Minimum and Maximum level marks.

The oil level should be between the two. Top off as required.




Fig. 22

Recommended oil: Yamalube 4-cycle

A drain bolt is located on the bottom of the crankcase. With the engine warm, remove the plug and drain oil. Re-install plug and add fresh oil.

Transmission drain plug torque:
300 ~ 350 in-lbs. (3.5 ~ 4.0 m-kgs.)

Transmission oil quantity: 500 c.c. (0.53 U.S.qt.)

Transmission oil should be replaced several times during the break-in period. If the unit is used for competition, oil replacement should also be often.

See Maintenance Chapter.

Caution:

Under no circumstances any additives should be included with the transmission oil. This oil also lubricates and cools the clutch. Many additives will cause severe clutch slippage.

VI. OPERATION

Caution:

1. Before riding this motorcycle, become thoroughly familiar with all operating controls and their function. Consult your Yamaha dealer regarding any control or function you do not thoroughly understand.
2. This model is designed for competition use only. It is not equipped with government approved lighting, mirrors, horn or directional signals. In most instances, it is illegal to ride this model (either day or night) on any public street or highway.

www.legends-yamaha-enduros.com

Preoperation check list

Item	Routine	Page
Brakes	Check operation/adjustment	26
Clutch	Check operation/lever adjustment	28
Aubolube tank	Check oil level/top-off as required	32
Transmission	Check oil level/top-off as required	19
Drive chain	Check alignment/adjustment/lubrication	29
Spark plug	After break-in-check color/condition weekly/500 mi.	35 • 36
Throttle	Check for proper cable operation (incl. Autolube cable)	—
Air filter	Foam type — must be always clean and damp with oil	49 • 50
Wheels and tires	Check pressure/runout/spoke tightness/axle nuts	
Fittings/fasteners	Check all — tighten as necessary	

Pre-operation checks should be made each time the machine is used. Such an inspection can be thoroughly accomplished in a very short time; and the added safety it assures is more than worth the time involved.

A. STARTING AND OPERATION

Caution:

Prior to operating the machine, perform steps listed in preoperation check list.

Turn fuel petcock lever to open (vertical) position. Check ignition kill switch. Kill switch must be on "RUN" position to complete ignition circuit.

1. Starting cold

Depress the starter lever. Keep the throttle completely closed. Engage the kick starter and start the engine.

2. Starting with engine warm

Do not engage starter lever. Open throttle slightly (1/4 turn). Engage the kick starter and start the engine.

3. Warm-up

Run the engine at idle or between idle and 1/8 throttle using the starter lever as required until the engine is warm.

This procedure normally takes 2 to 3 minutes. To check, see if the engine responds normally to throttle with starter lever off.

Caution:

See "Break-in" section prior to operating engine for the first time.

The kick mechanism is of the primary type.

Therefore, the engine may be started in any gear provided clutch is disengaged. The engine may be started in neutral with clutch engag-



Fig. 23




Fig. 24

ed or disengaged.


A 4-speed transmission is employed. Neutral is at the bottom of the shift pattern; there is the high gear at the top of the shift pattern. The shift mechanism is of the ratcheting type common to most motorcycles. Allow the lever to return to its "at rest" position prior to selecting another gear. Neutral is selected by shifting "down" to the bottom of the pattern.

With the engine running in the neutral position, disengage the clutch (pull in clutch lever), pull up on the shift lever until first gear is engaged, remove your foot from shift lever, increase engine speed slightly, slowly release clutch lever while advancing throttle. Repeat procedure for remaining gears.

Except during competition, shift the transmission when engine speed is approximately 3,000 to 4,000 r.p.m. This can be interpreted as approximately one-half throttle. (See "Break-in")

Note:

Model TY80B is not equipped with highway-approved lighting. This model is designed solely for competition use and should not be used on streets or highways at any time. In most instances, it is illegal to drive this model on any public streets or highways.



1. Shift lever
2. Footrest

Fig. 25

B. BREAK-IN

You must not put an excessive load on the engine during the first ten to twenty hours of operation. If speedometer mileage is maintained, use the following break-in procedure:

0 to 50 miles (3 Hrs.)

Avoid operation above one half throttle.

50 to 100 miles (3 ~ 6 Hrs.)

Avoid full throttle operation. Allow the motorcycle to rev freely through the gears but do not use full throttle at any time.

100 to 250 miles (6 ~ 15 Hrs.)

Avoid prolonged full throttle operation.

Avoid cruising speeds in excess of one half throttle. Vary speeds occasionally.

250 miles and beyond (15 Hrs.)

Avoid full throttle operation.

www.legends-yamaha-enduros.com

VII. MECHANICAL ADJUSTMENTS


A. BRAKES

1. Front brake

Front brake should be adjusted to suit rider preference with a minimum cable slack of 0.20 ~ 0.32 in. (5 ~ 8 mm.) play at the brake lever pivot point.


Adjustment is accomplished at one of two places; either the handle lever holder or the front wheel hub.

- a. Loosen the adjustor locknut.
- b. Turn the cable length adjustor in or out until adjustment is suitable.
- c. Tighten the adjusting bolt locknut.



1. 5 ~ 8 mm.

Fig. 26



1. Adjusting bolt 2. Locknut

Fig. 27


2. Rear brake

Adjust rear brake pedal play to suit, providing a minimum of 0.98 in. (25 mm.) free play. Adjustment is accomplished as follows:

- a. Using a 0.51 in. (13 mm.) wrench, turn the adjusting nut on the rear brake ferrule in or out until brake pedal free play is suitable (0.98 in. or 25 mm. minimum free play).


Note:

Rear brake pedal adjustment must be checked whenever chain is adjusted or rear wheel is removed and reinstalled.



1. Adjusting nut

Fig. 28



1. 0.98 in. (25 mm.)

Fig. 29

B. CLUTCH ADJUSTMENT

Proper clutch adjustment requires two separate procedures.

- a. Loosen cable, adjust screw locknut.
- b. Turn clutch cable adjust screw (at lever) all the way into the lever.

Note:

The above procedure provides for maximum cable free play to allow for proper clutch actuating mechanism adjustment.

- c. Remove cover cap on left crankcase cover.
- d. Loosen adjustor locknut.
- e. Using a Phillips screwdriver, turn adjust screw in or out until clutch arm (located under the engine directly below the adjust screw), is directly in line with the main axle center line.
- f. Tighten locknut.
- g. At clutch lever assembly, left handlebar, turn cable length adjustor in or out until freeplay at lever pivot equals 0.08 ~ 0.12 in. (2 ~ 3 mm.)
- h. Tighten adjusting bolt locknut.
- i. Re-install cover cap.




Fig. 30




Fig. 31




Fig. 32

C. DRIVE CHAIN ADJUSTMENT

To adjust drive chain, proceed as follows:

- a. Remove rear axle cotter pin.
- b. Loosen rear axle securing nut.
- c. With rider in position on machine, both wheels on ground, set axle adjusters until there is $3/4$ to 1 inch slack in the drive chain at the bottom of the chain at a point midway between the drive and driven axles.
- d. Turn cam adjusters both left and right until axle is situated in same cam slot position.
- e. Tighten the rear axle securing nut. Rear axle tightening torque equals:

Axle nut torque: 350 ~ 400 in-lbs. (4.0 ~ 4.5 m-kgs.)

- f. Install a new cotter pin, bend the ends.
- g. Check brake pedal free play.

Caution:

Whenever the chain is adjusted and/or the rear wheel is removed, always check during reassembly:

1. Rear axle alignment
2. Brake pedal free play




Fig. 33




Fig. 34





Fig. 35

D. CARBURETOR

Under normal operating conditions, there are only three adjustments to be made to the carburetor.

1. Throttle cable adjustment

- a. Lift the rubber mixing chamber cap cover from the top of the carburetor.
- b. Grasp outer cable housing. Lift up. Slack should equal 0.04 in. (1 mm.). If slack is incorrect, loosen adjusting bolt locknut and turn adjusting bolt in or out as required to achieve correct slack. Tighten adjusting bolt locknut. Reinstall cap cover.
- c. Grasp throttle cable housing at throttle assembly on right handlebar. Pull out. Slack should equal 0.04 in. (1 mm.). If not, loosen cable length adjuster locknut and adjust cable length accordingly.
- d. Tighten adjuster locknut.



2. Idle speed and idle air adjustments

- a. Turn idle air screw in until lightly seated.
- b. Back out 1-1/2 turns.
- c. Turn idle speed adjust screw until idle is approximately 1,250 to 1,350 r.p.m.

Pilot air screw: 1-1/2 turns out
Idle speed: 1,250 ~ 1,350 r.p.m.

Note:

Idle air mixture and idle speed adjustment screws should be so adjusted that engine response to throttle changes from idle position is rapid and without hesitation.

If the engine, when warm, hesitates or "bags", after adjusting as described, turn idle air mixture screw in or out in 1/4 turn increments until bogging problem decreases.

Readjust idle speed, recheck throttle cable slack.




Fig. 36




Fig. 37

E. ADJUSTING AUTOLUBE

1. Cable adjustment

- a. Remove Autolube pump cover, which is located on forward portion of right-hand crankcase cover.
- b. Rotate throttle until slack is removed from all cables. Hold this position.




Fig. 38

www.legends-yamaha-enduros.com





Fig. 39

- c. Check to see that Autolube pump plunger pin is aligned with the mark on the Autolube pump pulley.
- d. If the mark and pin are not in alignment, loosen cable length adjuster lock nut on upper edge of crankcase cover and adjust cable length until alignment is achieved. Tighten adjuster locknut.



1. Align the guide pin with the marking

Fig. 40

www.legends-yamaha-enduros.com

- 1. Pump cable
- 2. Cable adjusting nut
- 3. Lock nut
- 4. Adjust pulley guide pin
- 5. Bleeder bolt
- 6. Starter plate
- 7. Marking
- 8. Adjust pulley




Fig. 41

2. Pump stroke adjustment

Note:

Autolube pump stroke adjustment requires a special tool. This tool, Autolube Pump Feeler Gauge, may be purchased from your Authorized Yamaha Dealer.

- a. Rotate plastic bleed wheel until the pump plunger moves fully out and away from the pump body to its outermost limit.





Fig. 42

- b. Measure gap between raised boss on pump cable pulley and pump stopper plate. Clearance should equal 0.012 ~ 0.01 in. (0.30 ~ 0.25 mm.). If clearance is incorrect, remove adjust plate locknut and adjust plate.

Minimum pump stroke:

0.012 ~ 0.014 in. (0.30 ~ 0.35 mm.)



- | | |
|-------------------------|-----------------|
| 1. Adjust pulley | 4. Starter |
| 2. Adjust plate | 5. Feeler gauge |
| 3. Adjust plate locknut | |

Fig. 43

- c. Remove or add an adjustment shim as required.
- d. Reinstall adjust plate and locknut. Tighten the locknut. Re-measure gap. Repeat procedure as required.

F. SPARK PLUG

The spark plug in your machine indicates how the engine is operating. If the engine is operating correctly, and the machine is being ridden correctly, then the tip of the white insulator around the positive electrode of the spark plug will be a medium to light tan color. If the porcelain "donut" around the positive electrode is a very dark brown or black color, then a hotter type plug might be required. This situation is quite common during the engine break-in period. If the insulator tip shows a very light tan or white color or is actually pure white or if electrodes show signs of melting, then a colder type spark plug is required.

Remember, the insulator area surrounding the positive electrode of the spark plug must be a medium-to-light tan color. If it is not, check carburetion, timing and ignition adjustments. If the situation persists, consult your Authorized Yamaha Dealer.

Your machine is equipped with a relatively hot spark plug to insure clean, smooth low speed operation. If the machine is to be operated at higher r.p.m. ranges for extended periods, install the next colder spark plug.




Fig. 44




Fig. 45

The spark plug must be removed and checked prior to using the machine. Check electrode wear, insulator color, and negative to positive electrode gap.

Spark plug gap: 0.20 ~ 0.24 in. (0.5 ~ 0.6 mm.)

It is alright for you, as the owner, to exchange the standard plug. Engine conditions will cause any spark plug to slowly break down and erode. If erosion begins to increase, or if the electrodes finally become too worn, or if for any reason you believe the spark plug is not functioning correctly, replace it.

Standard spark plug: B-6HS www.yamaha-enduros.com

When installing the plug, always clean the gasket surface, use a new gasket, wipe off any grime that might be present on the surface of the spark plug, torque the spark plug properly.

Spark plug tightening torque:
230 ~ 250 in-lbs. (2.7 ~ 2.9 m-kgs.)

G. IGNITION TIMING

Ignition timing must be set with a dial indicator (to determine piston position) and a low-range ohm-meter (to determine exactly when contact breaker points begin to open). Proceed as follows:

- a. Remove spark plug and screw Dial Gauge Stand into spark plug hole.
- b. Insert Dial Gauge Assembly into spark plug stand.
- c. Remove left crankcase cover to gain access to contact breaker assembly (ignition points).
- d. Connect red lead of Point Checker to black wire in wire harness coming from magneto.
- e. Connect black lead of Point Checker to unpainted surface of cylinder fin or crankcase bolt or screw.
- f. Rotate magneto flywheel until piston is at top-dead-center (T.D.C.). Tighten set screw on dial gauge stand to secure dial gauge assembly. Set the zero on dial indicator face to line up exactly with dial indicator needle. Rotate flywheel back and forth to be sure that indicator needle does not go past zero.
- g. Starting at T.D.C. rotate flywheel clockwise until dial indicator reads approximately 0.07 in. (1.8 mm.) before top-dead-center (B.T.D.C.).




Fig. 46

- h. Slowly turn flywheel counterclockwise until gauge indicates correct timing figure. At this time, the ohmmeter needle should swing from "CLOSED" to "OPEN" position, indicating the contact breaker points have just begun to open.

Ignition timing: 0.07 in. (1.8 mm) B.T.D.C.




Fig. 47

- i. Repeat step H to verify point opening position. If points do not open within specified tolerance, they must be adjusted.
- j. Adjust ignition points by barely loosening Phillips head screw and carefully rotating contact breaker assembly with a slotted screwdriver until point checker indicates points "OPEN". Retighten Phillips head screw. Repeat steps F thru H.




Fig. 48

k. When correct ignition timing has been accomplished, check maximum point gap by turning flywheel until maximum point opening occurs. Measure point gap with thickness gauge.

Maximum allowable point gap:
0.012 ~ 0.016 in. (0.3 ~ 0.4 mm.)




Fig. 49

Note:

If the maximum point gap is over tolerance the point rubbing block is probably worn and the contact breaker assembly should be replaced. Do not attempt to bend the fixed point bracket to decrease maximum point gap. This will only result in point misalignment, difficulty in setting timing and premature point failure. See "Magneto Flywheel Removal" for point replacement procedure.

l. Remove dial gauge assembly and dial gauge stand. Replace spark plug.

Spark plug torque: 230 ~ 250 in-lbs. (2.7 ~ 2.9 m-kgs.)

m. Disconnect point checker.

n. Replace crankcase cover (L).

VIII. MAINTENANCE AND MINOR REPAIRS

The following sections provide information for the disassembly, troubleshooting and maintenance of various components of the motorcycle. If you do not have the necessary tools and an understanding of the mechanical principles involved, please refrain from attempting repairs. The use of improper tools and/or procedures can cause major damage to the unit with resultant additional repair costs.

To properly understand the procedures outlined we suggest you consult the GT80B Service Manual (1975) and the various other technical publications produced by Yamaha Motor Company or Yamaha International Corporation.

Finally, we suggest you consult your Yamaha Dealer prior to attempting any repair procedures. This is particularly important during the first ninety days the machine is in use.

www.legends-yamaha-enduros.com

PERIODIC MAINTENANCE INTERVALS

Page	Item	Remarks	Initial (miles)		Thereafter every (miles)	
			250	500	500	1,000
26, 109, 113	* Brake system (complete)	Check/adjust as required—repair as required	○		○	
28, 88	* Clutch	Check/adjust as required	○		○	
35	* Spark plug	Inspect/clean or replace as required	○	○	○	
114	* Wheels and tires	Pressure/spoke tension/run-out	○	○	○	
8, 46	* Fittings and fasteners	Tighten before each trip and/or	○	○	○	
30, 105	* Throttle	Cable operation/adjustment (incl. Autolube)	○	○		○
29, 101	* Drive chain	Tension/alignment	○	○	○	
19	* Transmission oil level check	Includes trans./Autolube tank (See Note 1)	○	○	○	
49	* Air filter	Foam type (See Service Notes 2 and 4)	○	○		○
—	Fuel petcock	Clean/flush tank as required	○	○		○
37	Ignition timing	Adjust/clean/replace points as required		○		○
30	Carburetor adjustment	Check operation/synchronization/fittings		○		○
52	Carburetor overhaul	Clean/repair as required/refit/adjust		○		○
77	Cylinder compression	Preventive maintenance check		○		○
68, 72	Decarbonize engine	Includes exhaust system		○		○

* Indicates preoperational check items.

Service notes:

1. Check Autolube tank level before each ride. Top off when oil level shows at the sight glass or before any prolonged use. See "Lubrication Intervals" for type of oil to use.
2. Foam element air filters must be damp with oil at all times to function properly. Remove, clean, and oil filter at least once per month or every 250 ~ 500 miles; whichever occurs first. (If extremely hard usage, such as dirt riding, clean and lube daily.) See "Lubrication Intervals" for additional details.
3. Preoperational checks should be made each time the machine is used. Such an inspection can be thoroughly accomplished in a very short time, and the added safety it assures the rider is more than worth the minimal time involved.
4. For additional information regarding drive chain, engine oil level, wet-type air filter, see "Lubrication Intervals".

LUBRICATION INTERVALS

Item	Remarks	Type	Period				
			Initial (miles)			Thereafter every (miles)	
			250	500	1,000	500	1,000
* Autolube	See Service Notes	No. 1	See Service Notes				
* Transmission oil	Warm engine before draining	No. 2	○	Check	○	Check	○
* Drive chain	Lube/adjust as required	No. 3	See Service Notes				
* Drive chain	Remove/clean/lube/adjust	No. 3		○		○	
* Air filter	Foam type	No. 9	See Service Notes				
Control and meter cables	Apply thoroughly	No. 4		○			○
Throttle grip and housing	Light application	No. 5		○			○
Rear arm pivot shaft	Apply until shows	No. 6			○		○
Brake pedal shaft	Light application	No. 5			○		○
Change pedal shaft	Light application	No. 5			○		○
Front forks	Drain completely-Check Specs	No. 3		Check	○		○
Steering ball races	Inspect thoroughly/Med. pack	No. 7			○		○
Point cam lubr. wick	Very light application	No. 8			○		○
Wheel bearings	Do not over-pack	No. 7			○		○

* Indicates preoperational check items.

- No. 1 Check tank level before each ride. Top off when oil level is at sight glass or before any prolonged use. Use the following lubricant (in order of preference):
Yamalube 2-cycle, or; two-stroke oil labeled "BIA certified for service TC-W"
- No. 2 At ambient temperatures of 45 ~ 90°F, use Yamalube 4-cycle. Do not use "additives" in oil.
- No. 3 Use 10W/30 "SE" motor oils. (If desired, specialty type lubricants of quality manufacture may be used.)
"Drive Chains" — Lube every 150 ~ 200 miles. If severe usage, every 50 ~ 100 miles or after every event.
- No. 4 Use graphite base type (specialty types available use name-brand, quality manufacturer).
- No. 5 Light duty: smooth, light-weight, "white" grease. Heavy duty: standard 90wt lube grease (do not use lube grease on throttle/housing).
- No. 6 Use standard 90 wt. lube grease — smooth, not coarse.
- No. 7 Medium-weight wheel bearing grease of quality manufacturer — preferably waterproof.
- No. 8 Light-weight machine oil. www.legends-yamaha-enduros.com
- No. 9 Air filters — foam element air filters must be damp with oil at all times to function properly. Clean and lube monthly or per mileage. If hard usage, clean and lube daily. Do not over-oil. Use SAE 10W/30 "SE".

A. MAINTENANCE AND LUBRICATION INTERVALS

These charts should be considered strictly as a guide to general maintenance and lubrication intervals. You must take into consideration that weather, terrain, geographical locations, and a variety of individual uses all tend to demand that each owner alter this time schedule to match his environment. For example, if the motorcycle is continually operated in an area of high humidity, then all parts must be lubricated much more frequently than shown on the chart to avoid the damage caused by rust to metal parts. If you are in doubt as to how closely you can follow these time recommendations, check with the YAMAHA dealer in your area.

B. COMPETITION

The serious competitor will no doubt already have a maintenance and lubrication schedule of his own. However, until one can be established according to individual usage, we suggest the following:

1. Cut the mileage recommendations by one-half. If no speedometer, estimate 10 ~ 15 mph average speed.
2. Immediately preceding each competition, pay particular attention to the following:
 - a. A thorough preoperational check.
 - b. Clean and lubricate air filter.
 - c. Lubricate all controls, cables and rear arm pivot.
3. Every other competition, perform the steps outlined in No. 2, and:
 - a. Disassemble top end and inspect.
 - b. Replace piston rings.
 - c. Decarbonize as required.
 - d. Service carburetor.
 - e. Replace transmission oil.
 - f. Check front fork operation and steering adjustment.
 - g. Remove chain; clean, oil and re-install.

- h. Remove wheel assemblies and service brakes.
- i. Check rear shock and swing arm operation.
- j. Adjust Autolube pump stroke and cable.

C. TORQUE SPECIFICATIONS

The list below covers those stud/bolt sizes with standard I.S.O. pitch threads. Torque specifications for components with thread pitches other than standard are given within the applicable chapter. Torque specifications call for dry, clean threads. Components such as the cylinder or cylinder head should be at room temperature prior to torquing. A cylinder head or any other item with several fasteners should be torqued down in a criss-cross pattern in successive stages until torque specification is reached. The method is similar to installing an automobile wheel and will avoid warping the component.

www.legends-yamaha-enduros.com

A (Nut)	B (Bolt)	Torque Specifications		
		m-kgs.	ft-lbs.	in-lbs.
0.34 in. (10 mm.)	0.24 in. (6 mm.)	1.0	7.2	85
0.51 in. (13 mm.)	0.31 in. (8 mm.)	2.0	15	175
0.55 in. (14 mm.)	0.31 in. (8 mm.)	2.0	15	175
0.67 in. (17 mm.)	0.39 in. (10 mm.)	3.5 ~ 4.0	25 ~ 29	300 ~ 350
0.75 in. (19 mm.)	0.47 in. (12 mm.)	4.0 ~ 4.5	29 ~ 33	350 ~ 400
0.87 in. (22 mm.)	0.55 in. (14 mm.)	4.5 ~ 5.0	33 ~ 36	400 ~ 440
1.02 ins. (26 mm.)	0.67 in. (17 mm.)	5.8 ~ 7.0	42 ~ 50	500 ~ 600
1.05 ins. (27 mm.)	0.71 in. (18 mm.)	5.8 ~ 7.0	42 ~ 50	500 ~ 600
1.18 ins. (30 mm.)	0.78 in. (20 mm.)	7.0 ~ 8.3	50 ~ 60	600 ~ 700
Spark plug		2.7 ~ 2.9	19 ~ 21	230 ~ 250




Fig. 50

D. TOOLS

The maintenance procedures outlined within this manual require additional special tools and instruments. A comprehensive list of the special tools is given below. For your convenience, we have also included a list of additional recommended hand tools and supplies.

1. Special tools and instruments

- | | | |
|---|----------------------------|-----------------------|
| 1. Autolube feeler gauge | 4. Magneto flywheel puller | 8. Outside micrometer |
| 2. Vernier calipers | 5. Dial gauge | 9. Cylinder gauge |
| 3. Clutch holding tool
Parts No. (90890-01023) | 6. Dial gauge stand | 10. Torque wrench |
| | 7. Point checker | 11. Feeler gauge set |




Fig. 51

2. General tools and materials

1. TY80B gasket kit
2. Socket wrench set
3. Combination wrench set
4. Selection of Phillips and standard screwdrivers
5. Circlip pliers (outside)
6. Soft faced hammer
7. Steel hammer
8. Selection of pliers and wire cutters
9. Several parts trays and shop rags




Fig. 52

E. AIR FILTER

a. Remove the lefthand side cover.



Fig. 53

b. Remove the Phillips head screw holding the air filter case cover in place. Remove the cover.

www.legends-yamaha-enduros.com



Fig. 54

c. Remove the air filter element.




Fig. 55

- d. Slip the element out of the wire mesh guide.
- e. Wash the element gently, but thoroughly, in solvent.
- f. Squeeze excess solvent out of element and dry.
- g. Pour a small quantity of motor oil onto filter element and work thoroughly into the porous foam material.

Note:

In order to function properly, the element must be damp with oil at all times.....but not "dripping" with oil.

- h. Re-insert element into the wire mesh filter guide.
- i. Coat the ends of the filter element with 90 wt. lube grease. This will provide an air-tight seal between the filter case cover and filter seat.
- j. Re-install the element, case cover and seat.

Note:

Each time filter element maintenance is performed, check the air inlet to the filter case for obstructions. Check the air cleaner joint rubber to the carburetor and manifold fittings for an air-tight seal. Tighten all fittings thoroughly to avoid the possibility of unfiltered air entering the engine.

Caution:

Never operate the engine with the air filter element removed. This will allow unfiltered air to enter causing rapid wear and possible engine damage. Additionally, operation without the filter element will affect carburetor jetting with subsequent poor performance and possible engine over-heating.




Fig. 56




Fig. 57

F. CARBURETOR




Fig. 58

1. Removal and installation

- a. Turn fuel petcock lever to the "STOP" position.
- b. Remove the gasoline tank fuel line from fitting at carburetor.
- c. Loosen the carburetor body fitting screw and inlet joint band (hose clamp).

Note:

For carburetor main jet replacement only, follow steps 1 through 3; then:

1. Remove carburetor.
2. Remove four (4) screws that secure float chamber body. Remove float chamber body.
3. Main jet screw into main nozzle body. Remove main jet. Change as required. Re-install float chamber body and reassemble, reversing steps 1 through 3.

Main jet: #86

Caution:

Removing the float chamber body will allow fuel to drain. Do not remove if engine is hot. Place a rag under carburetor to catch overflow. Remove float chamber body in well-ventilated area. Do not remove near open flame. Always clean and dry machine after reassembly.




Fig. 59




Fig. 60




Fig. 61 -

d. Push the air cleaner joint (hose) off the carburetor inlet.




Fig. 62

e. Rotating the carburetor body, work it off the cylinder manifold joint.

f. Noting the presence, location and routing of all vent and overflow tubes, pull the carburetor toward you.




Fig. 63

- g. Unscrew the mixing chamber top. Remove the slide and needle assembly.



Fig. 64

www.legends-yamaha-enduros.com




Fig. 65

- h. Remove the Phillips screws (4) holding float bowl to body. With carburetor in upright position, remove float chamber body. Drain gasoline from float chamber body into suitable container.




Fig. 66

- i. Invert carburetor body and inspect float. Note its installation position.



Fig. 67

- j. Remove float pivot pin and float. If fuel has entered a float, or if the float is damaged in any fashion, replace.

www.legends-yamaha-enduros.com



Fig. 68

- k. Remove the inlet needle directly beneath the float arm tang. Inspect the needle and seat for signs of excessive wear or attached foreign particles. Replace as required. Always replace inlet needle and inlet valve seat as an assembly.




Fig. 69

I. Remove, in order, the following components:

1) Main jet




Fig. 70

2) Pilot jet

www.legends-yamaha-enduros.com




Fig. 71

3) Main nozzle

4) Throttle screw (idle speed screw)

5) Air adjusting screw (idle mixture screw)




Fig. 72

- m. Push down on the starter jet lever to open the circuit.
- n. Wash the carburetor in mild petroleum base solvent. Wash all associated parts.
- o. Using high pressure air, blow out all passages and jets.

Note:

Never direct high pressure air into carburetor with float chamber body installed. Damage to floats may occur.

- p. Re-install all components with the exception of the float chamber body.
- q. Using a vernier caliper, measure the distance from the bottom of the float to the float chamber gasket surface (gasket removed).

Float level: 0.9 in. (23 mm.) ± 0.05

Note:

Hold the float so that tang is just resting on, but not depressing the spring loaded inlet needle.

To correct float height, remove the assembly and bend the tang a slight amount as required. Both the right and left float sides should measure identically. Correct as required.

- r. Install the float chamber body.
- s. Moving the machine, push needle out of seat in throttle valve (slide). Inspect for signs of bending, scratches or wear. Replace if damaged.




Fig. 73




Fig. 74

- t. Check needle clip position. Clip position is counted starting with the first clip groove at the top of the needle.

Jet needle type:	049-2
Clip position:	2

- u. Check throttle valve (slide) for signs of wear. Insert into carburetor body and check for free movement. If slide, or body is out of round causing slide to stick, replace as required.
- v. Install throttle valve and needle assembly in carburetor mixing chamber. Tighten mixing chamber top as tight as possible by hand. Do not use pliers or vice-grips as they may deform the mixing chamber shape, causing the throttle valve to stick during operation.
- w. Push down mixing chamber top cover and install all overflow and vent tubes. Re-install carburetor. Check position and routing of all tubes. Check tightness of all fittings. Make sure carburetor is mounted in a level position.
- x. After installation, re-adjust throttle cable and Autolube pump cable per directions in "Mechanical Adjustments".

2. Troubleshooting

A trials machine requires immediate, predictable throttle response over a wide operating range.

Cylinder porting, combustion chamber compression, ignition timing, muffler design, and carburetor size and component selection are all balanced to achieve this goal. However, variations in temperature, humidity and altitude, to name a few, will affect carburetion and consequently, engine performance.

The following list gives each of the major components of the TY80B carburetor that can be readily changed in order to modify carburetor performance if required. If you are unfamiliar with carburetor theory, we suggest you refrain from making changes. Quite often, a performance problem is caused by another related component, such as the exhaust system, ignition timing or combustion chamber compression.

Note:

See "Mechanical Adjustments" for additional carburetor adjustments.

3. Idle air mixture screw

Controls the ratio of air to fuel in the idle circuit. Turning the screw in decreases the air supply giving a richer mixture. Normally, for trials competition, the idle mixture screw is backed out to a lean position.
OPERATING RANGE MOST AFFECTED BY THIS ADJUSTMENT:
ZERO TO 1/8 THROTTLE.

4. Pilot jet

Controls the ratio of fuel to air in the idle circuit. Changing the jet to one with a higher number supplies more fuel to the circuit giving a richer mixture.

OPERATING RANGE MOST AFFECTED BY THIS JET: ZERO TO 1/8 THROTTLE.

5. Throttle valve (slide)

The throttle valve (slide) has a portion of the base cutaway to control air flowing over the main nozzle. A wider angle (more "cutaway") will create a leaner mixture. Throttle valves are numbered according to the angle of the cutaway. The higher the number, the more cutaway, the leaner the mixture.

OPERATING RANGE MOST AFFECTED BY THE THROTTLE VALVE: 1/8 TO 1/2 (+) THROTTLE.

6. Jet needle

The jet needle is fitted within the throttle valve. The tapered end of the needle fits into the main nozzle outlet. Raising the needle allows more fuel to flow out of the nozzle outlet giving a richer mixture. There are five circlip grooves at the top of the needle.

Moving the needle clip from the first, or top groove, through the fifth, or bottom groove, will give a correspondingly richer mixture.

OPERATING RANGE MOST AFFECTED BY THE JET NEEDLE: 1/8 TO 3/4 (+) THROTTLE.

7. Main jet

The main jet controls overall fuel flow through the main nozzle. Changing the jet to one with a higher number supplies more fuel to the main nozzle giving a richer mixture.

OPERATING RANGE MOST AFFECTED BY THE MAIN JET: 3/4 TO FULL THROTTLE.

Note:

Excessive changes in main jet size can affect overall performance.

Caution:

The fuel/air mixture ratio is a governing factor upon engine operating temperature. Any carburetor changes, whatsoever, must be followed by a thorough spark plug test.

www.legends-yamaha-enduros.com

G. REED VALVE

With carburetor removed, proceed as follows:

- a. Remove oil line from fitting on manifold.
- b. Remove the bolts (4) holding the intake manifold and reed valve assembly to cylinder.
Remove assembly.




Fig. 75




Fig. 76

c. Inspect reed pedals for signs of fatigue cracks.

Reed petals should fit flush or nearly flush against neoprene seat. If in doubt as to sealing ability, apply suction to carburetor side of assembly.

Leakage should be slight to moderate.




Fig. 77

d. If disassembly of the reed valve assembly is required, proceed as follows:

- 1). Remove Phillips screws (2) securing stopper plate and reed to reed block. Handle reed carefully. Avoid scratches and do not bend. Note from which side of the reed block the reed and stopper plate were removed. Re-install on same side.



Fig. 78

- 2) During reassembly, clean reed block, reed, and stopper plate thoroughly. Apply a holding agent, such as "Lock-Tite", to threads of Phillips screws. Tighten each screw gradually to avoid warping.

Tighten the screws thoroughly.

Note:

During reassembly, note the cut in the lower corner of the reed and stopper plate. Use as aid to direction of reed installation.

- e. During reassembly of the reed valve assembly and manifold, install new gaskets and torque the securing bolts gradually and in pattern. Tighten thoroughly.

www.legends-yamaha-enduros.com




Fig. 79




Fig. 80

H. TOP END AND MUFFLER

With the carburetor removed, proceed as follows:

1. Muffler and cylinder head removal

- a. Remove seat assembly.
- b. Remove securing bolt at rear of fuel tank.




Fig. 81

- c. Lift rear of fuel tank up and pull back to clear frame mounts.
- d. Remove bolt which secures rear of muffler to frame.

www.legends-yamaha-enduros.com




Fig. 82

- e. Using special ring nut wrench, remove ring nut holding muffler to cylinder. Remove muffler.




Fig. 83

- f. Remove spark plug lead wire. Loosen, but do not remove spark plug.




Fig. 84

www.legends-yamaha-enduros.com




Fig. 85

- g. Remove nuts (4) securing cylinder head to cylinder. Remove cylinder head and gasket.

Note:

Break each nut loose (1/4 turn) prior to removing.




Fig. 86

www.legends-yamaha-enduros.com




Fig. 87

2. Cylinder and piston removal

- a. With piston at Top Dead Center, raise cylinder until cylinder skirts clear crankcase. Stuff a clean shop rag into crankcase cavity, around rod, to prevent dirt and other foreign particles from entering. Remove cylinder.




Fig. 88

- b. Remove piston pin clip (1) from piston. Push piston pin out from opposite side. Remove piston.

www.legends-yamaha-enduros.com



Fig. 89




Fig. 90

3. Maintenance — muffler/spark arrester

- a. Using a rounded scraper, remove excess carbon deposits from manifold area of muffler. Check muffler gasket condition. The gasket seat is located around the cylinder exhaust port.
- b. Carbon deposits within the muffler may be removed by lightly tapping the outer shell with a hammer and then blowing out with compressed air. Heavy wire, such as a coat hanger, may be inserted to break loose deposits. Use care.
- c. Remove Phillips screw holding spark arrester in place. Remove spark arrester. Clean carbon from arrester assembly with scraper. Re-install.




Fig. 91

4. Maintenance — cylinder head

www.legends-yamaha-enduros.com

- a. Remove spark plug.
- b. Using a rounded scraper, remove carbon deposits from combustion chamber. Take care to avoid damaging the spark plug threads. Do not use a sharp instrument. Avoid scratching the material.
- c. Place cylinder head on a surface plate. There should be no warpage. Correct by re-surfacing. Place 400-600 grit wet sandpaper on surface plate and re-surface head using a figure-eight sanding pattern. Rotate head several times to avoid removing too much material from one side.
- d. Clean spark plug gasket from mating surface thoroughly.
- e. Wash cylinder head in solvent and wipe dry.




Fig. 92

- f. Install new cylinder head gasket during reassembly.

Cylinder head nut torque:
85 in-lbs. (1.0 m-kg.)

5. Maintenance — cylinder

- a. Using a rounded scraper, remove carbon deposits from exhaust port.
- b. Remove cylinder base gasket and clean gasket seat on cylinder and crankcase thoroughly.
- c. Check cylinder bore. Using a cylinder hone, remove any scoring. Hone lightly, using smooth stones. Hone not more than required to avoid excess piston clearance.
- d. Using a cylinder gauge set to standard bore size, measure the cylinder. Measure at six points; at top, center, and 1/2 in. from bottom of skirts, in line with the piston pin and at right angles to pin. Compare minimum and maximum measurements. If over tolerance, and not correctable by honing, re-bore to next over-size.

Max. allowable taper: 0.002 in. (0.05 mm.)
Max. allowable out-of-round: 0.0002 in. (0.005 mm.)

- e. Wash cylinder thoroughly with soap and water. Dry. Coat walls with light oil film immediately.
- f. During reassembly, always use a new cylinder base gasket.




Fig. 93




Fig. 94

6. Maintenance — piston rings

- a. Remove rings from piston. Remove ring expander from lower ring groove.
- b. Check rings for scoring. If any severe scratches are noticed, replace set.




Fig. 95

www.legends-yamaha-enduros.com




Fig. 96

- c. Measure ring end gap in free position. If beyond tolerance, replace set.

Top ring end gap, free	Approx. 0.3 in. (7.5 mm.)
Lower ring end gap, free	Approx. 0.16 in. (4 mm.)




Fig. 97

d. Insert each ring into cylinder. Push down approximately 3/4 in. using piston crown to maintain right-angle to bore. Measure installed end gap. If beyond tolerance, replace set.

	Min.	Max.
Top ring end gap, installed	0.006 in. (0.15 mm.)	0.014 in. (0.35 mm.)
2nd ring end gap, installed	0.006 in. (0.15 mm.)	0.014 in. (0.35 mm.)

e. Holding cylinder towards light, check for full seating of ring around bore. If not fully seated, check cylinder. If cylinder not out-of-round, replace the ring.

f. Check ring expander. If worn excessively, or broken, replace set.

g. With rings installed in grooves, insert feeler gauge between ring edge and groove. If beyond tolerance, replace ring and/or piston as required.

	Min.	Max.
2nd ring groove clearance	0.0012 in. (0.03 mm.)	0.0032 in. (0.08 mm.)



Fig. 98

- h. During installation, make sure ring ends are properly positioned on either side of locating pin in ring groove. Make sure ring expander is positioned in like manner. Apply a liberal coating of two-stroke oil to rings.
- i. New rings require break-in. Follow first portion of new machine break-in procedure.

7. Maintenance — piston

- a. Using a rounded scraper, remove carbon deposits from piston crown.



Fig. 99

- b. Break a used piston ring in two. File end square. Deburr edges to avoid scratching ring groove and clean carbon deposits from ring grooves.



Fig. 100

- c. Using 400-600 grit wet sandpaper, lightly sand score marks and lacquer deposits from sides of piston. Sand in cross-hatch pattern. Do not sand excessively.
- d. Wash piston in solvent and wipe dry.

- e. Using an outside micrometer, measure piston diameter. The piston is cam-ground and tapered. The only measuring point is at right-angles to the piston pin holes about 1/2 in. from the bottom of the piston skirts. Compare piston diameter to cylinder bore measurements.

Standard piston dia.: 1.88 ins. (47 mm.)

Subtracting piston maximum diameter from minimum cylinder diameter gives piston clearance. If beyond tolerance, hone cylinder to tolerance or re-bore to next over-size and fit new piston.

	Min.	Max.
Nominal piston clearance	0.0014 in. (0.035 mm.)	0.0016 in. (0.040 mm.)
Maximum wear limit	0.004 in. (0.100 mm.)	




Fig. 101




Fig. 102

- f. During reassembly, coat the piston skirt areas liberally with two-stroke oil.



Fig. 103

- g. Install new piston pin circlips and make sure they are fully seated within their grooves.




Fig. 104

- h. Take care during installation to avoid damaging the piston skirts against the crankcase as the cylinder is installed. Note the two induction holes in the piston skirt. These must be to the rear during installation.




Fig. 105

- i. Make sure the rings are properly positioned as the cylinder is installed.



Fig. 106

8. Maintenance — piston pin, bearing and connecting rod

- a. Check the pin for signs of wear. If any wear is evident, replace pin and bearing.
- b. Check the pin and bearing for signs of heat discoloration. If excessive (heavily blued), replace both.




Fig. 107

- c. Check the bearing cage for excessive wear. Check the rollers for signs of flat spots. If found, replace pin and bearing.
- d. Apply a light film of oil to pin and bearing surfaces. Install in connecting rod small end. Check for play. There should be no noticeable vertical play. If play exists, check connecting rod small end diameter and wear. Replace pin and bearing or all as required.



Fig. 108

- e. Rotate the crankshaft to top dead center. Mount a dial gauge at right angles to the connecting rod small end and measure axial play. (Hold bottom of rod to one side and rock top of rod from side to side.)
- f. Remove the dial gauge and slide the connecting rod to one side. Insert a feeler gauge between the side of the connecting rod big end and the crank wheel. Measure clearance.
- g. If any of these measurements exceed tolerance, crankshaft repair is required. Take the machine to your Authorized Yamaha Dealer.




Fig. 109

- h. During reassembly, apply a liberal coating of two stroke oil to the piston pin and bearing. Apply several drops of oil to the connecting rod big end. Apply several drops of oil into each crankshaft bearing oil delivery hole.



Fig. 110

	Max.	Min.
Connecting rod axial play	0.079 in. (2.0 mm.)	0.031 in. (0.8 mm.)
Connecting rod/crank web clearance	0.02 in. (0.5 mm.)	0.016 in. (0.4 mm.)

9. Troubleshooting — top end and muffler


If performance is not up to par, the following procedure will indicate if top end repair is required.

- a. Adjust ignition timing.
- b. Make a spark plug reading. Adjust spark plug and/or carburetion as required.
- c. Decarbonize muffler/spark arrester assembly.
Decarbonize cylinder head and piston crown. Take care that carbon does not drop into crankcase cavity or foul ring grooves. Reassemble.
- d. Warm up engine. Insert compression gauge into spark plug hole. With ignition off and throttle on, kick engine over briskly several times. If compression measurement exceeds tolerances, disassemble cylinder head and decarbonize.
- e. Reassemble and re-check compression pressure. If no improvement, disassemble top end complete.

Compression pressure:

78.0 lbs/in.² (5.5 kg/cm.²)/650 ~ 750 r.p.m.

I. FLYWHEEL MAGNETO



1. Removal and installation

Note:

For timing procedure, see "Mechanical Adjustments, Ignition Timing". For theory of operation and troubleshooting, see "Electrical System"

- a. Remove shift lever and left crankcase cover.
- b. Disconnect clutch cable.
- c. Remove the flywheel magneto securing nut, lock washer and flat washer. Note installation order and direction.
- d. Install the magneto flywheel puller.

Note:

The puller body has a lefthand thread.

- e. Tighten the puller body thoroughly into the flywheel. While holding the body, tighten the push bolt. This will pull the flywheel off the tapered end of the crankshaft.

Note:

If the flywheel is frozen on the taper, keep pressure on the push bolt while tapping on the end of the bolt with a light steel hammer.

- f. With the flywheel removed, the magneto backing plate is exposed, allowing for replacement of any assembly therein.
- g. The ignition source coil is located on the left-hand side of the backing plate.




Fig. 112




Fig. 113

2. Maintenance

- a. Apply a few drops of light-weight machine oil or distributor lubricant to the point cam lubricating wick.
- b. The ignition points can be lightly filed with an ignition point file or sanded with 400-600 grit sandpaper. Place a piece of clean paper between the points, let them close, and repeatedly remove the paper until no residue shows. The paper should be dipped in lacquer thinner or point cleaning fluid to provide a solvent to remove oil and sanding residue from point surfaces.
- c. Point replacement should only occur when point gap exceeds maximum tolerance; when the points are severely pitted; or if the points become shorted or show faulty operation.

Point gap: 0.012 ~ 0.016 in. (0.3 ~ 0.4 mm.)

Note:

There is no separate point gap adjustment. Point gap is directly related to ignition timing and cam follower wear.

New points, when installed, should be lightly burnished and thoroughly cleaned per b. above.

- d. When replacing ignition condenser, source coil, or lighting source coil, soldering is required. Use a low wattage gun. Do not allow wiring to overheat as lacquer insulation on coil windings may be destroyed. The use of a heat sink is recommended.

e. When installing magneto flywheel, make sure woodruff key is properly seated in keyway in crankshaft.

Apply a light coating of lithium soap base grease to tapered portion of crankshaft end. Carefully install flywheel taking care to align woodruff key. Install flat washer, lock washer and lock nut.

Tighten carefully to recommended torque value.

Flywheel securing nut torque:


300 ~ 350 in-lbs. (3.5 ~ 4.0 m-kgs.)

Note:

Whenever the magneto flywheel is removed, ignition timing must be reset.

www.legends-yamaha-enduros.com

J. KICK STARTER



K. CLUTCH, SHIFTER AND KICK STARTER

Note:

Clutch adjustment is covered in VII, "Mechanical Adjustments".

1. Removal

- a. Remove the kick start lever.
- b. Remove footrest assembly to provide clearance for crankcase cover removal.
- c. If cylinder is in place, remove oil pump delivery line from intake manifold.
- d. Remove the Autolube pump cover.
- e. Remove the clip and rotate the pump pulley to increase cable slack and remove the cable end from its seat in the pulley.
- f. Using a 0.34 in. (10 mm.) wrench, loosen the cable adjuster locknut. Remove the adjuster and cable.




Fig. 115




Fig. 116




Fig. 117

- g. Remove the pivot shaft nut, loosen the footrest mounting nut, and turn the footrest assembly so that it doesn't touch crankcase cover.

Remove the Allen bolts holding the side cover in place. Push down on the brake pedal to provide clearance and remove the cover.

Note:

The Autolube pump assembly need not be removed for this procedure.

www.legends-yamaha-enduros.com




Fig. 118




Fig. 119

- h. To remove kick start assembly, first disconnect return spring and allow it to unwind.




Fig. 120

- i. Pull out the kick starter assembly.




Fig. 121

- j. Remove the Phillips screws (4) holding the pressure plate. Remove the clutch springs, pressure plate and push rod. Remove the clutch plates, friction plates, and cushion rings.

Note:

When removing Phillips spring screws, loosen each screw in several stages working in a cross-hatch pattern to avoid any unnecessary warpage. Note the condition of each piece as it is removed and its location with the assembly.

www.legends-yamaha-enduros.com




Fig. 122




Fig. 123

- k. Using the clutch holding tool, remove the clutch securing nut.
Remove the clutch boss and driven gear (clutch housing).
- l. If the clutch housing spacer and thrust plate remain on the transmission main shaft, remove them.





Fig. 124

www.legends-yamaha-enduros.com

L. CLUTCH



1. Driven gear complete
2. O-ring
3. Thrust plate 1
4. Thrust plate 2
5. Clutch boss
6. Cushion ring
7. Friction plate
8. Clutch plate
9. Pressure plate
10. Bolt
11. Clutch spring
12. Belleville washer
13. Clutch boss nut
14. Push rod 1
15. Spacer
16. Ball
17. Push rod 2
18. Nut
19. Adjusting screw
20. Push screw
21. Push screw housing
22. Oil seal
23. Pan head screw
24. Push lever
25. Spring fork
26. Return lever spring

Fig. 125

1. **Troubleshooting — clutch assembly**

- a. Measure the composition friction plates at three or four points. If their minimum thickness exceeds tolerance, replace.

	New	Wear limit
Friction plate thickness	0.14 in. 3.5 mm.	0.13 in. 3.2 mm.

- b. Check the plates for signs of warpage and heat damage, replace as required.

Note:

For optimum performance, if any plate requires replacement, it is advisable to replace the entire set.

- c. Check each clutch plate for signs of heat damage and warpage. Place on surface plate (plate glass is acceptable) and use feeler gauge as illustrated. If warpage exceeds tolerance, replace.

Clutch plate warp. allowance:	0.002 in. (0.05 mm.) maximum
-------------------------------	------------------------------




Fig. 126



Fig. 127

- d. Thoroughly clean the clutch housing and spacer.
Apply a light film of oil to the bushing surface and spacer. Fit the spacer into the bushing. It should be a smooth, thumb-press fit. The spacer should rotate smoothly within the bushing.
- e. Check the bushing and spacer for signs of galling, heat damage, etc. If severe, replace as required.
- f. Apply a thin coat of oil to transmission main shaft and bushing spacer I.D. Slip thrust plate and spacer over main shaft. Spacer should fit with approximately same "feed" as in clutch housing. Replace as required.




Fig. 128

- g. Check dogs on driven gear (clutch housing). Look for cracks and signs of galling on edges. If moderate, deburr. If severe, replace.



Fig. 129

- h. Check splines on clutch boss for signs of galling. If moderate, deburr. If severe, replace.

Note:

Galling on either the friction plate dogs of the clutch housing or clutch plate splines of the clutch boss will cause erratic clutch operation.

- i. Fit the clutch thrust plates (2) and clutch boss with a light film of oil on all parts. Check for smooth rotation. Check for signs of excessive wear on all parts. Replace as necessary.
- j. If clutch operation has been abnormal, and the above procedures show no major failures, install the clutch housing on the transmission main shaft with thrust plates, bearing spacer, and clutch boss in their proper positions for reassemble. Do not install clutch or friction plates. Install Belleville spring and clutch securing nut. Torque to standard assembly value.

Clutch securing nut torque:

350 ~ 400 in-lbs. (4.0 ~ 4.5 m-kgs.)

- k. With transmission in neutral and primary driven gear stationary, clutch boss should turn without drag within the clutch housing. If housing does not turn easily, indicating insufficient housing end play, check all thrust plates for incorrect thickness. Correct by installing thinner thrust plates. Clutch housing end play is given in table and can be measured with a dial gauge.

	Nominal	Min.	Max.
Clutch housing end play	0.006 in. (0.15 mm.)	0.004 in. (0.10 mm.)	0.012 in. (0.30 mm.)

	New	Min.
Clutch spring free length	1.24 ins. (31.5 mm.)	1.22 ins. (30.5 mm.)

Note:

For optimum clutch operation it is advisable to replace the clutch springs as a set if one or more are faulty.




Fig. 130

- i. Set the clutch spring set on a level surface. Rotate each spring until all are at approximately the same vertical angle and maximum apparent height. Place straight edge across set. If any spring exceeds tolerance, replace that spring.

Clutch spring set maximum length difference:
0.04 in. (1.0 mm.)

- m. During installation of the clutch assembly, do not allow the cushion rings to become twisted. Take care that the thrust plates do not slip out of position as the housing and clutch boss are installed. Install all parts with a heavy coat of 10W.-30 motor oil on their mating surfaces.

Clutch securing nut torque:
350 ~ 400 in-lbs. (4.0 ~ 4.5 m-kgs.)




Fig. 131

M. SHIFT MECHANISM

1. Removal

Note:

Shifter maintenance and adjustment should be performed with clutch assembly removed.

- a. Remove the "E" clip securing change lever number two. Push down on change lever number three and remove the assembly.
- b. Check the levers, pivots and springs for damage or wear and replace as required.
- c. Turn change shaft in case. It must not bind or catch.
- d. If it does, remove and file off any burrs or straighten if bent. Replace if damage is too extensive.
- e. Remove shift cam stopper bolt, spring and detent from top, left-hand side of crankcase.

With the rear wheel off the ground, rotate the clutch shaft with one hand and turn the shift drum from lock to lock with the other hand. If the transmission doesn't shift through all gears smoothly, the engine should be disassembled and the transmission checked.





Fig. 132


SHIFTER 1



1. Shift cam
2. Dowel pin
3. Side plate
4. Flat head screw
5. Shift fork 1
6. Dowel pin
7. Cotter pin
8. Stopper plate 2
9. Flat head screw
10. Stopper plate 1
11. Spring screw
12. Drain plug gasket
13. Cam stopper spring
14. Cam stopper
15. Dowel pin
16. Blind plug
17. Circlip
18. Shift fork 2
19. Shift fork guide bar
20. E-clip

Fig. 133

SHIFTER 2



- | | |
|--------------------------|--------------------------|
| 1. Change lever assembly | 8. Change shaft assembly |
| 2. Shaft | 9. Change pedal |
| 3. Shaft return spring | 10. Change pedal cover |
| 4. E-clip | 11. Bolt |
| 5. Adjusting screw | 12. Oil seal |
| 6. Nut | 13. Change axle washer |
| 7. Change lever roller | 14. E-clip |

Fig. 134

2. Adjustment




Fig. 135

- a. In 2nd gear, check for proper centering. Change adjustment on screw as required.
- b. While arm is butted against adjusting screw, measure clearance between change lever and shift drum dowel pin.
- c. Repeat steps (2) and (3) shifting from 3rd — 2nd. Clearance must equal (3) above. Change adjustment using screw as required.
- d. Repeat step (1).

N. DRIVE SPROCKET

With the left crankcase cover removed, proceed as follows:

- a. Using a blunt chisel, flatten the drive sprocket lock washer tab.
- b. With the drive chain in place, transmission in gear, firmly apply the rear brake. Remove the sprocket securing nut. Remove the sprocket.



Fig. 136

- c. Check sprocket wear. Replace if wear decreases tooth height to a point approaching the roller center line.




Fig. 137

- d. Replace if tooth wear shows a pattern such as that in the illustration, or as precaution and common sense dictate.

www.legends-yamaha-enduros.com





Fig. 138



1. Drive sprocket
2. Lock washer
3. Locknut
4. Sprocket wheel gear
5. Lock washer
6. Fitting bolt
7. Chain
8. Chain joint

Fig. 139

- e. During drive sprocket reassembly, make sure the lock washer splines are properly seated on the drive shaft splines. Tighten securing nut thoroughly to specified torque value. Bend lock washer tab fully against securing nut flats.

Drive sprocket securing nut torque:
350 ~ 400 in-lbs. (4.0 ~ 4.5 m-kgs.)

O. DRIVEN SPROCKET

With the rear wheel removed, proceed as follows:

- a. Using a blunt chisel, flatten the securing bolt lock washer tabs. Remove the securing bolts (4). Remove the lock washers and sprocket.
- b. Check sprocket wear per procedures for the drive sprocket.
- c. During reassembly, make sure the sprocket and sprocket seat are clean. Tighten the securing bolts in a cross-hatch pattern. Bend the tabs of the lock washers fully against the securing bolt flats.

Driven sprocket securing bolt torque:
175 in-lbs. (2.0 m-kgs.)




Fig. 140

P. CHAIN

Note:

Please refer to Maintenance and Lubrication Intervals Charts for additional information.

- Using a blunt-nosed pliers, remove the master link clip and side plate. Remove the chain.
- Check the chain for stiffness. Hold as illustrated. If stiff, soak in solvent solution, clean with medium bristle brush, dry with high pressure air. Oil chain thoroughly and attempt to work out kinks. If still stiff, replace.

www.legends-yamaha-enduros.com

- Check the side plates for visible wear. Check to see if excessive play exists in pins and rollers. Check for damaged rollers. Replace as required.
- During reassembly, the master link clip must be installed with the rounded end facing the direction of travel.




Fig. 141




Fig. 142

□ Troubleshooting

With the chain installed on the machine, excessive wear may be roughly determined by attempting to pull the chain away from the rear sprocket. If the chain will lift away more than one-half the length of the sprocket teeth, remove and inspect.

If any portion of the chain shows signs of damage, or if either sprocket shows signs of excessive wear, remove and inspect.

□ Maintenance

The chain should be lubricated per the recommendations given in the Maintenance and Lubrication Intervals Charts. More often if possible. Preferably after every use. See "Chassis and Suspension, Swing arm", for additional information regarding chain guide and oiler.

1. Wipe off dirt with shop rag. If accumulation is severe, use soft bristle brush, then rag.
2. Apply lubricant between roller and side plates on both inside and outside of chain. Don't skip a portion as this will cause uneven wear. Apply thoroughly. Wipe off excess.

Note:

Chain and lubricant should be at room temperature to assure penetration of lubricant into rollers.

Choice of lubricant is determined by use and terrain. SAE 20 wt. or 30 wt. may be used, but several specialty types by accessory manufactures offer more penetration, corrosion resistance and shear strength for roller protection.




Fig. 143

In certain areas, semi-drying lubricants are preferable. These will resist picking up sand particles, dust, etc. Consult your Authorized Yamaha Dealer.

3. Periodically, remove the chain. Wipe and/or brush excess dirt off. Blow off with high pressure air.
4. Soak chain in solvent, brushing off remaining dirt. Dry with high pressure air. Lubricate thoroughly while off machine. Work each roller thoroughly to make sure lubricant penetrates. Wipe off excess. Re-install.

Q. CABLES

Note:

See Maintenance and Lubrication Intervals Charts for additional information.

Cable maintenance is primarily concerned with preventing deterioration through rust and weathering; and providing for proper lubrication to allow the cable to move freely within its housing.

Cable removal is straight-forward and uncomplicated. Removal will not be discussed within this section. For details, see the individual maintenance section for which the cable is an integral part.

Cable routing is of paramount importance, however. For details of cable routing, see the cable routing diagrams at the end of this manual.

□ **Maintenance**

1. Remove the cable.
2. Check for the movement of the cable within its housing. If movement is obstructed, check for fraying of the cable strands. If fraying is evident, replace the cable assembly.
3. To lubricate cable, hold in vertical position. Apply lubricant to uppermost end of cable. Leave in vertical position until lubricant appears at bottom end. Allow excess to drain and re-install.

Note:

Choice of lubricant depends upon conditions and preference. However, a semi-drying, graphite-base lubricant will probably perform adequately under most conditions.

Under certain conditions, a water displacing lubricant is more suitable. Check with the Authorized Yamaha Dealer in your area.

R. THROTTLE CABLE CYLINDER

The throttle cable cylinder (junction point for Autolube control cable) must be periodically maintained also.

- a. Remove throttle cable number one from handlebar housing.
- b. Remove throttle cable number two from carburetor mixing chamber top.
- c. Remove Autolube pump cable from pump pulley. Remove cable adjuster.
- d. Remove seat and fuel tank.
- e. Remove cable/cylinder assembly complete.
- f. Remove cylinder cap, throttle cable two and Autolube pump cable.
- g. Wash assembly thoroughly in solvent.
- h. Lubricate all associated cables.
- i. Apply a thin coating of lubricant to cylinder walls.


Note:

A small amount of lithium soap base grease may be used in lieu of cable lubricant. However, if machine is to be used in extreme cold, this should be avoided.

- j. Reassemble all cables. Make sure cylinder is sealed from ravages of weather and riding conditions. Reinstall. See cable routing diagrams for correct installation position. See Mechanical Adjustments Chapter for correct cable adjustment.

HANDLE - WIRE

THE HANDLE WIRE CYLINDER



1. Handlebars
2. Grip left
3. Grip right
4. Guide tube
5. Throttle wire
6. Cylinder
7. Throttle wire 2
8. Pump wire
9. Clutch wire
10. Wire end
11. Brake wire
12. Wire adjusting nut
13. Wire adjusting bolt
14. Lever left
15. Lever right
16. Lever collar
17. Nut
18. Lever fitting screw
19. Lever holder (left)
20. Lever holder (right)
21. Adjusting bolt
22. Adjusting nut
23. Switch cord band
24. Wire guide holder

Fig. 144

IX. CHASSIS AND SUSPENSION

A. FRONT WHEEL

1. Removal

- a. Disconnect the brake cable.
- b. Remove cotter pin from front wheel nut.

- c. Remove the front wheel nut.

www.legends-yamaha-enduros.com




Fig. 145





Fig. 146

FRONT WHEEL



1. Front hub
2. Spoke set
3. Rim
4. Tire
5. Tube
6. Rim band
7. Bearing spacer
8. Spacer flange
9. Bearing
10. Oil seal
11. Brake shoe plate
12. Cam shaft
13. Oil seal
14. Brake shoe complete
15. Return spring
16. Cam shaft lever
17. Bolt
18. Nut
19. Spring washer
20. Plain washer
21. Wheel shaft
22. Wheel shaft collar
23. Shaft nut
24. Cotter pin

Fig. 147

- d. Remove the front wheel axle by simultaneously twisting and pulling out on the axle.
- e. Raise the front of the machine and set it on a box. Remove the wheel assembly.

2. Checking brake shoe wear

- a. Measure the outside diameter at the brake shoe with slide calipers. If it measures less than specified limit, replace.

Front brake shoe diameter: 3.74 ins. (95 mm.)

Replacement limit: 3.5 ins. (90 mm.)

b. Brake drum

Oil or scratches on the inner surface of the brake drum will impair braking performance or result in abnormal noises. Remove oil by wiping with a rag soaked in lacquer thinner or solvent. Remove scratches by lightly and evenly rubbing with emery cloth.

c. Replacing wheel bearings

If the bearings allow excessive play in the wheel or if it does not turn smoothly, replace the bearing as follows:

- 1) First clean and outside of the wheel hub.




Fig. 148




Fig. 149

- 2) Insert the bent end of the special tool into the hole located in the center of the bearing spacer, and drive the spacer out from the hub by tapping the other end of the special tool with a hammer. (Both bearing spacer and spacer flange can easily be removed.)
- 3) Push out the bearing on the other side.
- 4) To install the wheel bearing, reverse the above sequence. Be sure to grease the bearing before installation and use the bearing fitting tool (available from Yamaha dealers).
- 5) Check the lips of the seals for damage or warpage. Replace if necessary.

www.legends-yamaha-enduros.com

B. REAR WHEEL

The rear wheel is 14 ins. size, and the rear tire is Trials Universal. A single leading-shoe type brake is used. A labyrinth seal between the wheel hub and the brake plate is provided to prevent water and dust leakage.

1. Removal

- a. Remove the tension bar and brake rod from rear shoe plate.




Fig. 150




Fig. 151




Fig. 152

- b. Remove cotter pin from rear wheel shaft nut.
- c. Remove the rear wheel shaft nut.




Fig. 153

www.legends-yamaha-enduros.com

- d. Pull out the rear wheel shaft by simultaneously twisting and pulling out.
- e. Remove the rear brake shoe plate.
- f. Lean the machine to the left and remove the rear wheel assembly.





Fig. 154

REAR WHEEL



- | | |
|-------------------------|-------------------------|
| 1. Rear hub | 26. Cotter pin |
| 2. Spoke set | 27. Wheel shaft |
| 3. Rim | 28. Chain puller |
| 4. Tire | 29. Wheel shaft collar |
| 5. Tube | 30. Sprocket wheel gear |
| 6. Rim band | 31. Fitting bolt |
| 7. Bearing spacer | 32. Lock washer |
| 8. Spacer flange | 33. Nut |
| 9. Bearing | 34. Oil seal |
| 10. Oil seal | 35. Shaft collar |
| 11. Brake shoe plate | 36. Shaft nut |
| 12. Shift cam | 37. Cotter pin |
| 13. Brake shoe complete | 38. Chain |
| 14. Return spring | 39. Chain joint |
| 15. Cam shaft lever | |
| 16. Bolt | |
| 17. Nut | |
| 18. Spring washer | |
| 19. Plain washer | |
| 20. Tension bar | |
| 21. Tension bar bolt | |
| 22. Spring washer | |
| 23. Nut | |
| 24. Cotter pin | |
| 25. Plain washer | |

Fig. 155

2. Checking brake shoe wear

- a. Measure the outside diameter at the brake shoe with slide calipers. If it measures less than specified, replace it.

Rear brake shoe diameter: 4.33 ins. (110 mm.)

Replacement limit: 4.13 ins. (105 mm.)

- b. Smooth out a rough shoe surface with sandpaper or with a file.

c. Brake drum

Oil or scratches on the inner surface of the brake drum will impair braking performance or result in abnormal noises. Remove oil by wiping with a rag soaked in lacquer thinner or solvent. Remove scratches by lightly and evenly rubbing with emery cloth.

d. Replacing wheel bearings.

See front wheel section.

e. Spokes

Check the spokes. If they are loose or bent, tighten or replace them. If the machine is ridden in rough country often, or raced, the spokes should be checked regularly.

f. Rear wheel sprocket

1) Inspection

A worn sprocket will result in excessive chain noise and shorten the life of the chain. Check the sprocket for worn teeth, and replace sprocket if they are worn.




Fig. 156

- 2) To replace the sprocket, take the following steps:
 - a) Bend the lock washer ears flat.
 - b) Remove the sprocket fitting bolts.
 - c) Check the lock washer and fitting bolt for breakage and damage. If the lock washer is not bent over the fitting bolt head, or is broken, or if the bolt is loose, the sprocket can come loose. Make sure that both lock washers and the mounting bolts are tight when installing new sprocket.

C. CHECKING RIMS AND SPOKES

(Front and Rear Wheels)

www.legends-yamaha-enduros.com

1. Checking for loose spokes

Loose spokes can be checked by bracing the machine off the ground so that the wheel can spin freely. Slowly revolve the wheel and at the same time let the metal shaft of a fairly heavy screwdriver bounce off each spoke. If all the spokes are tightened approximately the same, then the sound given off by the screwdriver hitting the spokes should sound the same. If one spoke makes a dull flat sound, then check it for looseness.




Fig. 157




Fig. 158



Fig. 159

2. Checking rim "run-out"

While you have the wheel elevated, you should check that it does not have too much run-out. "Run-out" is the amount the wheel deviates from a straight line as it spins. Spin the wheel, and solidly anchor some sort of a pointer about 1/8 in. away from the side of the rim. As the wheel spins, the distance between the pointer and the rim should not change more than 1/16 in. total. Any greater fluctuation means that you should have your dealer remove this rim warpage by properly adjusting the spokes.




Fig. 160

Lateral run-out limits: 0.07 in. (2 mm.) (1/16 in.)

Vertical run-out limits: 0.07 in. (2 mm.) (1/16 in.)

D. TIRE REPAIRS

1. Removal

- a. Remove valve cap, valve core, and valve stem locknut.
- b. When all air is out of tube, separate tire bead from rim (both sides) by stepping on tire with your foot.
- c. Use two tire removal irons (with rounded edges) and begin to work the tire bead over the edge of the rim, starting 180° opposite the tube stem. Take care to avoid pinching the tube as you do this.




Fig. 161

- d. After you have worked one side of the tire completely off the rim, then you can slip the tube out. Be very careful not to damage the stem while pushing it back out to the rim hole.

Note:

If you are changing the tire itself, then finish the removal by working the tire off the same rim edge just previously mentioned.

2. Installing tire

Reinstalling the tire assembly can be accomplished by reversing the disassembly procedure. The only difference in procedure would be right after the tube has been installed, but before the tire has been completely slipped onto the rim, inflate the tube. This removes any creases that might exist. Release the air and continue with reassembly. Also, right after the tire has been completely slipped onto the rim, check to make sure that the stem is squarely in the center of the hole in the rim.

Tire Pressure	Front	20 lbs/in. ² (1.4 kg/cm. ²)	Normal riding (use 4 ~ 6 p.s.i. for max. traction at slow speeds)
	Rear	28 lbs/in. ² (2.0 kg/cm. ²)	

E. FRONT FORKS AND STEERING HEAD

1. General

The front forks on your machine utilize chrome plated tubular steel fork legs (inner tubes) and tubular aluminum sliders (outer tubes). The entire inside surface of the aluminum outer tube slides over the inner tube.

The steering head pivot is supported by two sets of uncaged ball and race bearing assemblies.




Fig. 162

2. Front fork oil change

- Remove cap bolts on inner fork tubes.
- Remove drain screw from each outer tube with open container under each drain hole.
- After most of oil has drained, slowly raise and lower outer tubes to pump out remaining oil.
- Replace drain screws.

Note:

Check gaskets, replace if damaged.





Fig. 163

FRONT FORK



1. Outer tube left
2. Outer tube right
3. O-ring
4. Fork spring
5. Spring upper washer
6. Spacer
7. Inner tube left
8. Inner tube right
9. Slide metal
10. Outer nut complete
11. Oil seal
12. Dust seal
13. Packing
14. Cap washer
15. Cap bolt
16. Under bracket complete
17. Under bracket bolt
18. Clip

Fig. 164

e. Measure correct amount of oil and pour into each leg.

Recommended oil: Yamaha fork oil
Quantity: 2.9 oz. (85 c.c.) (per leg)

Note:

Select the weight oil that suits local conditions and your preference (lighter for less damping; heavier for more damping).




Fig. 165

- f. After filling, slowly pump the outer tubes up and down to distribute the oil.
- g. Inspect O-ring on inner tubes and replace if damaged.




Fig. 166

h. Replace fork cap bolts and torque to specification.

Fork cap torque: 300 ~ 350 in-lbs. (3.5 ~ 4.0 m-kgs.)

3. Front fork disassembly

- a. With the front wheel removed, the fork legs can be removed from the upper and lower brackets.
- b. Disassembly procedure for individual fork tube assembly is found in DT250A/360A Service Manual.

Note:

Proper fork seal installation is important. Also, carefully tap seal in with large socket to avoid damage to aluminum fork tube.

4. Steering head adjustment

- a. With front wheel elevated, grasp bottoms of fork legs and gently push and pull to check steering head freeplay. There should be no noticeable freeplay.





Fig. 167



Fig. 168

STEERING



1. Dust seal 1
2. Ball race 1
3. Ball
4. Ball race 2
5. Ball race 2
6. Ball
7. Ball race 1
8. Ball race cover
9. Fitting nut
10. Handle crown
11. Crown washer
12. Fitting bolt
13. Bolt
14. Spring washer
15. Handle holder upper
16. Handle holder under
17. Nut
18. Spring washer
19. Plain washer

Fig. 169

- b. Loosen stem bolt.
- c. Use steering nut wrench to tighten adjust nut. Tighten until freeplay is eliminated.

Caution:

Forks must swing from lock to lock without binding or catching.

- d. Tighten stem bolt and torque to specification.

Stem bolt torque: 300 ~ 350 in-lbs. (3.5 ~ 4.0 m-kgs.)

F. REAR SHOCK ABSORBERS AND SWING ARM

1. Rear shock removal and inspection

- a. After rear wheel has been removed, remove Phillips head screw, crown nut and cup washer from each shock.
- b. Remove shock.




Fig. 170




Fig. 171




Fig. 172

- c. Operate shock absorber to check damping. As you push down, only slight damping should be felt. Return stroke will have considerable damping. If there is no damping, replace shock.

2. Swing arm inspection

- a. With rear wheel and shock absorbers removed, grasp the ends of the arm and move from right to left to check for freeplay.

Swing arm freeplay: 0.04 in. (1.0 mm.)

- b. If freeplay is excessive, remove swing arm and replace swing arm bushings.

www.legends-yamaha-enduros.com

G. INSTALLATION OF OPTIONAL PARTS (FOOTREST AND OTHERS FOR ENDURO USE)

The model TY80B was originally developed for trials riding. To meet the great market demand for an enduro version of this model, Yamaha presents optional parts centering upon the footrests that will provide the best possible riding position for enduro.




Fig. 173




Fig. 174


Component parts

Footrest (right and left)	1 each	YZ80 type
Footrest bracket (left)	1	
Footrest bracket (right)	1	
Brake pedal	1	Modified following advanced footrest position
Side stand	1	Same as above
Steering stopper	1	Steering angle changed from 144° to 94°

There are bolts and nuts required for the above installation as follows.

Steering stopper fitting bolt	2
Footrest bracket fitting bolt	1
Spring washer for above	1
Fitting nut for above	1
Footrest fitting bolt	2
Nut for above	2
Footrest return spring	2

www.legends-yamaha-enduros.com



1. Footrest right
2. Footrest bracket right
3. Fitting bolt.
4. Return spring
5. Brake pedal
6. Fitting nut
7. Brake pedal return spring
8. Fitting nut
9. Fitting bolt
10. Footrest bracket left
11. Footrest left
12. Fitting nut
13. Return spring
14. Footrest fitting bolt
15. Side stand
16. Spring washer
17. Steering stopper
18. Fitting bolt

Fig. 175

1. Replacement with optional parts:

- a. Remove both the footrest brackets.

As the pivot shaft is also used to secure the brackets, block the rear wheel to raise it off the ground when removing pivot shaft.

- b. Remove the brake pedal.

- 1) Remove the cotter pin and plane washer from the brake rod.
- 2) The right hand footrest can now be pulled out as the bracket holding bolts have already been removed in a. above. Next pull out the brake pedal. Put the return spring aside so that it is not lost. This return spring is used in the subsequent replacement operation.

- c. Remove the left hand footrest.

www.legends-yamaha-enduros.com

2. Installation of the optional parts

- a. Install the brake pedal.

Note that the return spring is turned approximately 180° from the original position as illustrated. The frame has a new hole to hold this spring. Also a new cotter pin must be used.

* Note the position of the plane washer.






Fig. 176

How to hook the brake return spring

OPTIONAL PARTS



S.T.D. TYPE



b. Install the footrest bracket.

First fit the pivot shaft to keep the rear arm in position. Secure the optional bracket to the frame at three positions. (See drawing.)

Tightening torque:

Pivot shaft nut

2 ~ 3 m-kgs.

Other bolts and nuts

0.8 ~ 1.25 m-kgs.

c. Install the footrest to the footrest bracket.

Remember that the return spring should be installed in the correct direction.

d. Remove the side stand and replace it with the option.

To install the footrest bracket, the original bolts, nuts and return spring should be used.

- e. Install the steering stopper. With this operation, the installation of the bracket is complete.

Tightening torque: 0.35 ~ 0.55 m·kg.

A steering system for trials use has a larger steering angle and when this steering system is used for enduro riding it may cause a danger to the rider. The purpose of the stopper is to limit the steering angle.

Steering angle (either side): 72° to 47°

In addition to the above, the following secondary reduction sprocket gears are available as options for the TY80B model.

Drive sprocket:	11T	www.legends-yamaha-enduros.com
	12T (S.T.D.)	
	13T	
	14T	
Driven sprocket:	39T	
	41T (S.T.D.)	

There are various points of which extra note should be taken in enduro riding such as spark plugs, the tire pressure, retightening of the respective parts, etc. We would suggest that you ask your nearest dealers for advice in these respects.

X. ELECTRICAL SYSTEM

A. GENERAL INFORMATION AND SCHEMATICS

1. General

The TY80B uses a flywheel magneto to generate electrical current/voltage for the ignition system and the lighting system. There are two coils attached to the magneto backing plate. The right-hand coil supplies primary voltage to the ignition coil. The left-hand coil provides alternating current (AC) for operation of the lights and horn.

Note:

If headlight filament burns out while engine is running, the tail lamp filament may also burn out because of excess voltage. Always check taillight operation when replacing headlight.

a. Table of component parts

www.legends-yamaha-enduros.com

Part Name	Manufacturer	Model/Type
Flywheel magneto	MITSUBISHI	FOT02471
Ignition coil	MITSUBISHI	F6T40184
Contact breaker assembly	MITSUBISHI	
Condenser 	MITSUBISHI	
Spark plug	N.G.K.	B-6HS

b. Electrical wiring diagram




Fig. 179

2. Magneto ignition system

a. Description

The ignition system consists of the following parts:

1. Flywheel magneto
2. Ignition source coil
3. Contact breaker assembly (points)
4. Ignition condenser
5. Ignition coil (voltage step-up coil)
6. Kill button
7. Spark plug

As the flywheel rotates, the contact breaker points begin to open and close, alternately. This make-and-break operation develops an electromotive force in the ignition power source coil, and produces a voltage in the ignition coil primary windings. The ignition coil is a kind of transformer, with a 1 : 50 turn ratio of the primary to the secondary winding. The voltage (150-300V.) which is produced in the primary winding, is stepped up to 12,000 - 14,000V. by mutual-induction and the electric spark jumps across the spark plug gap.




Fig. 180

www.legends-yamaha-enduros.com

b. Ignition timing

Refer to "Mechanical Adjustments, Ignition Timing" for step-by-step procedure.

Spark Test:

Remove the spark plug from the cylinder head and reconnect the high voltage lead. Then hold the spark plug approximately 7 mm. away from the head and see if it sparks as you crank the kickstarter. If it sparks at 7 mm. or so, and has blue white color, the ignition coil is considered to be in good condition.

c. Ignition coil

primary winding resistance: $1.02\Omega. \pm 10\%$ (20°C or 68°F)
Secondary winding resistance: $6.0K\Omega. \pm 10\%$ (20°C or 68°F)





Fig. 181

Burned contact points greatly affect the flow of current in the primary winding of the ignition coil. If the contact points show excessive wear, or the spark is weak (the ignition coil is in good condition), check the condenser.

d. Condenser

The condenser instantly stores a static electric charge as the contact breaker points separate, and the energy stored in the condenser discharges instantly when the points are closed. If it were not for the condenser, an electric arc would jump across the separating contact points causing them to burn.



Insulation resistance tests should be conducted by connecting the tester as shown. If the pointer swings fully and the reading is more than $3M\Omega$, the insulation is in good condition. If the insulation is faulty, the pointer will stay pointing at the uppermost reading, indicating very little resistance.

Note:

After this measurement, the condenser should be discharged by connecting the positive and negative sides with a thick wire.

Capacity tests can be performed by simply setting the tester to the condenser capacity. The tester should be connected with the condenser in the same way as in the case of the insulation resistance test. Before this measurement, be sure to set the tester correctly. If the reading is within $0.3\mu F \pm 10\%$, the condenser capacity is correct.

www.legends-yamaha-enduros.com

XI. MISCELLANEOUS

CONVERSION TABLES

LENGTHS

Multiply	By	To obtain	Multiply	By	To obtain
Millimeters (mm.)	0.03937	Inches	Kilometers (km.)	0.6214	Miles
Inches (in.)	25.4	Millimeters	Miles (mi.)	1.609	Kilometers
Centimeters (cm.)	0.3937	Inches	Meters (m.)	3.281	Feet
Inches (in.)	2.54	Centimeters	Feet (ft.)	0.3048	Meters

WEIGHTS

Kilograms (kg.)	2.205	Pounds	Grams (g.)	0.03527	Ounces
Pounds	0.4536	Kilograms	Ounces (oz.)	28.25	Grams

VOLUMES

Cubic centimeters (c.c.)	0.06102	Cubic inches	Imperial gallons	277.274	cu.in.
Cubic inches (cu.in.)	16.387	c.c.	Liters (l.)	1.057	Quarts
Liters (l.)	0.264	Gallons	Quarts (qt.)	0.946	Liters
Gallons (gal.)	3.785	Liters	Cubic centimeters (c.c.)	0.0339	Fluid ounces
U.S. gallons	1.2	Imperial gals.	Fluid ounces (fl.oz.)	29.57	c.c.
Imperial gallons	4.537	Liters			

OTHERS

Metric horsepower (qs.)	1.014	bhp.	Foot-pounds (ft.-lbs.)	0.1383	m-kg.
Brake horsepower (bhp.)	0.9859	ps.	Kilometers per liter	2.352	mph.
Meter-Kilogram (m-kg.)	7.234	Foot-pounds	(km/l.)		
Kilograms/sq.cm.	14.22	Pounds/sq.in.	Miles per gallon (mpg.)	0.4252	km/l.
		(Lbs/in. ² or psi)			

Centigrade (C° x 9/5) + 32 = Fahrenheit (F°)

CLEANING AND STORAGE

A. Cleaning

Frequent thorough cleaning of your motorcycle will not only enhance its appearance but will improve general performance and extend the useful life of many components.

1. Before cleaning the machine:
 - a. Block off end of exhaust pipe to prevent water entry; a plastic bag and strong rubber band may be used.
 - b. Remove air cleaner or protect it from water with plastic covering.
 - c. Make sure spark plug, gas cap, oil tank cap, transmission oil filler cap and battery caps are properly installed.
2. If engine case is excessively greasy, apply degreaser with a paint brush. Do not apply degreaser to chain, sprockets, or wheel axles.
3. Rinse dirt and degreaser off with www.legends-yamaha-enduros.com garden hose, using only enough hose pressure to do the job. Excessive hose pressure may cause water seepage and contamination of wheel bearings, front forks, brake drums, and transmission seals. Many expensive repair bills have resulted from improper high-pressure detergent applications such as those available in coin-operated car washes.
4. Once the majority of dirt has been hosed off, wash all surfaces with warm water and mild, detergent-type soap. An old tooth brush or bottle brush is handy to reach those hard-to-get-to places.
5. Rinse machine off immediately with clean water and dry all surfaces with a chamois skin, clean towel, or soft absorbent cloth.
6. Immediately after washing, remove excess moisture from chain and lubricate to prevent rust.
7. Chrome-plated parts such as handlebars, rims, spokes, forks, etc., may be further cleaned with automotive chrome cleaner.
8. Clean the seat with a vinyl upholstery cleaner to keep the cover pliable and glossy.

9. Automotive-type wax may be applied to all painted and chrome-plated surfaces. Avoid combination cleaner-waxes. Many contain abrasives which may mar paint or protective finish on fuel and oil tanks.
10. After finishing, start the engine immediately and allow to idle for several minutes.

B. Storage

Long term storage (30 days or more) of your motorcycles will require some preventive procedures to insure against deterioration. After cleaning machine thoroughly, prepare for storage as follows:

1. Drain fuel tank, fuel lines, and carburetor float bowl(s).
2. Remove empty fuel tank, pour a cup of 10W. to 30W. oil in tank, shake tank to coat inner surfaces thoroughly and drain off excess oil. Reinstall tank.
3. Remove spark plug, pour about one tablespoon of 10W. to 30W. oil in spark plug hole and reinstall spark plugs. Kick engine over several times (with ignition off) to coat cylinder walls with oil.
4. Remove drive chain. Clean thoroughly with solvent and lubricate with graphite-base chain lubricant. Reinstall chain or store in a plastic bag (tie to frame for safe-keeping).
5. Lubricate all control cables.
6. Remove battery and charge. Store in a dry place and re-charge once a month. Do not store battery in an excessively warm or cold place (less than 32°F or more than 90°F).
7. Block up frame to raise both wheels off ground. (Main stands can be used on machines so equipped.)
8. Deflate tires to 15 psi.
9. Tie a plastic bag over exhaust pipe outlet(s) to prevent moisture entering.
10. If storing in humid or salt-air atmosphere, coat all exposed metal surfaces with a light film of oil. Do not apply oil to rubber parts or seat cover.

CABLE ROUTING DIAGRAMS




Fig. 183




Fig. 185




Fig. 184

MAINTENANCE RECORD

DATE

MILES

ITEM

REMARKS

DATE	MILES	ITEM	REMARKS

www.legends-yamaha-enduros.com

WARRANTY (for U.S.A. and Canada)

Yamaha's warranty on the TY80B extends for a period of 90 days from date of sale. Other conditions regarding your warranty coverage are explained in the Warranty Policy, and your Owner's Warranty Guide Book.

If any questions arise regarding warranty, consult your Authorized Yamaha Dealer, or:

U.S. DISTRIBUTOR

Yamaha International Corporation

6610 Orangethorpe

Buena Park, California 90620

U.S.A.

www.legends-yamaha-enduros.com

CANADIAN DISTRIBUTOR

Yamaha Motor Canada LTD.

1350 Verdun Place

Richmond, B.C.

Canada

www.legends-yamaha-enduros.com



YAMAHA MOTOR CO., LTD.

LIT-11624-51-01

SINCE 1887

IWATA, JAPAN

Printed in Japan
74 · 4 · 5.0 x 1 ©