

YAMAHA RD200A

Owner's Manual

www.legends-yamaha-enduros.com

NOTICE

Yamaha Motor Company and its U.S. subsidiary, Yamaha International Corporation, are confident you will enjoy your new Yamaha to the utmost. We have made every effort to provide you with a safe, well engineered and constructed product.

This Owner's Manual will acquaint you with several features and maintenance procedures concerning your Yamaha. However, if you are unfamiliar with the product, features or procedures outlined in this booklet we strongly urge you to consult your Authorized Yamaha Dealer for additional information.

Please review your owner's warranty guide book thoroughly regarding your warranty obligations.

RD200A OWNER'S MANUAL

1st Printing

www.legendsofyamaha-enduros.com

October 1973

All rights reserved, Yamaha International Corporation
and/or Yamaha Motor Co., Ltd., Japan.

Yamaha International Corporation
P.O. Box 6600, Buena Park, Cal.

P/N LIT-11623-97-00

FOREWORD

It is our greatest pleasure that you are now a member of the Yamaha RD200A riders. The Yamaha RD200A now ready for your use and service, is a motorcycle which has been manufactured by us under the strictest quality control in our Factory. Naturally, like any other model, proper handling, and daily inspection, adjustment and care are a prerequisite for successful top performance of this model. This Manual discusses these points to assist you in your best operation and handling of the Yamaha RD200A. Your perusal of the various items in this Manual is sincerely requested.




YAMAHA MOTOR CO., LTD.
SERVICE DEPARTMENT

CONTENTS


Contents	3
General View	4
Features	6
Machine Identification	8
Yamaha Autolube	9
Control Function	10
Basic Instruction	16
Operation	17
Service Tools	24
Lubrication and Maintenance Chart	24
Servicing	29
Warranty Information	56
Requirements for a Good Motorcyclist	57
Troubleshooting	58
Specifications	59
Consumer Information	63

www.legends-yamaha-enduros.com

General view



Right hand side view



Left hand side view

Features

1. "TORQUE INDUCTION" System

Another new type engine has made its debut! The reed valve has been adopted as a new Intake system to Yamaha's RD200A. This, together with the 7-port cylinders, ensures excellence in steady engine performance from low to high speed running.

2. Highly-dependable Yamaha Autolube

Yamaha Autolube provides superior engine lubrication that extends the service life of the engine.

3. Easy Starting

The engine can be started by simply disengaging the clutch and kicking the kick pedal without shifting gears back to neutral. This is a valuable convenience to the rider.

www.legends-yamaha-enduros.com

4. Adjustable Rear Cushion

The rear cushions are adjustable to check positions. The rider can adjust spring tension to compensate for varying weights, speeds, and road conditions.

5. Front Fork Design

The Yamaha RD200A employs a front fork design well-known for its strength and superior handling characteristics. Its use assures the rider of the ultimate suspension for even the roughest terrain.

6. Speedometer and Tachometer

A speedometer and tachometer are standard equipment. The individual units are separately mounted for


maximum visibility. An additional feature of the speedometer is an odometer which can be reset by tenths to zero for trip or enduro purposes.

7. Carburetor with built-in starter jet


Yamaha's carburetor is already well-known for providing easy starting. Equipped with this unique starter jet, the Yamaha RD200A is quick starting under all conditions.

www.legends-yamaha-enduros.com


Machine Identification



The frame serial number (a) is stamped on the right of the steering head pipe, and the engine serial number (b) is located on top of the crankcase (L). These numbers are required when registering the motorcycle and also for processing warranty claims. Further, when ordering spare parts, engine serial number and frame serial number should be started.



What is Yamaha Autolube?





Autolube is the best lubricating system available for 2 stroke of oil injected straight to the engine is controlled by a compact, high-precision oil pump. The pump plunger, driven by a reduction gear, has its output controlled by throttle opening, and engine speed. Because of the wide range of control Autolube offers, precisely the right amount of oil is available at all time. Autolube eliminates a number of major problem unavoidable with premix lubrication. This means both improved performance and reliability.

www.legends-yamaha-enduros.com

Yamaha Autolube Features:

1. Oil consumption is greatly reduced, up to 1/3 less than pre-mix systems.
2. More effective lubrication results because the oil enters the engine in larger size droplets.
3. There is much less unwanted carbon deposited on the spark plug, cylinder head, piston and exhaust system!
4. There is much less exhaust smoke.
5. Refueling is simplified, gas and oil are kept inseparate tanks.
6. Because poor quality oils can easily be avoided, and because the possibility of mismeasuring or inadequately mixing fuel is eliminated, Autolube offers completely consistent lubrication.
7. Longer engine life. The Autolube injection system provides lubricating and cooling oil to the internal moving parts of the engine at all times. Even when the throttle is shut off the engine is receiving lubricating oil.

Control Function




1. Main switch

The following chart shows the key position at which the lamps, horn and ignition circuit are switched on or off: (The circle (○) denote "Switch on")

Parts Name	Key position			Instructions	
	OFF	I	II		III
Ignition circuit		○	○	I Kick or electric starting II Push starting	
Head lamp		○		○	When lighting switch is turned on.
Tail lamp		○		○	When lighting switch is turned on. Use III when parking at night.
Stop lamp		○			The brake is applied.
Neutral lamp		○			When shift to neutral
Meter lamps		○		○	When lighting switch is turned on.
Charge lamp		○			Goes off when engine starts.
Horn		○			Push the horn button.
Flasher almps		○			Turn on left handlebar switch.

2. Fuel pet cock


To fill the carburetor float bowls, set the fuel pet cock lever to the OPEN position. If you should run low of fuel on the road, turn the lever to RE-SERVE position. With just over a quart of fuel,



remaining you can drive nearly 25 miles (40 km), enough to get you to the nearest service station for refueling. When parking or storing your machine, be sure that the lever is in the STOP position.


3. Handlebar switch

- (a) Horn button To sound the horn, depress the horn button.
- (b) Dimmer switch To raise the headlight beam, pull the switch toward you. To lower the beam, push the switch forward.



www.legends-yamaha-enduro.com

- (c) Flasher switch To signal a right turn, push the switch to the right. For left turns, push switch left.
- (d) Lighting switch To light the head lamp, tail lamp and meter lamps push the head lamp switch forward.
- (e) Starter button To start the engine, push the starter button.
- (f) Kill switch Make sure that the "Kill" switch is on "RUN". The "Kill" switch has been equipped to ensure safety in




an emergency such as when the motorcycle is upset or when trouble takes place on the throttle system.

CAUTION: The engine will not start when the "Kill" switch is turned to "OFF".

4. Indication lamps


- (a) Flasher pilot lamp (ORANGE)
When flasher switch is on, the pilot lamp flashes.
- (b) Neutral lamp (GREEN)
Mounted within the tachometer shell, the neutral indicator glows whenever the transmission is in neutral.
- (c) High beam indicator (RED)
Mounted on middle of the meter bracket, the high beam glows whenever the headlight high beam is in use.
- (d) Charge lamp (RED)
Charge lamp goes out when charging starts

www.legends-yamaha-enduro.com




5. Front brake (Right handlebar lever)

The right handle lever controls the operation of the front brake. The front brake is of the drum and is adjustable at two points which is adjustment will be explained later.



6. Steering lock

Turn the handlebar to the left, insert the steering lock key and turn it 45° counterclockwise. Remove the key after checking to see that the front forks are securely locked. Be sure to lock your forks whenever you park.



7. Rear cushion adjustment

Place machine on mainstand, insert screwdriver as show, turn it to change the spring rate.


The rear suspension should be adjusted to fit the load, speed and road conditions.

Standard A


Intermediate (3 positions)

Stiff C

www.legends-yamaha-enduros.com



※ Adjust both right & left cushions to the same position





9. How to read the tachometer

A tachometer is provided so that the rider can easily maintain engine RPM sufficient to keep the engine within the power curve. For maximum performance accelerate in each gear to 7,500 rpm or at most to 8,000 rpm before shifting. The best range for city driving is 3,500 to 4,000 rpm in lower gears. In this range the engine has ample power and yet is quite docile. Never lug your engine! (i.e. operate below 3,500 r.p.m.) It is recommended not to use red-zone 9,000 - 12,000 rpm.

www.legends-yamaha-enduros.com

CAUTION
see "Break-in" section for additional information.

Basic Instruction



1. Gasoline

Use fuel with an octane rating of 90+. Some regular fuels and most mid-range have 90+ octane ratings. Ethyl grade fuels usually have octane ratings in excess of 100. In addition, they have considerable tetra-ethyl lead added which can cause spark plug problems. Whenever possible, use fresh, name brand, gasoline low lead rating.

2. Oil


We recommend that your first choice be YAMA-LUBE, which can be purchased from any Yamaha dealer. If for any reason you use another type of oil, choose from the following list, which is in descending order of preference.

- | |
|--|
| a. Another brand of 30 wt. two-stroke oil designed for air cooled engines. |
| b. A 30 wt. two-stroke oil designed for water cooled engines. |
| c. A 30 wt., quality, detergent type automotive oil. |

Note: Under extremely cold conditions ($+32^{\circ}$ and below), Some Oils become exceedingly thick and do not flow as readily.

Consult your dealer regarding the oil you are using and the conditions under which you are riding.

Operation



1. Before starting

Before you start for a ride you should check several points for safety. In particular:

- a Do you have enough fuel?
- b Do you have enough oil?

If the oil is below the level mark in the glass port, add oil. Make sure that the oil is sufficient for your driving plan by using an oil level gauge. (Refer to "Basic instruction" for type of oil)

- c Are your tire pressures correct?

Incorrect tire pressures affect the comfort, handling, acceleration and life of tires. Incorrect tire pressures can also lead to accidents!

www.legends-yamaha-entana.com

	Front tire	Rear tire
Normal riding	23 lbs/in ² (1.6 kg/cm ²)	29 lbs/in ² (2.0 kg/cm ²)
Continuous high speed riding	29 lbs/in ² (2.0 kg/cm ²)	34 lbs/in ² (2.4 kg/cm ²)

- d Do both brakes and the stoplamp work?


- e Are the lights and horn working?

Check the headlamp, taillamp, meterlamps, and indicating lamps. The few minutes you save by not checking are not worth being stranded without lights!

2. Starting

- a Turn the fuel petcock lever to the "OPEN" position.
- b Insert the ignition Key and turn it to the #1 position

The use of a primary kick starting system enables you to start the engine either in gear or in neutral (if in gear, pull in the clutch lever)



A Starting in cold weather

Most engine are difficult to start in cold or freezing weather.

YAMAHA Motorcycles however, uses a carburetor with a built in starter jet that gives a richer mixture for easier cold weather starting.

a Pull the starter knob.


b Start the engine with the kick starter or electric starter, keeping the throttle closed.

B Starting when your engine is warm

When your engine is warm, after riding or in warm weather, don't use the starter lever. Open the throttle slightly ($\frac{1}{4}$ turns or less) and kick the starter.

C Warming up

To get maximum engine life, always "warm up" the engine for a few minutes before starting off. Never accelerate hard with a cold engine! To see whether or not the engine is warm, see if it responds to throttle normally. Don't forget to raise the starter lever after the engine is warm.



3. Shifting and Acceleration

RD200A has a 5-speed transmission. The transmission allows you to control the amount of power you have available at a given speed or starting accelerating, climbing hills, etc.

The use of the change pedal is illustrated at the left.

To shift into NEUTRAL, depress the change pedal to the end of its travel (you will feel a stop when you are in low gear), then raise it slightly. legends-yamaha-enduros.com

If you are in neutral, the green light in the tachometer will be on.

- a. Pull the clutch lever to disengage the clutch.
- b. Shift into FIRST gear.
- c. Open the throttle gradually, and, at the same time, release the clutch lever slowly.
- d. At 10 to 15 mph, close the throttle, and at the same time pull in the clutch lever quickly.
- e. Shift into SECOND, Be careful not to shift into neutral.
- f. Open the throttle part way and gradually release the clutch lever.
- g. To accelerate or decelerate, use the same procedure to shift into THIRD, FOURTH, and FIFTH gears.
- h. Except for competition or high speed driving, shift so that the engine speed remains between 4,000 ~ 5,000 rpm. This is the optimum operating range for the engine.

a **Going Uphill**

When starting to climb a gentle grade, open the throttle little by little to avoid losing engine speed and power.

When climbing a steep grade, shift down (for example) from THIRD to SECOND or from SECOND to FIRST as required.

b **Going Downhill**

On a long down grade or sharp descent, don't rely on the brakes alone, but use the engine compression as a brake: shift into THIRD or SECOND as required by the grade and close the throttle.

CAUTION: Never attempt to turn off the ignition switch on a long hill.

This may only cause the spark plug to foul, in addition to being unsafe.

www.legends-yamaha-enduros.com

4. Stopping

There are several ways to stop.

Pulling in the clutch lever and twisting the throttle grip in the closed direction will permit you to gradually glide to a stop. Downshifting through the gears, using the drag of the engine to slow down is another. However, the best method, and the one most universally used, is to use both engine compression (downshifting through the gears as the machine slows) and the front and rear brakes.

When stopping, gradually apply the rear brake while twisting the throttle grip in the closed direction. After the rear brake starts to take hold, gradually apply the front brake.

As the machine continues to slow shift down through the gears using engine compression to aid the slowing effect. When shifting down, watch the tachometer to see that the engine does not over-revolution.

Note: During periods of Inclement weather, snow, rain, sleet, or ice, or on poor road surfaces where traction is minimal, or in a sharp corner, IT IS NOT ADVISABLE TO FIRMLY APPLY THE FRONT BRAKE. While it is true that the front brake supplies the greater portion of braking portion of braking power, it is also true that stability can be upset very easily if it is used incautiously under the above conditions.

5. Cruising

A frequently asked question is "What rpm should I cruise at?"

The BREAK-IN section provides limitations when the motorcycle is new, but once the engine has been broken in, then we suggest that you follow these guide lines. For sustained load and throttle conditions, such as those encountered on open highways, cruise at $\frac{3}{4}$ throttle or at $\frac{3}{4}$ of the rpm "red line", whichever comes first. Always bear in mind though, the maximum allowable speed limit for the area through which you are riding. This is a recommendation, not a "hard and fast" rule. Any modification or personalization of the running gear could possibly change the operating range most comfortable and most

efficient for the engine.

6. Break-in

THERE IS NEVER A MORE IMPORTANT PERIOD, IN THE LIFE OF YOUR RD250 THAN THE PERIOD BETWEEN ZERO AND A HUNDRED MILES. For this reason we ask that you carefully read the following material.

Because the engine is brand new, you must not put an excessive load on it during the first several hours of running. You could look at it in this manner: During the first 100 miles the various parts in the engine wear and polish themselves to the correct operating clearances. During this period prolonged full throttle operation, or any condition which might result in excessive head and cylinder temperatures, must be avoided. However, momentary full throttle operation, under load, (2-3 seconds maximum) does not harm the engine. Each full throttle acceleration sequence should be followed with a substantial rest period for the engine by cruising at lower rpm's so the engine can rid itself of the temporary build up of heat. The method for breaking in an RD200A is quite simple. (See following page.)

Break-in (continued)

- a 0 to 100 miles: Avoid operation above 4,000 rpm.
Allow a cooling off period of 5 to 10 minutes after every hour of operation.
Vary the speed of the motorcycle from time to time. Do not operate it at one, set, throttle position.


- b 100 to 250 miles: Avoid prolonged operation above 5,000 rpm.
Allow the motorcycle to rev freely through the gears but do not use full throttle at any time.

- c 250 to 500 miles: Avoid prolonged full throttle operation.
Avoid cruising speeds in excess of 6,000 rpm.
www.legends-yamaha-enduros.com

- d 500 miles and beyond: Avoid prolonged full throttle operation.
Avoid engine speeds in excess of 7,000 rpm. Vary speeds occasionally.

Note: See lubrication and maintenance charts for initial 300, 1000, and 2000 mile service.

Service Tools



The servicing information included in this manual is intended to provide you, the owner, with the necessary information to provide a means for doing your own preventive maintenance and minor repairs.

The tools provided in the owner's tool kit are sufficient for this purpose, except that a torque wrench is also necessary to properly tighten nuts and bolts.

(See torque chart, P.28)

Should you desire additional service information on your RD200A a copy of Service Manual can be purchased from any Authorized Yamaha Dealer or direct from the Literature Department, Yamaha International Corp., P.O. Box 6600, Buena Park, Calif. (90620).

(Canadian Distributor: Yamaha Motor Canada LTD., 1350 Verdun Place Richmond, B.C., Canada)

Lubrication and Maintenance Charts

These charts should be considered strictly as a guide to general lubrication and maintenance periods. You must take into consideration that weather, terrain, geographical locations, and a variety of individual uses all tend to demand that each owner alter this time schedule to match his environment. For example, if the motorcycle is continually operated in an area of high humidity, then all parts must be lubricated much more frequently than shown on the chart to avoid the ravages of water on metal parts. If you are in doubt as to how closely you can follow these time recommendations, check with the YAMAHA dealer in your area.

Lubrication Intervals

	Item	Type	Initial			Thereafter Every	
			300 miles	1,000 miles	2,000 miles	2,000 miles	4,000 miles
1	Brake cam shaft	G		○	○	○	
2	Wheel bearing	G			○		○
3	Clutch cable	M/O		○	○	○	
4	Tacho, speedometer cable	G			○	○	
5	Meter gear unit	G			○	○	
6	Steering ball race	G					○
7	Front fork oil	M/O	○		○	○	
8	Brake pedal shaft	G		○	○	○	
9	Change pedal shaft	M/O,G			○	○	
10	Accelerator grip	G		○	○	○	
11	Transmission oil	M/O	○	○	○	○	
12	Dynamo lubricator	G					○
13	Stand shaft	M/O,G					○
14	Rear arm pivot shaft	G			○	○	
15	Drive chain	M/O		○	○	○	

- ※ G Grease
- ※ M/O Motor oil

Periodic Maintenance Intervals

	Item	Preoperation check	Initial			Thereafter Every	
			300 miles	1,000 miles	2,000 miles	2,000 miles	4,000 miles
1	Front and rear brake adjustment (F.R)	○	○	○	○	○	
2	Clutch adjustment	○	○	○	○	○	
3	Transmission oil replacement		○	○	○	○	
4	Front fork oil replacement		○		○	○	
5	Grease up			○	○	○	
6	Battery electrolyte refilling	○	○	○	○	○	
7	Spark plug cleaning		○	○	○	○	
8	Ignition timing adjustment		○	○	○	○	
9	Fuel pet cock cleaning		○	○	○	○	
10	Carburetor adjustment			○	○	○	
11	Carburetor cleaning						○
12	Air cleaner cleaning			○	○	○	
13	Cylinder, piston cleaning			○		○	
14	Silencer muffler cleaning			○		○	
15	Drive chain adjustment, oiling		○	○	○	○	
16	Autolube pump adjustment		○	○	○	○	
17	F.R.wheel inspection	○	○	○	○	○	
18	Bolt, Nut retightening	○	○	○	○	○	
19	Spoke, Rim inspection		○	○	○	○	

Be sure to check the above points before long-distance touring.

Service Notes:

1. DRIVE CHAIN: In addition to tension and alignment, chain must be lubricated every 200-250 miles. If unit is subjected to extremely hard usage, such as racing or dirt riding, chain must be checked constantly. See "Lubrication Intervals" for additional details.
2. AIR FILTER: Must be clean at all times to function properly. Remove and clean filter at least once per month or every 2,000 miles, more often if possible.

Note: If unit is subjected to extremely hard usage, such as dirt riding, etc., clean filter daily.

Lubrication recommendation

Transmission oil	Use a 10w/30 multi-viscosity oil, or a quality 30wt oil. (SAE "SE")
Swing arm shaft grease Brake actuating cam grease. Steering head bearing grease. Rear brake pivot point grease. Throttle grip grease.	Use an all purpose, chassis-type grease that does not break down easily in water (Shell and Lubriplate, as examples, carry this grease).
Front fork oil.	Use 10w/30, 20wt, or 30wt oil for street, use 30 or 40wt oil for dirt (nonfoaming, if possible).
Autolube oil.	See BASIC INSTRUCTION section.

A Note To The Owner

Periodic Maintenance and Lubrication Interval charts are included within this manual to provide you with the necessary information for appropriate preventive maintenance. If any procedure in the charts is not completely understood, or not covered in this manual, please consult your Authorized Yamaha Dealer for the necessary service.

In some instances, failure to have the machine properly serviced by your dealer will void the Warranty on your machine. Therefore, it is most important to study the charts, this manual, and your Warranty obligations most carefully.

SERVICE DEPARTMENT

Torque

All fittings require a minimal amount of torque during tightening to keep them from vibrating loose. Excessive tightening will only lead to stripped threads and broken studs. As a rule of thumb, use the following tightening chart:


STUD SIZE	TORQUE
6 mm	90 in/lbs.
7 mm	135 in/lbs.
8 mm	180 in/lbs.
10 mm	300 - 350 in/lbs.
12 mm	350 - 400 in/lbs.
14 mm	400 - 450 in/lbs.
Axle Nuts	500 - 600 in/lbs.
Spark Plugs	230 - 250 in/lbs.

Servicing

1. Clutch cable

The clutch cable requires periodic lubrication to prevent the cable strands from rusting or hanging up in the casing. First, disconnect the cable from the clutch lever by screwing the adjuster all the way back to the cable casing. This will provide enough free play, in the cable for you to slip the cable out of the lever holder through the slot in the lock nut, adjuster, and holder. Hold the cable upright and allow several drops of lubricant to flow down the cable. Hold the cable upright for several minutes to permit complete lubrication.


If the cable needs to be replaced, then perform the steps above and disconnect the cable at the lever. Next, disconnect the cable at the engine. Begin by taking off the cover that houses the clutch activating mechanism (left side of the engine). Looking at the inside of this cover, you will see the clutch actuating arm. Push the arm up and lift the cable end off. Removing the old cable and hooking up the new one will take but a few moments.



2. Clutch adjustment


The RD200A has two clutch adjustments. The first adjustment, located at the handlebar lever, is used to take up slack from cable stretch and to provide sufficient free play so that the clutch engages and disengages completely. The picture left illustrates all the parts involved in making the adjustment.

- a First, loosen the lock nut. Then turn the adjuster either in or out depending on which direction is necessary to arrive at 1/16"-1/8" (2-3mm) free play.



- b The second adjustment is located behind the adjusting cover. Removing the cover will expose the adjusting set screw and lock nut. Loosen the lock nut, rotate the set screw in until it lightly seats against a clutch push rod that works with the set screw to operate the clutch. Back the set screw out $\frac{1}{4}$ turn and tighten the lock nut. This adjustment must be checked because heat and clutch wear will affect this free play, possibly enough to cause incomplete clutch operation.


www.legends-yamaha-enduros.com



3. Front brake adjustment

As with the clutch, there are also two adjustments to check.

These two adjustments are located at the brake lever and the front hub. In this situation though, only one brake adjustment is necessary, using either of these two places to make the adjustment. Preferably, it is much easier to make it at the brake lever. This is done by loosening the lock nut, and screwing the adjuster in or out until you have 3/16" (5~8 mm.) free play.



4. Rear brake adjustment


The correct free play of the rear brake pedal is about 1.0 in. (25 mm.). Adjust by turning the adjusting nut at the end of the rear brake rod a half turn at a time. After adjusting the brake, make sure the brake light is working. If not, readjust the stoplight switch.

Note: Inspect the brake linings for wear and clean the brake shoes and drums every 2,000 miles (3,000 km). Always keep the shoes and drums free of oil.

Rear brake adjustment should be performed any time the wheel is moved or removed.

5. Front wheel



Work that might need to be done on the front wheel assembly includes tire or tube exchange, brake shoe replacement, hub/spokes/rim assembly replacement, and brake assembly maintenance and inspection. The following are the steps necessary to dismantle the front wheel, step by step, and you should proceed with the steps until you have removed the part to be replaced. You, as the owner, can replace everything but the hub, the spokes, or the rim. To individually replace spokes or rim requires that the spokes be "replaced". This should be done by a competent dealer as the spokes must be positioned and torqued correctly. If not done properly wheel alignment will not be correct and steering will be negatively affected.



6. Front wheel removal

To carry out front wheel repair, you must remove the wheel.

- a Disconnect the brake cable at the front brake lever.
- b Disconnect both the brake cable and speedometer cable from the front wheel hub plate.
- c Remove the cotter pin and front wheel nut.



www.legends-yamaha-enduros.com



d Loosen the front wheel axle pinch nuts.

- e Remove the front axle by simultaneously twisting and pulling out on the axle.
- f Brace the front of the machine off the ground and remove the wheel assembly.
- g During reassembly, make sure the speedometer torque tab is correctly positioned, the axle nut is torqued, the pinch bolts are torqued, and a new safety cotter pin is installed-in that order.

www.legends-yamaha-enduros.com


7. Rear wheel

A complete list of rear wheel parts that you can remove, certain precautions and limitations that must be adhered to, checking for wheel run-out, and checking for spoke tightness can all be found in the FRONT WHEEL section. In order for you to carry out those steps that are possible, a list of procedures is given explaining how to completely disassemble the rear wheel assembly.



8. Rear wheel removal

- a Remove the tension bar and the brake rod from the rear shoe plate. Presence and location of the lock washer and cotter pin. These are safety parts and must be included during reassembly.
- b Loosen the lock nuts and the chain tension adjusting bolts on both right and left sides.




- c Remove the cotter pin.
- d Remove the cotter pin and rear wheel shaft nut.
- e Remove the right hand chain adjuster and distance collar.
- f Remove the chain adjusters distance collar and pull back the wheel ass'y.

www.legends-yamaha-enduros.com

The brake plate can now be easily slipped out of the rear wheel hub. The brake plate carries both brake shoes. They can be left in place on the brake plate for measurement, as shown below, or they can be lifted off for replacement or maintenance. The two brake shoes are held in place by two springs. These springs hold the two shoes to the brake actuating cams. Removal of these springs, or spreading them, will allow the shoes to be lifted off. Whenever you have the brake plate off the wheel assembly, it is very good policy to apply a small amount of grease to the brake actuating cams.


Shown immediately below are two steps that must be performed periodically to maintain maximum stopping efficiency. The brake linings and brake drum must be in correct working condition, and these steps do much to guarantee perfect working order



9. Brake shoe

Measure the outside diameter of the brake shoe set with slide calipers.

If front brake shoe measures less than 175 mm (6.9 in.), and rear brake shoe is 145 mm (5.7 in.), replace it. Smooth out any rough shoe surface with sand paper or with a file.



10. Brake drum, Rims, Spokes (Front and rear wheels)

Oil or scratches on the inner surface of the brake drum will impair braking performance or result in abnormal noises. Remove oil by wiping with a rag soaked in lacquer thinner or solvent. Remove scratches by lightly and evenly rubbing with emery cloth.

There are also checks that you can perform to determine if wheel work is necessary for your dealer to do. First, check for any loose spokes. This can be checked by bracing the front end off the ground so that the front wheel can spin free. Slowly revolve the front wheel and at the same time let the metal shaft of a fairly heavy screwdriver bounce off each spoke. If all the spokes are tightened approximately the same, then the sound given off by the screwdriver hitting the spokes should sound the same. If one spoke makes a dull flat sound, then check it for looseness.

While you have the front end up in the air, you should check that the front wheel does not have too much run-out. "Run-out" is the amount the front wheel deviates from a straight line as it spins.

Secure the front forks to keep them from turning, spin the front wheel, and solidly anchor some sort of a pointer about 1/8" away from the side of the rim.

As the wheel spins, the distance between the pointer and the rim should not change more than 1/16" total. Any greater fluctuation means that you should have your dealer remove this rim warpage by properly adjusting the spokes.

11. Tire repair

First, remove the valve cap and valve stem lock nut. Empty all the air out of the tire. Use two tire removal irons (with rounded edges) and begin to work the tire bead over the edge of the rim, starting 180° opposite the tube stem. Take care to avoid pinching the tube as you do this. After you have worked one side of the tire completely off the rim, then you can slip the tube out. Be very careful not to damage the stem while pushing it back out to the rim hole. If you are changing the tire itself, then finish the removal by working the tire off the same rim edge just previously mentioned.

Reinstalling the tire assembly can be accomplished by reversing the disassembly procedure. The only difference in procedure would be right after the tube has been installed, but before the tire has been completely slipped onto the rim, inflate the tube. This removes any creases that might exist. Release the air continue with reassembly. Also, right after the tire has been completely slipped onto the rim, check to make sure that the stem is squarely in the center of the hole in the rim.

Inflate the tire to specified pressure


Front	23 lbs/in ² (1.6 kg/cm ²)	Normal riding
Rear	29 lbs/in ² (2.0 kg/cm ²)	
Front	29 lbs/in ² (2.0 kg/cm ²)	High speed riding
Rear	34 lbs/in ² (2.4 kg/cm ²)	

12. Drive chain

Because the chain consists of an extraordinary amount of parts that rub against one another, it is prone to wear if it is not maintained constantly and correctly. Without any lubrication, a chain can wear out within 100 miles. You should develop a habit of servicing the chain on a regular schedule. This habit is especially important if you spend the major portion of your time riding in the dirt where dust and dirt can readily work into the chain links.

- a Lubrication - - there are several excellent pressure can lubricants available. Use a brush and a rag to wipe off any accumulation of dirt, then spray a liberal amount of lubricant on the chain at least every 200 miles.
- b Cleaning - - Completely saturate the chain with solvent to remove as much dirt as possible. Drain and dry the chain thoroughly. Immediately after the chain has dried completely, lubricate to prevent any rust from forming.
- c Adjustment - - proper drive chain up and down free play, with the rider in position, should equal $\frac{3}{4}$ " (20mm) when measured at the center of the lower section of chain.
Follow these steps to obtain the correct free play:

CAUTION: During machine cleaning, do not remove chain lubricant.
See "Cleaning" section for additional details.




Drive chain adjustment

- a Remove the cotter pin and loosen the wheel nut (1) and sprocket wheel nut (2).
- b Loosen the chain adjusting bolt lock nuts (3).
- c Rotate the adjusting bolts in or out, whichever is needed to obtain the correct free play, and at the same time make sure that both ends of the axle are positioned evenly. This can be checked by utilizing the marks on the very end of the swing arms, just above and to the rear of the rear wheel nuts.
- d After completing the adjustment, retighten all the lock nuts.
- e Finally, be sure to bent a cotterpin and check for correct brake pedal operation as it could have changed due to the chain adjustment.

13. Battery


The life of your battery depends greatly on how well you keep it serviced. In order to service it completely and correctly, there are certain facts that you must know.

- a Always keep the battery fluid level between the "Maximum" and the "Minimum" level. It should be checked at least once a month, and more often during hot weather. If the battery needs filling, use distilled water. Do not use tap water as it usually contains minerals that can be harmful to the life of the battery.



- b If for any reason the battery has become discharged, and you are going to charge it yourself, use a "trickle charger" that has no more than a one amp maximum. Also, make sure that all the battery caps have been taken off and that the rubber battery breather tube is not clogged or pinched shut. A charging battery creates gas, and pressure could build up in the battery if all the outlets were plugged up. Charge battery in a well ventilated area away from open flame.
- c If the motorcycle is to be stored for more than a month, then remove the battery, have it fully charged, and store it in a cool dry storage area. If storage time is going to be lengthy, it is best to leave the battery with your dealer with specific instructions to recharge the battery every month or so. This procedure is necessary to insure maximum battery life.

When reinstalling the battery, be sure to hook up the RED lead to the positive terminal and the BLACK lead to the negative terminal (the polarity of each is stamped just below each terminal).




14. Throttle cable and grip lubrication

The throttle twist grip assembly should be greased at the time that the cable is lubricated, since the grip must be removed to get at the end of the throttle cable. Two screws clamp the throttle grip to the handlebar. Once these two are removed, the end of the cable can be held high to pour in several drops of lubricant. With the throttle grip disassembled, coat the metal surfaces of the grip assembly with a suitable all-purpose grease to cut down friction.

www.legends-yamaha-enduros.com

15. Carburetor

There are only three adjustments on the carburetor that do not require the services of a mechanic: the idle mixture, engine idle speed, and throttle cable slack. Because the carburetor is such a critical part of the engine, any carburetor disassembly should be done by an experienced mechanic.



a Idle mixture

To set the idle mixture you must turn the idle pilot screw (#1) in until it lightly seats, then back it out $1\frac{1}{4}$ turns. - - no more or no less. This is a factory setting that can be set with the engine stopped.

b Idle speed


Start the engine and let it warm up. Next, screw the throttle stop screw (#2) in or out, whichever direction is necessary for the engine to idle between 1,150 and 1,250 rpm (check tachometer).

www.legends-yamaha-enduro.com

c Throttle cable slack

After engine idle speed has been set, then loosen the cable adjuster lock nut and turn the adjuster on top of the carburetor until there is 1 mm (0.04") of slack in throttle cable 'B'. Retighten the lock nut.

Make the second throttle cable slack adjustment right at the throttle grip. There is a lock nut and adjuster where cable 'A' meets cable guide 'A'. Loosen the lock nut and turn the adjuster until there is 0.5 - 1.0 mm (0.02 - 0.04") slack in throttle cable 'A'. Retighten the lock nut.





Note: To measure the amount of cable slack, slide the cable back and forth over the throttle wire, and see how much end gap exists between the cable end and top of the carburetor (or cable guide 'A', if checking throttle cable 'A' slack).

www.legends-yamaha-enduros.com

16. Throttle cable replacement

Replacement of this cable should be left to your dealer as it is complicated, and carburetor and Autolube adjustments are affected.



17. Autolube pump cable adjustment


Close the throttle grip completely, then twist it open until all cable slack is removed, but stop before the slides start to lift.

Adjust the pump cable so the mark on the pump pulley lines up with the 'adjust pulley guide pin'. The Autolube cable adjuster is located at the bottom end of the cable, screwed into the top of the right case cover.

IMPORTANT NOTE: If the pump runs out of oil, the pump must be bled to release air trapped in the pump. Remove the Phillips-head bleed screw, twist the throttle to full open position (turns the Autolube pump to maximum stroke), and rotate the plastic manual starter pump plate until only oil comes out the bleed hole (air stops coming out with the oil). Reinstall and tighten the bleed screw.

18. Fuel petcock


The petcock serves another purpose other than acting as a fuel on and off valve. A wire mesh filter is incorporated into the assembly. This filter must be removed occasionally and cleaned. Screw off the threaded cup at the bottom of the petcock and remove the filter. The filter might momentarily hang up in the petcock itself, if it does not drop down with the unscrewed cup.



When reinstalling the cup, do not overtighten as the rubber sealing washer inside could buckle and jam up into the fuel passage of the petcock.

19. Air filter

An air cleaner excludes dust and dirt from the engine. It must be clean at all times. If you drive often on dirt roads, be sure to clean it at least once a month.



a Remove the sidecover (R) and oil tank.

b Remove the cleaner case cover and take off the cleaner element.

Cleaning

Wash the foam filter thoroughly in solvent until all dirt has been removed. Squeeze all the solvent out. Pour oil onto the filter (away grade of 20 or 30wt), work it completely in, and then squeeze out the surplus oil. The filter should be completely impregnated with oil, but not "dripping" with it. Under no circumstances should you run the motorcycle without the air filter. First, dirt and dust will be able to pass through into the cylinder.

Premature engine failure will be the result. Secondly more air will flow to the engine and there will not be enough gasoline for all the air. The lean mixture will result in higher engine temperatures and possibly severe engine damage.

www.legends-yamaha-enduros.com

20. Ignition timing

Timing is of critical importance. If after both your service checkups have been completed, and if for any reason you wish to check the timing, have your dealer check for you.

21. Breaker point

Unless you are sufficiently experienced, it would be advisable for a mechanic to replace the points, as ignition timing will change when the points are replaced. As it is, points (and condenser) normally last several thousand miles.

Note: In addition to the above, changes in point gap through wear and/or filing for cleaning purposes will also change timing, have your Authorized Yamaha Dealer service the ignition for you.


22. Spark plug

The spark plug in your machine can tell you a great deal as to how the engine is operating when you know how to "read" the plug. If the engine is operating correctly, and if it is being ridden correctly, then the tip of the white insulator in the spark plug will be a light tan color (standard plug is NGK B-8HS). If, when you remove the spark plug, it is very dark brown or black, then a plug with a hotter heat range might be needed. This situation is quite common during the engine break-in period. If the insulator tip shows a very light tan color, or is actually white, or if the electrodes begin to melt, then a spark plug with a colder heat range is required. Again, if the spark plug insulator tip does not have a light tan color, have your dealer install a spark plug with a different heat range to correct the situation. Do not attempt to experiment with different heat range spark plugs yourself, as it takes an experienced eye to gauge which spark plug to use, and to gauge it the spark plug is actually at fault. It is all right though for you to replace the standard plug. Engine conditions can cause any spark plug to slowly break down. If deposits begin to build up, or if the electrodes finally become too worn, or if for any reason you believe the spark plug to not be functioning correctly, replace it. Be sure, when replacing the plug, that you always clean the gasket surface, that you use a new gasket, and that the spark plug is torqued to 19-21 ft/lbs. Also wipe off any grime that might be present on the surface of the spark plug. The plug can be taken out to be cleaned and gapped. As long as deposit build-up on the insulator is not extreme, you can use a glass bead type spark plug cleaner to quickly remove the deposits.

Use a wire type feeler gauge to set the electrode gap at 0.020" - 0.024" (0.5 mm - 0.6 mm.)

23. Transmission oil

The only servicing for you to do is to check and fill the transmission lubricating oil. The transmission dip stick is located right above the kickstarter. To check the level, warm the engine up for several minutes, screw the dip stick completely out and then just rest the stick in the hole.



Note: When checking transmission oil level with the dip stick, let the unscrewed dip stick just rest on the case threads. Also, be sure the machine is positioned straight up and on both wheels.

Commendable oil Yamaha gear oil
or SAE "SE" 10W/30 Motor oil

Amount 850 cc (0.85 qts)


Amount
www.legends-yamaha-enduros.com

The dip stick has a Minimum and a Maximum mark, and the oil level should be between the two. If the level is lower, then add sufficient 10w/30 oil to raise it to the proper level.

During the break-in period, you should replace the gear oil 30 days after the date of purchase or after 500 miles. The transmission should be drained and refilled approximately every 2,000 - 4,000 miles. On the bottom of the engine there is a drain plug. Remove it and drain all the transmission oil out.

Reinstall the drain plug (make sure it is tight). Add 10w/30 oil through the dip stick hole.

Note: DO NOT ADD ANY CHEMICAL ADDITIVES. TRANSMISSION OIL ALSO LUBRICATES THE CLUTCH AND ADDITIVES COULD CAUSE THE CLUTCH TO SLIP.



www.legends-yamaha.com

24. Decarbonization

Carbon deposits in the combustion chamber, on the head of the piston, in the exhaust port, and in the muffler are a constant cause of engine power loss. Decarbonization of these parts is relatively simple, requiring only a few tools. A torque wrench is one of the necessary tools. Going any further though, such as removing the carbon from ring grooves, should be done by a certified mechanic, as this requires cylinder removal.

Begin this servicing step by gradually loosening the four cylinder retaining nuts, in a pattern. DO NOT




LOOSEN EACH NUT COMPLETELY ALL AT ONCE, but work around the cylinder head, loosening each nut $\frac{1}{2}$ turn at a time. Slip the head off and use a dull or round edge scraper to remove the carbon from the combustion chamber (do not remove the spark plug). The round end of a hacksaw blade works quite well. Use a rag dipped in solvent and thoroughly clean the area. Do not scratch the gasket surface.

Bring the piston up to the very top and use the same scraping tool to remove the carbon from the top of the piston. Blow off as much of the loosened carbon as possible, then use the solvent soaked rag to pick up as much of the rest as possible.

Next, rotate the piston as far down as possible. Slip a dry rag down over the piston for protection. Disconnect the muffler. Very carefully use a small scraper and remove the carbon from the port opening (take care that it does not fall back into the cylinder). As soon as possible, scrape the carbon from the exhaust port from the outside opening.

The head can now be put back onto the cylinder. Carefully wipe off the gasket surfaces of both parts. Position the head gasket (which should be a new one) on the cylinder. Slip the head into place and tighten the four retaining bolts until they are finger tight. Use the torque wrench to tighten them further. Total torquing pressure is 15 - 30 ft/lbs. but you should torque all four nuts in a 'cross' pattern, and in two progressive steps of increasing torque (example : 15 ft-lb, 18 ft-lbs) to prehead warpage.



Next, remove the inner cylinder from the back end of the muffler. This is done by removing the set screw and pulling out the assembly. Remove all the carbon deposits with a wire brush. While the assembly is out of the muffler, look inside for additional deposits. If any are present, the muffler should be removed and a stout scraper used to break it loose, Tip the muffler up and shake out all the loose carbon. Reinstall the muffler, slip the inner cylinder back, and tighten down the set screw. This decarbonization procedure, even though it only takes a short time to complete, is absolutely


necessary to prolong the performance life of the engine. Whether you perform this maintenance yourself, or have your dealer do it, be sure to faithfully follow the maintenance time recommendations listed in the chart at the beginning of the SERVICING section.

25. Steering

Periodically you should check for any looseness in the steering assembly. Do this by blocking the front end off the ground, grasping the bottom of the forks, and gently rocking the fork assembly backward and forward. You will feel any looseness in the steering assembly bearings. If any exists, do not attempt to correct it yourself but let your dealer make the adjustment with the correct tools.

Also, these same front fork bearings must also be lubricated every 4,000 miles. This the dealer should also do.

26. Front fork



At least every 4,000 miles the front fork oil should be completely drained and refilled. Remove the Phillips head screws in the very bottom of the forks. Next, remove the fork cap found on top of each fork tube and most of the fork oil will drain out. Compress the forks several times to pump all the remaining oil out. Slowly pour in 5.5 oz. (163cc) oil in each fork leg. (see Lubrication Recommendations section for type oil).

At least every other time you should have your mechanic dismantle the fork assembly and thoroughly clean out each fork. Water and dirt eventually coat much of the inner fork surfaces and cannot be readily removed just by draining.

WARRANTY INFORMATION

Study your Owner's Warranty Guidebook thoroughly. It contains your Warranty Policy, an explanation of the policy, break-in procedures and the warranty-required service schedules. Becoming familiar with these items will be to your advantage in making the best use of Yamaha's warranty program.

The acceptance of any warranty claim that your dealer might submit in the future depends greatly on just what has been done to the motorcycle. IF ANY PARTICULAR FAILURE CAN BE TRACED DIRECTLY TO A REPAIR OR MAINTENANCE PERFORMED INCORRECTLY. THE WARRANTY CLAIM MAY NOT BE ACCEPTED. For this reason, we recommended that all services beyond those detailed in this manual be performed by a qualified mechanic at an authorized Yamaha dealer.

There are certain requirements that must be met to qualify for warranty coverage.

1. Your machine must be registered for warranty. This is accomplished when the Warranty Registration card is filled out by you and mailed by the dealer to Yamaha at the time of purchase.
2. Your Owner's Warranty Guidebook outlines the required service schedules and provides a maintenance record for your protection and convenience. Proper maintenance will insure a trouble free life for your new Yamaha.
3. If any problems occur which you feel should be covered under warranty, NOTIFY YOUR DEALER IMMEDIATELY. Do not delay, as little problems left unrepaired can become large problems which may not be covered under warranty.

REQUIREMENTS FOR A GOOD MOTORCYCLIST

1. Safety is more important than speed. Always observe traffic regulations & signs.
2. Always use quality gasoline and oil, and avoid the inconvenience of running out of gas or oil.
3. Check tire pressures before every ride.
4. Warm up the engine for about one minute before riding.
5. Shift gears gently, while momentarily closing the throttle, avoid power shifting.
6. During the break-in period, ride at the suggested speed in each gear.
7. Apply the front and the rear brake at the same time
8. Down a long hill, use engine compression as a brake.
9. When parking, be sure to turn off and remove the ignition key, turn off the fuel cock, and lock the steering.
10. Check parts at regular intervals as described in this manual.

Troubleshooting

1 Factory Authorized Service

Your Yamaha dealer is a factory trained mechanic who guarantees thorough and correct maintenance for your motorcycle. We recommend that you let your dealer make all repairs and adjustments on your motorcycle. You will be assured prompt and good service.

2 Genuine Yamaha Parts

Always use genuine Yamaha parts and not "substitute" brands. Yamaha parts are manufactured to meet the factory's exacting standards of precision and quality.

3 If Something Should Go Wrong

The RD200A undergoes rigid factory tests to assure you long and satisfactory performance. However, if something should go wrong with your machine, immediately ask your Yamaha dealer for advice. He is always glad to answer your questions.

IMPORTANT: Some components are sealed or cannot be disassembled. If repairs to such components are necessary go to your Yamaha dealer. Yamaha cannot be responsible for repairs and adjustments to such components performed by non-authorized personnel.

Note: The inspection and maintenance of Autolube should be entrusted to your dealer.

Specifications

Model	YAMAHA RD 200A	
Dimension	Overall length	76.6 in. (1,945 mm)
	Overall width	29.1 in. (740 mm)
	Overall height	39.6 in. (1,005 mm)
	Wheelbase	49.0 in. (1.245 mm)
	Minimum road clearance	6.1 in. (155 mm)
Weight	Net	25.6 lbs (116 kg)
Performance	Maximum speed	85~90 mph (135~140 km/h)
	Fuel consumption (on paved level road)	82.5 mile/US gal at 31 mph (35 km/ at 50 km/h)
	Climbing capacity	24 degrees
	Minimum turning radius	82.7 in. (2,100 mm)
	0-400 acceleration	16.0 sec.
	Braking distance	46 ft at 31 mph (14 m at 50 km/h)
Engine	Type	Air-cooled, 2-stroke, gasoline, Torque induction
	Engine model	397
	Cylinder	2 in parallel, forward inclined
	Displacement	11.89 cu.in. (195 c.c.)

	Bore & Stroke	2,047 in. x 1.811 in. (52 mm x 46 mm)
	Compression ratio	7.1 : 1
	Starting system	Primary kick
	Ignition system	Battery
	Gasoline oil tank capacity	3.0 US qt (11.5 ℓ)
	Oil tank capacity	2.1 US qt (2 ℓ)
	Lubricating system	Separate lubrication (Yamaha Autolube)
	Battery capacity	12V, 9AH
	Battery type	12N9-3A-1
	Generator system	Starter Generator
	Generator type	GS214-02
	Generator manufacturer	HITACHI
	Spark plug	NGK (B-8HS) x 2
	Carburetor	V20P x 2
	Air cleaner	Wet foam rubber
Transmission	Primary reduction system	Gear
	Primary reduction ratio	53/16 3.312
	Secondary reduction system	Chain
	Secondary reduction ratio	36/15 2.400
	Clutch	Wet, multi-disc
	Gear box type	Constant mesh, 5-speed

Operating system	Left foot operated, Return system	
Gear ratio	First	34/12 2.833
	Second	29/17 1.705
	Third	25/20 1.250
	Fourth	23/22 1.045
	Fifth	22/24 0.916

Steering	Caster	62° 30'
	Trail	3.7 in. (95 mm)

Tire size	Front	2.75 - 18 - 4PR
	Rear	3.25 - 18 - 4PR

Suspension system	Front	Telescopic fork
	Rear	Swing arm

Cushion system	Front	Coil spring, oil damper
	Rear	Coil spring, oil damper

Frame	Steel tubing, diamond structure
-------	---------------------------------

Lamps	Headlamp	12V, 35W/25W
	Taillamp	12V, 8W
	Stoplamp	12V, 27W
	Flasherlamps	12V, 27W
	Pilot lamps N	12V, 3W
	" F	12V, 3W
	" H	12V, 2W
	Meter lamps	22V, 3W
	Meter system	Separate type, tachometer & Speedometer

www.legends-yamaha-enduros.com

Consumer Information

Stopping Distance

This figure indicates braking performance that can be met or exceeded by the vehicles to which it applies, without locking the wheels, under different conditions of loading and with partial failures of the braking system. The information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions and the information may not be correct under other conditions.

Description of vehicles to which this table applies: Yamaha motorcycle RD200 A

A. Fully Operational Service Brake

Load

Light

Maximum

180

185

0 100 200 300

Stopping Distance in Feet from 60 mph.

Acceleration and passing ability

This figure indicates passing times and distances that can be met or exceeded by the vehicles to which it applies, in the situations diagrammed below.

The low-speed pass assumes an initial speed of 20 mph and a limiting speed of 35 mph. The high-speed pass assumes an initial speed of 50 mph and a limiting speed of 80 mph.


NOTICE: The information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions, and the information may not be correct under other conditions.

Description of vehicles to which this table applies: Yamaha motorcycle RD'200A


Summary table:

Low-speed pass	365 feet;	7.6 seconds
High-speed pass	1330 feet;	15.0 seconds

LOW-SPEED



HIGH-SPEED



www.legends-yamaha-enduros.com



SINCE 1887

YAMAHA MOTOR CO., LTD.

IWATA, JAPAN

LIT - 11623 - 97 - 00

Printed in Japan

'73-11.3.0 X1 